Havells Esteam

Havells Esteam 1800-Watt Steam Iron User Manual

Model: Esteam

1. Introduction

Thank you for choosing the Havells Esteam 1800-Watt Steam Iron. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read these instructions carefully before first use and retain them for future reference.

2. Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions.

- Ensure the voltage indicated on the iron corresponds to your main supply voltage.
- Do not immerse the iron, power cord, or plug in water or other liquids.
- Always unplug the iron from the electrical outlet when filling with water, emptying, or when not in use.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.
- Keep the iron and its cord out of reach of children.
- The iron features an overheat safety protection circuit that ensures automatic cut-off if left unattended for too long.
- Use the iron only for its intended household purpose.
- Never direct steam at people or pets.

3. Product Overview

Familiarize yourself with the components of your Havells Esteam Steam Iron.



Image: Havells Esteam 1800-Watt Steam Iron. This image displays the steam iron from a side angle, highlighting its blue water tank, white body, and black soleplate. The temperature dial and steam control are visible on the top surface.

3.1. Included Components

- Havells Esteam 1800-Watt Steam Iron
- Instruction Manual

4. Setup

4.1. Before First Use

1. Remove any labels or protective film from the soleplate.
2. It is recommended to iron an old piece of damp cloth for a few minutes to remove any manufacturing residues.

4.2. Filling the Water Tank

- Ensure the iron is unplugged from the power outlet.
- Open the water filler cap.
- Fill the 250 ml water tank with clean tap water up to the MAX mark. Do not overfill.
- Close the water filler cap securely.

5. Operating Instructions

5.1. Temperature Setting

1. Plug the iron into a suitable power outlet (220-240 volts).
2. Turn the temperature control dial to the desired setting based on the fabric type. Refer to the fabric care labels on your garments.
3. The indicator light will illuminate, indicating the iron is heating. It will turn off when the set temperature is reached.

5.2. Steam Ironing

- Ensure the water tank is filled.
- Set the temperature dial to the steam range (usually marked with three dots or a steam symbol). Steam will only be produced at higher temperatures.
- Once the indicator light turns off, select the desired steam level using the steam control slider. The

iron provides 15g/min powerful steam.

- Begin ironing.

5.3. Dry Ironing

- Ensure the water tank is empty or the steam control is set to the 'no steam' position.
- Set the temperature dial according to the fabric type.
- Proceed with ironing.

6. Maintenance and Care

6.1. Cleaning the Iron

- Always unplug the iron and allow it to cool completely before cleaning.
- Wipe the soleplate with a damp cloth and a non-abrasive cleaner if necessary.
- Clean the exterior of the iron with a soft, damp cloth. Do not use harsh abrasives or solvents.

6.2. Descaling (Self-Clean Function)

Regular descaling helps maintain steam performance. Refer to the full product manual for detailed descaling instructions if a self-clean function is available and not explicitly mentioned here.

6.3. Storage

- After use, unplug the iron and empty any remaining water from the tank.
- Allow the iron to cool down completely.
- Store the iron upright on its heel rest in a dry, safe place.

7. Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outage; faulty outlet.	Check power connection; test outlet with another appliance.
No steam or insufficient steam.	Water tank empty; temperature too low; steam control set to 'no steam'; mineral buildup.	Fill water tank; set temperature to steam range; adjust steam control; descale the iron.
Water leaks from soleplate.	Temperature too low for steam; water tank overfilled; iron stored with water.	Increase temperature; do not overfill; empty tank after use.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

- **Model:** Esteam
- **Brand:** Havells
- **Power:** 1800 Watts

- **Operating Voltage:** 220 - 240 Volts
- **Water Tank Capacity:** 250 ml
- **Steam Output:** 15g/min
- **Item Weight:** 550 g
- **Item Dimensions (LxWxH):** 24 x 10.5 x 11.5 Centimeters
- **Safety Feature:** Overheat safety protection circuit

9. Warranty and Support

Your Havells Esteam 1800-Watt Steam Iron comes with a**2-year warranty** on the product from the date of purchase.

For warranty claims, technical support, or service inquiries, please contact Havells customer service. Keep your purchase receipt as proof of purchase.

For more information, visit the official Havells website or refer to the contact details provided with your product packaging.