

Manuals.plus /

› YAKOE /

› YAKOE Conservatory 9 Seater Outdoor Rattan Garden Furniture Classical Corner Dining Set Instruction Manual

YAKOE B01MQFVT7Z

YAKOE Conservatory 9 Seater Outdoor Rattan Garden Furniture Classical Corner Dining Set Instruction Manual

Model: B01MQFVT7Z

1. INTRODUCTION

Thank you for purchasing the YAKOE Conservatory 9 Seater Outdoor Rattan Garden Furniture Classical Corner Dining Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture set. Please read these instructions carefully before assembly and retain them for future reference.



Image 1.1: The YAKOE Conservatory 9 Seater Outdoor Rattan Garden Furniture Classical Corner Dining Set, showcasing the L-shaped sofa, dining table, and footstools in a garden environment.

2. SAFETY INFORMATION

- Ensure all components are present and undamaged before beginning assembly. Do not use if any parts are missing or damaged.
- Assemble the furniture on a soft, clean surface to prevent scratches or damage.
- Always tighten all bolts and screws securely. Periodically check and re-tighten all fasteners to ensure stability.
- Do not stand or jump on the furniture.
- Keep children and pets away from the assembly area.
- Place the furniture on a level surface to prevent tipping.
- The glass tabletop is fragile. Handle with care during assembly and use. Avoid placing excessively hot or heavy objects directly on the glass.

3. PACKAGE CONTENTS

Your YAKOE Conservatory 9 Seater Outdoor Rattan Garden Furniture Classical Corner Dining Set is delivered in 4 packages and includes the following components:

- One (1) Three-seater sofa unit
- One (1) Three-sided sofa unit (corner section)
- One (1) Glass-topped dining table
- Three (3) Footstools
- All necessary cushions for sofas and footstools
- All required fixings and assembly instructions



4. SETUP AND ASSEMBLY

This furniture set requires self-assembly. Detailed assembly instructions with diagrams are included in one of the packages. Please follow these steps carefully:

1. **Unpack all components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent damage. Verify that all listed components and fixings are present.
2. **Assemble sofa units:** Follow the provided diagrams to connect the sections of the three-seater sofa and the three-sided corner sofa. Ensure all bolts are finger-tightened initially.
3. **Assemble dining table:** Construct the dining table frame according to the instructions. Carefully place the glass tabletop onto the assembled table frame, ensuring it is securely seated.
4. **Assemble footstools:** Assemble the three footstools as per the instructions.
5. **Final tightening:** Once all units are assembled, carefully place them in their desired positions. Then, systematically tighten all bolts and screws using the provided tools until secure. Do not overtighten.
6. **Place cushions:** Distribute the cushions onto the sofa units and footstools.

It is recommended to have two people for assembly to ensure ease and safety, especially when handling larger components and the glass tabletop.

5. OPERATING AND USAGE

Your YAKOE Rattan Garden Furniture set is designed for outdoor use and can be left outside all year round. It provides comfortable seating and dining space for up to 9 people.

- **Seating:** The L-shaped corner sofa and three footstools offer flexible seating arrangements.
- **Dining:** The glass-topped dining table is suitable for outdoor meals and entertaining.
- **Cushions:** The included cushions are water-resistant. While designed for outdoor use, it is advisable to store them in a dry place during prolonged periods of heavy rain or in winter to extend their lifespan.



Image 5.1: The YAKOE dining set arranged for use, showing the comfortable cushions and spacious dining table.

6. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your rattan furniture set.

- **Rattan Frame:** The rattan material is designed to be weather-resistant. To clean, simply wipe with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- **Cushions:** The cushions are water-resistant and washable. Hand washing is recommended to maintain their quality. Allow cushions to air dry completely before storing or reusing.
- **Glass Tabletop:** Clean the glass with a standard glass cleaner and a soft cloth. Avoid abrasive cleaners or scouring pads that could scratch the surface.
- **Winter Storage:** While the rattan frame can be left outdoors, covering the furniture during winter months or prolonged periods of non-use will help protect it from extreme weather conditions and extend its life. Store cushions indoors in a dry place during these periods.
- **Fasteners:** Periodically check all bolts and screws and re-tighten them as necessary to ensure the furniture remains stable and secure.



Image 6.1: Detail of the glass tabletop securely placed on the rattan weave, showing the material texture.



Image 6.2: A detailed view of the durable grey rattan weave, illustrating its texture and construction.

7. TROUBLESHOOTING

If you encounter any issues with your furniture set, please refer to the following common solutions:

- **Wobbly Furniture:** Ensure all bolts and screws are securely tightened. Check that the furniture is placed on a level surface. Adjust if necessary.
- **Missing Parts:** Double-check all packaging. If parts are genuinely missing, contact customer support with your purchase details.
- **Difficulty Assembling:** Review the assembly instructions carefully. Ensure you are using the correct parts for each step. Do not force components together.
- **Cushion Care:** If cushions become wet, allow them to dry thoroughly in a well-ventilated area to prevent mildew.

8. SPECIFICATIONS

Feature	Detail
Model Number	B01MQFVT7Z
Brand	YAKOE
Color	Grey
Material Type	Rattan
Item Weight	27.8 Kilograms
Overall L-shaped Corner Sofa Dimensions	180.5 cm x 240.5 cm x 70 cm (Length x Width x Height)
Dining Table Dimensions	130 cm x 80 cm x 75 cm (Length x Width x Height)
Footstool Dimensions	47 cm x 40 cm x 40 cm (Length x Width x Height)
Required Assembly	Yes
Product Care Instructions	Wipe with Damp Cloth (Rattan), Hand washing recommended (Cushions)

9. WARRANTY AND SUPPORT

For any questions, missing parts, or support regarding your YAKOE Conservatory 9 Seater Outdoor Rattan Garden Furniture Classical Corner Dining Set, please refer to your purchase documentation for specific warranty information and contact the retailer or manufacturer directly. Keep your proof of purchase for warranty claims.

You can often find contact information on the YAKOE brand page or through your Amazon order history.