

Yaheetech 3 Tier Console Sofa Table

Yaheetech 3 Tier Console Sofa Table with Drawer - Instruction Manual

Model: 3 Tier Console Sofa Table

INTRODUCTION

Thank you for choosing the Yaheetech 3 Tier Console Sofa Table. This manual provides detailed instructions for assembly, proper usage, maintenance, and troubleshooting to ensure safe and efficient operation of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload shelves or the tabletop. Refer to specifications for weight limits.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.
- Do not stand or climb on the table.
- Use caution when moving the table to prevent damage or injury. Lift, do not drag.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop Panel
- Bottom Base Panel
- Middle Shelf Panel
- Side Support Panels (2)
- Central Support Panel

- Drawer Components (Front, Back, Sides, Bottom)
- Drawer Knob
- Hardware Pack (Screws, Dowels, Cam Locks, Drawer Slides)
- Assembly Tool (Hex Key)

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults. A Phillips head screwdriver (not included) may be needed in addition to the provided hex key.



Figure 1: Product dimensions and key components.

- 1. Prepare the Base:** Attach the two Side Support Panels and the Central Support Panel to the Bottom Base Panel using the provided screws and dowels. Ensure they are aligned correctly.
- 2. Install Middle Shelf:** Secure the Middle Shelf Panel between the Side Support Panels and the Central Support Panel using screws and cam locks. Make sure the shelf is level.
- 3. Assemble the Drawer:** Connect the drawer sides, front, and back panels. Slide the drawer bottom into the grooves. Attach the drawer slides to the drawer box and the corresponding locations on the table structure

(under the tabletop). Fasten the drawer knob to the drawer front.

4. **Attach Tabletop:** Carefully place the Tabletop Panel onto the assembled structure, aligning it with the pre-drilled holes. Secure the tabletop using the remaining screws and cam locks.
5. **Final Check:** Ensure all connections are tight and the table is stable.



Figure 2: Assembled console table.

OPERATING INSTRUCTIONS (USAGE)

The Yaheetech 3 Tier Console Sofa Table is designed for various uses in your living space:

- **Display Surface:** Use the top surface for decorative items, lamps, or framed photos.
- **Storage Drawer:** The integrated drawer provides discreet storage for small items such as keys, remote controls, or stationery.
- **Open Shelves:** The middle and bottom shelves offer additional space for books, baskets, or other decorative accents.



Figure 3: Drawer in use for storage.

MAINTENANCE

Proper care will extend the life and appearance of your console table:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining, especially on the engineered wood surface.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Table is wobbly or unstable.	Loose fasteners; uneven floor.	Ensure all screws and cam locks are fully tightened. Adjust floor levelers if present, or place shims under legs.
Drawer does not slide smoothly.	Drawer slides misaligned; debris in tracks.	Check that drawer slides are correctly installed and aligned. Clean tracks of any dust or debris. Apply a silicone-based lubricant if necessary.
Parts do not fit together.	Incorrect orientation; manufacturing defect.	Review assembly steps and diagrams to ensure parts are oriented correctly. Do not force parts. If a defect is suspected, contact customer support.
Screws do not tighten.	Stripped hole; incorrect screw size.	Ensure you are using the correct screw for the designated hole. If a hole is stripped, wood glue and a dowel can be used to repair it, or contact customer support for replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	Yaheetech
Model Name	3 Tier Console Sofa Table
Product Dimensions (D x W x H)	11.6" x 36" x 34.3" (29.5 cm x 91.4 cm x 87.1 cm)
Item Weight	24.91 Pounds (11.3 kg)
Frame Material	Engineered Wood
Color	Black
Number of Drawers	1
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's policy or contact Yaheetech customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, visit the [Yaheetech Store on Amazon](#).