

- Manuals.plus /
- > CUCKOO /
 - > Cuckoo CR-0655F Rice Cooker & Warmer User Manual

CUCKOO CR-0655F

CUCKOO CR-0655F Rice Cooker & Warmer User Manual

Model: CR-0655F

PRODUCT OVERVIEW

The CUCKOO CR-0655F Rice Cooker & Warmer is designed for effortless and precise cooking. Its advanced Fuzzy Logic Technology automatically adjusts cooking time and temperature, ensuring perfectly cooked rice every time. With a 6-cup uncooked (12-cup cooked) capacity, it's suitable for both small and large households.

This versatile appliance offers 11 menu options, including Glutinous (White) Rice, Mixed Rice, Brown/GABA Rice, Porridge, Steam, Multi Cook, and Baby Food. Additional features like Turbo mode for faster cooking, a timer setting for delayed cooking, and a warming mode to keep food at optimal temperature make it a convenient addition to any kitchen.



Image: The CUCKOO CR-0655F Rice Cooker & Warmer, showcasing its sleek red and white design with a digital display.

Key Features:

- **Fuzzy Logic Technology:** Guarantees perfectly cooked rice by automatically adjusting cooking parameters.
- **11 Menu Options:** Diverse cooking modes for various rice types and other dishes.
- **6-Cup Uncooked Capacity:** Yields up to 12 cups of cooked rice, suitable for families.
- **Easy to Use & Clean:** High-visibility LED display, simple touch buttons, non-stick inner pot, and self-clean setting.
- **Timer & Warming Mode:** Convenient for busy schedules, keeping food ready when needed.

Official Product Video

Video: An official product overview of the Cuckoo CR-0655F Rice Cooker and Warmer, highlighting its features and design.

SETUP

Unboxing and Initial Inspection


Upon unboxing, ensure all components are present and undamaged. The package should include the CUCKOO CR-0655F Rice Cooker, a non-stick inner pot, a rice scoop, and a rice measuring cup.



TURBO MODE

Fast Track to Flavor

Enjoy Speedy Cooking Sessions



BUILT-IN TIMER



Prep Now, Cook Later

Set Cooking Times Up to 12 Hours Early

Image: The essential accessories included with the rice cooker: a rice paddle, a measuring cup, and the non-stick inner pot.

Placement

Place the rice cooker on a stable, flat, and heat-resistant surface. Ensure there is adequate ventilation around the unit. Avoid placing it near heat sources or in direct sunlight. The product dimensions are approximately 8.6"D x 9.4"W x 13"H.


Designed for Easy & Convenient Cooking



#1 Brand in Korea



Intelligent Modes



Versatile Cooking

UP TO **6** Cups Capacity



Image: The CUCKOO CR-0655F Rice Cooker on a kitchen counter, illustrating its compact design and dimensions.

Power Connection

Connect the power cord to the rice cooker and then plug it into a standard 120V electrical outlet. Ensure the outlet is properly grounded.

Initial Cleaning

Before first use, wash the non-stick inner pot, removable lid, rice scoop, and measuring cup with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.

OPERATING INSTRUCTIONS

Basic Rice Cooking

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. One cup of uncooked rice yields approximately two cups of cooked rice.
2. **Wash Rice:** Rinse the rice thoroughly under cold water until the water runs clear.
3. **Add Water:** Place the washed rice into the inner pot. Add water up to the corresponding water level mark inside the pot for the type and amount of rice you are cooking.
4. **Select Menu:** Close the lid securely. Use the 'Menu' button on the LCD display to select your desired cooking mode (e.g., Glutinous, Mixed, Brown/GABA).
5. **Start Cooking:** Press the 'Cook' button to begin the cooking cycle. The Fuzzy Logic Technology will automatically optimize cooking time and temperature.

One Cooker, Countless Dishes

Satisfy Every Craving With a Range of Presets for Any Occasion

GLUTINOUS

MIXED

BROWN/GABA

PORRIDGE

MULTICOOK

BABYFOOD

Teriyaki Chicken Bowl



White Rice



Brown Rice & Veggie



Braised Pork



Angel Cake



Image: A visual representation of the smart cooking process, from water and rice measurement to the final cooked product, highlighting the Fuzzy Logic technology.

Advanced Cooking Modes

The CR-0655F offers various specialized cooking modes:

- **Turbo Mode:** For faster cooking of white rice when you're short on time.
- **Mixed Rice:** Optimized for cooking mixed grain rice.

- **Brown/GABA Rice:** Specific settings for brown rice and GABA rice to ensure proper texture and nutrient retention.
- **Porridge:** Ideal for preparing creamy porridge.
- **Steam:** Use for steaming vegetables or other foods.
- **Multi Cook:** A versatile setting for various non-rice dishes, including cakes.
- **My Mode:** Allows customization of cooking settings for unique flavor and texture preferences.

Compact Design, Big Flavor

Enjoy Delicious Food Without Taking up Valuable Counter Space



Included Accessories



Rice Paddle



Measuring Cup



Inner Pot

Image: A close-up of the rice cooker's LCD display, showing the various menu options available for different cooking needs.

Timer and Keep Warm Functions

- **Timer Setting:** Use the 'Timer' button to set a delayed cooking start time, ensuring your meal is ready exactly when you need it.
- **Keep Warm:** After cooking, the unit automatically switches to 'Keep Warm' mode, maintaining the rice at an optimal serving temperature for hours without drying it out.
- **Reheat:** If rice has cooled, use the 'Reheat' function to bring it back to a warm, palatable temperature.

MAINTENANCE

Cleaning the Rice Cooker

Regular cleaning ensures optimal performance and longevity of your rice cooker. Always unplug the unit and allow it to cool completely before cleaning.

- **Inner Pot:** The non-stick inner pot should be hand washed with warm, soapy water. Avoid abrasive scrubbers to protect the non-stick coating.
- **Removable Lid:** The lid is easily detachable for thorough cleaning. Wash with warm, soapy water and rinse well.
- **Self-Clean Function:** Utilize the 'Auto Clean' setting for powerful steam sterilization of the interior. Follow the instructions in the detailed manual for this feature.
- **Water Collection Cup:** Regularly remove and empty the water collection cup located at the back of the unit. Wash it with soap and water.
- **Exterior:** Wipe the exterior of the rice cooker with a soft, damp cloth. Do not immerse the main unit in water.

Hassle-Free Maintenance

Spend Less Time Cleaning with Thoughtful Features



Easy Detachable Cover

Easily Remove the Cover for Convenient Cleaning



One-Touch Cleaning

Powerful Steam Sterilization With Self Cleaning



Push Auto Clean



Self-Cleaning



Smart Water Flow

Cleans Stagnant Water Inside to Maintain Fresh Rice Taste



Image: Visuals demonstrating the easy detachable cover, the one-touch self-cleaning function, and the smart water flow system for fresh rice taste.

TROUBLESHOOTING

If you encounter any issues with your CUCKOO CR-0655F Rice Cooker, please refer to the following common solutions

before contacting customer support:

- **Rice too hard/soft:** Ensure the correct rice-to-water ratio is used according to the inner pot's markings and the type of rice.
- **Rice sticking to the pot:** Ensure the non-stick inner pot is clean and undamaged. A small amount of cooking oil can be added before cooking if issues persist.
- **Unit not powering on:** Check if the power cord is securely plugged into both the unit and a working electrical outlet.
- **Error codes on display:** Consult the comprehensive user manual (PDF link available online) for specific error code meanings and resolutions.

For persistent problems or issues not covered here, please contact CUCKOO customer support.

SPECIFICATIONS

Feature	Specification
Brand	CUCKOO
Model Name	Micom Rice Cooker
Item Model Number	CR-0655F
Capacity	6 Cups (Uncooked) / 12 Cups (Cooked)
Product Dimensions	8.6"D x 9.4"W x 13"H
Power Source	Power Plug
Voltage	120V
Wattage	700 watts
Material	Plastic
Color	Red/White
Item Weight	7 Pounds
Product Care Instructions	Hand Wash

WARRANTY & SUPPORT

For detailed warranty information, please refer to the official CUCKOO website or the full user manual provided with your product. CUCKOO products are known for their durability and quality. If you require technical assistance, have questions about operation, or need to inquire about replacement parts, please

contact CUCKOO customer support. You can often find contact information on the manufacturer's website or within the original product packaging.

An electronic version of the user manual is available for download:[User Manual \(PDF\)](#)

© 2025 CUCKOO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01MQWFGKG>

More documents and user manuals: <https://manuals.plus/>