ASAKUKI 100-DF001

ASAKUKI 500ml Premium Essential Oil Diffuser User Manual

Model: 100-DF001

1. Product Overview

The ASAKUKI 500ml Premium Essential Oil Diffuser is a versatile 5-in-1 aromatherapy device designed to enhance your living space. It functions as an essential oil diffuser, humidifier, air purifier, ionizer, and night light. Featuring a large water tank, remote control, and multiple settings, it provides a relaxing and fragrant atmosphere.

Key Features:

- **5-in-1 Functionality:** Diffuser, Humidifier, Air Purifier, Ionizer, Night Light.
- **Large Capacity:** 500ml water tank for extended operation.
- **Remote Control:** Conveniently adjust settings from a distance.
- **7 LED Light Colors:** Customizable ambient lighting, fixed or cycling.
- **Multiple Mist Modes:** Continuous, 60/120/180 minute timers, and intermittent mist.
- **Ultra-Quiet Operation:** Noise level below 23 dB for undisturbed use.
- **Auto-Off Safety Switch:** Automatically shuts off when water runs out.
- **BPA-Free Material:** Safe for use around babies and pets.



The ASAKUKI 500ml Premium Essential Oil Diffuser, shown with its remote control.

2. Setup Guide

Follow these steps for the initial setup of your ASAKUKI Essential Oil Diffuser:

1. **Place the Diffuser:** Position the diffuser on a flat, stable surface. Ensure it is not near any water-sensitive electronics or open flames.
2. **Connect Power:** Plug the power adapter into the diffuser's DC jack, then plug the adapter into a wall outlet.




Step 1: Connect the power adapter to the diffuser.

3. **Remove the Cover:** Gently lift the top cover of the diffuser.
4. **Add Water:** Using a measuring cup, fill the water tank with clean tap water up to the maximum water level line (500ml). Do not overfill.



Step 2: Fill the water tank up to the MAX line.

5. **Add Essential Oil:** Add 2-3 drops of your preferred essential oil directly into the water tank. Adjust the quantity based on your preference and room size.



Step 3: Add a few drops of essential oil.

6. **Replace the Cover:** Carefully place the top cover back onto the diffuser, ensuring it is properly seated.



Step 4: Replace the cover and power on the unit.

3. Operating Instructions

Your ASAKUKI diffuser can be operated using the buttons on the unit or the included remote control.

Using the Remote Control:



The remote control allows for convenient operation from up to 16.5 feet away.

- **ON/OFF Button:** Press to turn the diffuser on or off.
- **Mist Button:** Press to cycle through mist modes: Continuous, 60 minutes, 120 minutes, 180 minutes.
- **High/Low Button:** Adjusts mist intensity between high and low.
- **Light Button:** Turns the LED light on/off. Press repeatedly to cycle through 7 colors or set to a fixed color.
- **Intermittent Mist:** Some remotes may have a dedicated button for intermittent mist (e.g., 10 seconds on, 10 seconds off).

Using the Unit Buttons:

- **LIGHT Button:** Controls the LED light. Press to turn on, cycle through colors, or fix a color. Hold to turn off.
- **HIGH/LOW Button:** Adjusts mist intensity.
- **MIST Button:** Turns on the mist and cycles through timer settings (ON, 60, 120, 180 minutes). Hold to turn off.



The diffuser is suitable for various occasions, from working to sleeping.

4. Maintenance and Care

Regular cleaning is essential to ensure optimal performance and longevity of your diffuser.

Cleaning Instructions:

1. **Unplug the Diffuser:** Always disconnect the power adapter before cleaning.
2. **Empty Water:** Pour out any remaining water from the tank, ensuring to pour from the side opposite the air outlet to avoid water entering the internal components.
3. **Wipe Down:** Use a soft cloth or sponge to wipe the inside of the water tank. For stubborn residue or oil buildup, use a cotton swab dipped in rubbing alcohol or a mixture of distilled water and white vinegar (1:1 ratio).

4. **Clean Ultrasonic Plate:** Gently wipe the ultrasonic vibration plate (the small ceramic disc at the bottom of the tank) with a cotton swab. Do not scratch or apply excessive pressure.
5. **Rinse and Dry:** Rinse the tank with clean water (avoiding the air outlet) and wipe it dry with a clean cloth.
6. **External Cleaning:** Wipe the exterior of the diffuser with a soft, dry cloth.

Important Note:

• Do not use corrosive detergents or harsh chemicals.
• Do not immerse the entire unit in water.
• Clean the diffuser regularly, especially if you change essential oils frequently or use it daily.

5. Troubleshooting

Problem	Possible Cause	Solution
No mist or low mist output	◦ Insufficient water in tank ◦ Water level too high ◦ Ultrasonic plate dirty or clogged ◦ Diffuser not placed on a flat surface ◦ Too much essential oil	◦ Add water to the appropriate level. ◦ Remove some water. ◦ Clean the ultrasonic plate as per maintenance instructions. ◦ Ensure the diffuser is on a flat surface. ◦ Clean the diffuser and use less oil.
Diffuser beeps twice and shuts off	Water tank is empty.	Refill the water tank. This is a safety feature to prevent dry burning.
Light not working	Light function is off or malfunction.	Press the 'Light' button on the unit or remote to turn it on. If it still doesn't work, contact support.
Remote control not responding	Battery drained or obstruction.	Replace the remote control battery. Ensure no obstructions between the remote and the diffuser.
Cannot select specific light color via Alexa/Smart Home	This model does not support specific color selection via smart home integration.	The LED light will cycle through colors automatically or can be fixed to a color by pressing the physical button on the device to 'pause' the cycle. Specific color selection via voice command is not a supported feature for this model.

6. Specifications

Feature	Detail
Brand	ASAKUKI
Model Name	ROCK
Model Number	100-DF001
Capacity	500 Milliliters
Runtime	Up to 18 hours (low mist mode)
Coverage Area	300 square feet
Noise Level	Less than 23 dB
Power Source	Corded Electric
Wattage	12 watts
Material	Polypropylene (PP), BPA Free
Product Dimensions	6.62"L x 6.62"W x 4.93"H (16.8 cm L x 16.8 cm W x 12.5 cm H)
Item Weight	1.1 pounds (500 Grams)
UPC	190835221999



Product dimensions and capacity details.

7. Warranty and Support

ASAKUKI provides a **two-year technical support** for this product. Your satisfaction is paramount. For any technical assistance or inquiries, please refer to the official user guide or contact ASAKUKI customer service.
You can also download the comprehensive User Guide in PDF format for more detailed informationDownload User Guide (PDF)

© 2025 ASAKUKI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question