

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Woods](#) /

› [Woods WiOn 50063 Smart Plug-In Indoor and Outdoor Wi-Fi Switch and Yard Stake Bundle Instruction Manual](#)

Woods 50063

Woods WiOn 50063 Smart Plug-In Indoor and Outdoor Wi-Fi Switch and Yard Stake Bundle

Model: 50063 | Brand: Woods WiOn

INTRODUCTION

This instruction manual provides detailed guidance for the setup, operation, and maintenance of your Woods WiOn 50063 Smart Plug-In Indoor and Outdoor Wi-Fi Switch and Yard Stake Bundle. This bundle includes one WiOn 50050 indoor outlet and one WiOn 50053 outdoor yard stake, designed to provide convenient Wi-Fi control over your indoor and outdoor electrical devices.

IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the product in water or expose it to excessive moisture.
- Ensure the product is properly grounded.
- Do not exceed the maximum electrical ratings (125 Volts, 1000 Watts).
- Keep children away from electrical outlets and devices.
- Disconnect power before performing any maintenance or cleaning.
- The outdoor yard stake is weather-resistant but should not be submerged. Ensure all plugs are fully inserted into the outlets to maintain weather resistance.

PACKAGE CONTENTS

Your Woods WiOn 50063 bundle includes:

- 1 x WiOn 50050 Indoor Wi-Fi Smart Plug
- 1 x WiOn 50053 Outdoor Wi-Fi Yard Stake (with 6-foot cord)
- Instruction Manual

PRODUCT OVERVIEW

The WiOn 50063 bundle provides smart control for both indoor and outdoor applications. The indoor plug features a single grounded outlet, while the outdoor yard stake offers three Wi-Fi controlled outlets and three constant-on outlets, all housed in a durable, weather-resistant casing.



Image: The Woods WiOn 50050 indoor smart plug (left) and the WiOn 50053 outdoor yard stake (right).

SETUP GUIDE

1. Download the WiOn App

Search for "WiOn" in your smartphone's app store (available for iOS and Android). Download and install the application.

2. Connect to Wi-Fi

Ensure your smartphone or tablet is connected to your home's 2.4 GHz Wi-Fi network. The WiOn devices operate on this frequency.

3. Plug In Your Device

Plug the WiOn indoor smart plug or outdoor yard stake into a standard electrical outlet. The indicator light on the device will begin to flash, indicating it's ready for pairing.



Image: The WiOn indoor smart plug installed in a wall outlet, ready for use with an appliance like a fan.

4. Pair with the App

1. Open the WiOn app and follow the on-screen instructions to add a new device.
2. The app will guide you through connecting the WiOn device to your Wi-Fi network.

3. Once connected, you can name your device (e.g., "Living Room Lamp," "Backyard Lights") for easy identification.

5. Optimal Placement

For the outdoor yard stake, place it in a location where it can receive a strong Wi-Fi signal and is suitable for your landscape lighting or decorations. The stake design allows for secure placement in the ground.



Image: The WiOn outdoor yard stake discreetly placed within a garden, blending with the foliage.

OPERATING INSTRUCTIONS

Using the WiOn App

The WiOn app provides comprehensive control over your smart plugs and yard stake. You can control devices from anywhere using your smartphone.

- **Remote ON/OFF:** Tap the device icon in the app to instantly turn connected devices on or off.
- **Scheduling:** Set up to 12 ON/OFF settings per day. You can customize schedules for daily, weekdays, or weekends.
- **Countdown Timer:** Use the countdown feature to automatically turn off a device after a set period.
- **Random/Vacation Mode:** Activate this mode to randomly turn lights on and off, giving your home a lived-in appearance when you are away.
- **Sunrise/Sunset:** Program devices to turn on or off automatically based on local sunrise and sunset times.

Manual Control

Each WiOn device also features a manual ON/OFF button directly on the unit for convenient control without the app.



Image: The WiOn outdoor yard stake effectively powering and illuminating outdoor Christmas decorations in a winter environment.

MAINTENANCE

- Keep the devices clean by wiping them with a dry, soft cloth. Do not use harsh chemicals or abrasive cleaners.
- Regularly check the outdoor yard stake for any signs of damage or wear, especially after severe weather conditions.
- Ensure the outdoor unit's outlets are covered when not in use to prevent water ingress.
- Store the devices in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not connecting to Wi-Fi.	Weak Wi-Fi signal; incorrect Wi-Fi password; device too far from router; 5 GHz network.	Move device closer to router; ensure correct 2.4 GHz Wi-Fi network is selected; re-enter password; reset device and try pairing again.
Device not responding to app commands.	No internet connection; app glitch; device offline.	Check your home internet connection; restart the WiOn app; unplug and re-plug the device; ensure device indicator light is solid.

Problem	Possible Cause	Solution
Outdoor stake not working after rain.	Water ingress due to improper plug insertion or extreme weather.	Ensure all plugs are fully inserted and unused outlets are covered. If damage is suspected, discontinue use and replace the unit.


SPECIFICATIONS


Feature	Detail
Model Number	50063
Voltage	125 Volts
Wattage	1000 Watts
Item Weight	1.68 pounds
Product Dimensions	1.75 x 2.75 x 21.5 inches
Included Components	Instruction Manual, WiOn 50050 Indoor Plug, WiOn 50053 Outdoor Yard Stake
Cord Length (Outdoor)	6 feet
Wi-Fi Frequency	2.4 GHz

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Woods WiOn website. Keep your purchase receipt as proof of purchase for warranty claims.

Related Documents - 50063

	<p>Woods 59785 6-Outlet Power Stake and Remote with Built-in Timer Instructions</p> <p>Detailed instructions for the Woods 59785 6-Outlet Power Stake and Remote with Built-in Timer, covering installation, operation, safety, and troubleshooting. Features include a 6 ft. cord, 13A/1625W rating, and remote control functionality.</p>
---	---

	<p><u>Woods 50014 Outdoor 7-Day Digital Timer 3-C with 2-Outlets User Manual</u></p> <p>User manual for the Woods 50014 Outdoor 7-Day Digital Timer. Provides instructions on battery charging, setting current time, programming ON/OFF schedules, overriding timer functions, using random security, countdown, and daylight saving time features.</p>
	<p><u>Woods TD1300-2 Indoor 7-Day Lighting Timer: User Manual & Instructions</u></p> <p>Detailed instructions and specifications for the Woods TD1300-2 Indoor 7-Day Lighting Timer. Learn how to program ON/OFF times, countdown settings, manual override, and random switching features.</p>
	<p><u>Woods Wireless Remote Control Outlet 50125/50125-R User Manual</u></p> <p>User manual for the Woods 50125/50125-R Wireless Remote Control Outlet. Provides instructions on installation, pairing, troubleshooting, specifications, safety warnings, and warranty information.</p>
	<p><u>Woods 59744WD Timer: Setting Clock and Programming Instructions</u></p> <p>Comprehensive guide on how to set the clock and program the timer functions for the Woods 59744WD indoor 24-hour wall switch timer. Learn to set time, program ON/OFF cycles, and understand AUTO mode.</p>
	<p><u>Woods 59773 Wireless Remote Wall Switch - User Guide</u></p> <p>Instructions and specifications for the Woods 59773 wireless remote wall switch, including setup, operation, battery replacement, and FCC compliance information.</p>