

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Alcatel](#) /

› [Alcatel OT-1052G One Touch 1052 Mobile Phone User Manual](#)

Alcatel 1052G

Alcatel OT-1052G One Touch 1052 Mobile Phone User Manual

Model: OT-1052G

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Alcatel OT-1052G One Touch 1052 Mobile Phone. Please read this guide thoroughly before operating your device to ensure proper functionality and to understand its features.

PACKAGE CONTENTS

Verify that your package contains the following items:

- Alcatel OT-1052G Mobile Phone
- 400mAh Li/ion Battery
- MicroUSB Data Cable
- MicroUSB Power Charger
- Stereo Headset

DEVICE OVERVIEW



Figure 1: Front and back view of the Alcatel OT-1052G One Touch 1052 Mobile Phone. The front displays the screen with time and date, navigation buttons, and a numeric keypad. The back shows the textured casing with the Alcatel logo.

The Alcatel OT-1052G features a compact design with a 1.8-inch QQVGA display, a numeric keypad, and essential function buttons. It includes a VGA camera, flashlight, and a microSD card slot for expandable storage.

SETUP

1. Battery Installation

1. Remove the back cover of the phone by gently prying it open from the notch.
2. Align the gold contacts of the 400mAh Li/ion battery with the contacts in the battery compartment.

3. Insert the battery firmly into place.
4. Replace the back cover, ensuring it clicks securely.

2. SIM Card Installation

1. With the battery removed, locate the SIM card slot.
2. Insert your SIM card into the slot with the gold contacts facing down and the cut corner aligned as indicated.
3. Ensure the SIM card is fully seated.

3. microSD Card Installation (Optional)

1. Locate the microSD card slot, typically near the SIM card slot.
2. Insert a microSDHC card (up to 32GB) into the slot until it clicks into place.
3. This card provides additional storage for photos, videos, and MP3 files.

4. Charging the Battery

1. Connect the microUSB power charger to a power outlet.
2. Connect the microUSB data cable to the charging port on your phone.
3. The phone will indicate that it is charging. A full charge takes approximately 3 hours.
4. Alternatively, the device can be charged via a computer's USB port using the microUSB data cable.

OPERATING INSTRUCTIONS

Power On/Off

- To power on, press and hold the **Power/End Call** button until the screen lights up.
- To power off, press and hold the **Power/End Call** button, then select "Power off" from the options.

Making Calls

1. From the home screen, enter the phone number using the numeric keypad.
2. Press the **Call** button (usually the green button) to initiate the call.
3. To end a call, press the **Power/End Call** button (usually the red button).

Sending SMS Messages

1. Navigate to the **Menu** and select **Messages**.
2. Choose **Create new message**.
3. Enter the recipient's phone number or select from **Contacts**.
4. Type your message using the keypad.
5. Press **Send**.

Camera Function

- Access the camera from the **Menu**.
- Use the navigation keys to frame your shot.
- Press the center navigation key to capture a photo or start/stop video recording.
- Photos and videos are saved to the phone's memory or the installed microSD card.

FM Radio

- Connect the stereo headset (included) to the 3.5mm audio jack; it acts as an antenna.
- Go to **Menu** and select **FM Radio**.

- Scan for available stations or tune manually.

Flashlight

- The flashlight can typically be activated or deactivated via a dedicated side button or through the **Menu**. Refer to the on-screen prompts.

Bluetooth Connectivity

- To enable Bluetooth, go to **Menu > Settings > Connectivity > Bluetooth**.
- Turn Bluetooth **On** and search for available devices to pair.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the phone's screen and body. Avoid liquid cleaners or abrasive materials.
- **Battery Care:** To prolong battery life, avoid exposing the phone to extreme temperatures. Do not leave the battery fully discharged for extended periods.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and moisture when not in use.

TROUBLESHOOTING

Problem	Possible Solution
Phone does not power on	Ensure the battery is correctly installed and charged. Connect the charger and try again.
Cannot make or receive calls	Check if the SIM card is properly inserted. Verify network coverage in your area. Contact your service provider if issues persist.
Battery not charging	Ensure the charger and cable are securely connected and undamaged. Try a different power outlet or USB port.
Poor audio quality	Check the volume settings. Ensure the speaker/microphone is not obstructed. For calls, try moving to an area with better network reception.
MicroSD card not detected	Ensure the microSD card is correctly inserted. Try reinserting it or using a different compatible card.

SPECIFICATIONS

Feature	Detail
Brand	Alcatel
Model	OT-1052G
Display	1.8 Inches QQVGA (128 x 160 pixels) LCD
Operating System	Alcatel Basic OS
Memory Storage Capacity	32 GB (via microSDHC, card not included)
RAM Memory Installed Size	32 MB

Feature	Detail
Camera	VGA for Photos and Videos (640x480 pixels video capture)
Battery	400mAh Li/ion (up to 2 hours talk time, 120 hours standby)
Connectivity	2G Cellular Technology, Bluetooth, USB (microUSB)
Audio Output	3.5 mm jack
Additional Features	FM Radio, MP3 Player, Flashlight, Calendar, Alarm Clock, Dictator
Dimensions	11 x 10 x 9 cm; 63 g

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Alcatel website. Keep your proof of purchase for warranty claims.