

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ariete](#) /
- › [Ariete 4145 XVAPOR CONFORT Multi-Purpose Steam Cleaner User Manual](#)

## Ariete 4145

# Ariete 4145 XVAPOR CONFORT Multi-Purpose Steam Cleaner

## USER MANUAL

### Introduction

---

Thank you for choosing the Ariete 4145 XVAPOR CONFORT Multi-Purpose Steam Cleaner. This appliance is designed to provide deep and chemical-free cleaning for various surfaces in your home, effectively eliminating 99.9% of germs and bacteria using only steam. Please read this manual carefully before using the appliance to ensure safe and optimal performance. Keep this manual for future reference.



Figure 1: Ariete 4145 XVPOR CONFORT Steam Cleaner main unit.

This image shows the main unit of the Ariete 4145 XVPOR CONFORT steam cleaner, featuring its compact design with a handle, hose, and wheels for easy maneuverability. The unit is white and dark grey with light blue accents.

## Safety Information

---

Always observe the following basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury:

- Read all instructions before use.
- Do not leave the appliance unattended when plugged in.
- Do not use the appliance if the cord or plug is damaged.
- Keep children and pets away from the appliance during operation.
- Do not direct steam at people, animals, or electrical appliances.
- Always unplug the appliance before filling with water or cleaning.
- Use only clean tap water. Do not add detergents, perfumes, or other chemicals to the water tank.
- Allow the appliance to cool completely before storing.

## Product Overview and Features

---

The Ariete XVAPOR CONFORT is designed for efficient and versatile steam cleaning. Key features include:

- **1500W Power:** Ensures quick heating and powerful steam output.
- **1.2L Boiler Capacity:** Provides extended cleaning time.
- **5 BAR Pressure:** Delivers strong steam for effective dirt removal.
- **Steam Ready Light:** Indicates when the appliance is ready for use.
- **45 Minutes Autonomy:** Allows for continuous cleaning sessions.
- **Stainless Steel Boiler:** Durable and long-lasting.
- **Safety Cap:** Prevents opening while under pressure.
- **On-Off Button:** For easy control.



Figure 2: Key features of the Ariete 4145 XVAPOR CONFORT.

This image highlights the main specifications of the steam cleaner, including its 1500W power, 1.2L boiler capacity, steam ready light, 5 BAR pressure, 6m cable length, safety cap, on-off button, 45 minutes autonomy, and stainless steel boiler.

### Included Components:

The Ariete 4145 XVAPOR CONFORT comes with various accessories to tackle different cleaning tasks:

- Main Steam Cleaner Unit
- Flexible Hose with Steam Gun
- Floor Brush

- Extension Tubes
- Round Brush
- 90° Nozzle
- Glass/Window Cleaning Nozzle
- Fabric Accessory with Cloth
- Funnel and Measuring Cup

## Setup

---

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Filling the Water Tank:**
  - Ensure the appliance is unplugged and cool.
  - Unscrew the safety cap counter-clockwise.
  - Using the provided measuring cup and funnel, fill the boiler with up to 1.2 liters of clean tap water. Do not overfill.
  - Securely screw the safety cap back on clockwise until tight.
3. **Attaching Accessories:**
  - Connect the flexible hose to the main unit by aligning the connectors and twisting until it locks into place.
  - Attach the desired cleaning accessory (e.g., round brush, 90° nozzle, floor brush with extension tubes) to the steam gun or extension tube by pushing and twisting until secure.
4. **Power Connection:** Plug the power cord into a suitable grounded electrical outlet (230 Volts).

## Operating Instructions

---

1. **Power On:** Press the On/Off button. The steam ready indicator light will illuminate, signaling that the appliance is heating up.
2. **Heating Time:** Allow approximately 8-10 minutes for the water to heat and steam to build pressure. The steam ready light will turn off or change color when the appliance is ready for use.
3. **Steam Release:** Press the steam trigger on the steam gun to release steam. For continuous steam, engage the lock on the trigger.
4. **Cleaning Surfaces:**
  - **Round Brush for Dirty Surfaces:** Ideal for scrubbing stubborn dirt on tiles, grout, and other hard surfaces.



## Round brush for dirty surfaces

*Figure 3: Using the round brush on tiled surfaces.*

This image shows a hand holding the steam gun with the round brush attachment, directing steam onto a tiled wall to clean dirty surfaces.

- **90° Nozzle for Hard-to-Reach Areas:** Perfect for corners, crevices, and fixtures like sinks and faucets.



## 90° nozzle for hard-to-reach areas

*Figure 4: Cleaning a sink with the 90° nozzle.*

This image illustrates the use of the 90-degree nozzle attachment to direct steam into the tight corners and crevices of a stainless steel kitchen sink, demonstrating its effectiveness for hard-to-reach areas.

- **Glass and Window Cleaning Nozzle:** For streak-free cleaning of windows, mirrors, and other glass surfaces.



## Glass and window cleaning Nozzle for deep cleaning accessory

*Figure 5: Using the glass and window cleaning nozzle.*

This image shows a hand holding the steam gun with the glass and window cleaning nozzle attached, applying steam to a window for deep cleaning.

- **Fabric Accessory:** Use with the cloth cover for refreshing and sanitizing upholstery, curtains, and garments.



## Compact and Powerful

*Figure 6: Cleaning a sofa with the fabric accessory.*

This image depicts the fabric accessory being used to steam clean a blue upholstered sofa, demonstrating its utility for refreshing and sanitizing soft furnishings.

- **Floor Brush:** Attach extension tubes for cleaning floors. Move the brush slowly over the surface to allow steam to penetrate.
- 5. **Refilling (if needed):** If steam output decreases significantly or stops, the water tank may be empty. Unplug the unit, allow it to cool for a few minutes, then carefully unscrew the safety cap and refill as per setup instructions.
- 6. **Power Off:** When finished, release the steam trigger, press the On/Off button to turn off the unit, and unplug it from the electrical outlet.

## Maintenance

---

Regular maintenance ensures the longevity and optimal performance of your steam cleaner.

- **Cleaning the Unit:** After each use, ensure the unit is unplugged and cool. Wipe the exterior with a damp cloth.
- **Cleaning Accessories:** Wash removable accessories (brushes, nozzles, cloths) with water and mild detergent. Allow them to dry completely before storing.
- **Descaling:** Depending on water hardness in your area, mineral deposits may build up in the boiler. Descale the unit

periodically (e.g., every 3-6 months) using a descaling solution specifically designed for steam cleaners, following the product's instructions. Alternatively, a solution of white vinegar and water can be used (consult manufacturer guidelines for specific ratios and procedures).

- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the water tank is empty before storage.

## Troubleshooting

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty. Unit not heated sufficiently. Mineral buildup in boiler.	Refill water tank. Wait for steam ready light to indicate readiness. Descal the unit.
Water leaking from nozzle.	Appliance not fully heated. Condensation in hose/nozzle.	Allow more time for heating. Direct steam into a bucket until only steam comes out.
Appliance not turning on.	Not plugged in. Power outlet issue.	Ensure power cord is securely plugged in. Check power outlet with another appliance.
Safety cap difficult to open.	Unit is still under pressure or hot.	Allow the unit to cool down completely and release any residual pressure by pressing the steam trigger until no more steam comes out.

## Specifications

Attribute	Value
Brand	Ariete
Model Number	4145
Color	White
Product Dimensions (L x W x H)	20 x 14 x 69 cm
Weight	5.7 Kilograms
Boiler Capacity	1.2 Liters
Power	1500 Watts
Voltage	230 Volts
Material	Multi-layer (Stainless Steel Boiler)
Special Features	Steam ready indicator light, On/Off switch

Attribute	Value
Recommended Surface	Carpet, Floor

## Warranty and Support

---

For warranty information, please refer to the warranty card included with your product or contact Ariete customer service. Keep your proof of purchase for warranty claims.

If you encounter any issues not covered in the troubleshooting section, or require further assistance, please contact Ariete customer support. Contact details can typically be found on the manufacturer's website or on the product packaging.

**Online Resources:** For additional tips, FAQs, and product registration, visit the official Ariete website.