

[Manuals.plus](#) /

› [RCA](#) /

› RCA Mini Retro 6 Can Beverage Refrigerator User Manual

RCA RMIS129-BLACK

RCA Mini Retro 6 Can Beverage Refrigerator User Manual

Model: RMIS129-BLACK

PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient operation of your RCA Mini Retro 6 Can Beverage Refrigerator. Please read it thoroughly before use and retain it for future reference.

The RCA Mini Retro 6 Can Beverage Refrigerator is a compact and portable cooling unit designed to hold up to six 12 oz cans or 4 liters of beverages. It features a classic retro design and is suitable for various personal spaces.

Key Features

- Capacity: Holds 6 x 12 oz Cans or 4 Liters
- Color: Black
- Material: Durable Plastic Construction
- Compact and Portable Design



Image: Front view of the RCA Mini Retro Refrigerator, showcasing its compact size and retro aesthetic.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before operating this appliance.

- Ensure the power cord is not pinched or damaged.
- Do not operate the refrigerator if it has been damaged in any way.
- Keep ventilation openings clear of obstruction.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction

concerning use of the appliance by a person responsible for their safety.

- Supervise children to ensure they do not play with the appliance.
- For indoor use only.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not place the refrigerator near heat sources or in direct sunlight.
- Unplug the refrigerator before cleaning or performing any maintenance.

WHAT'S IN THE BOX

Your package should contain the following items:

- RCA Mini Retro 6 Can Beverage Refrigerator
- Removable Shelf
- AC Charging Cord (for home use)
- DC Charging Cord (for car use)
- Owner's Manual (this document)



Image: Back view of the RCA Mini Retro Refrigerator, highlighting the power input ports (AC and DC), the cold/off/hot switch, and the two included charging cords (one for standard wall outlets, one for car cigarette lighters).

SETUP

1. **Unpacking:** Carefully remove the refrigerator and all accessories from the packaging. Inspect for any damage.
2. **Placement:** Place the refrigerator on a flat, stable surface. Ensure there is adequate ventilation around the unit (at least 4 inches of space on all sides). Do not block the ventilation openings.
3. **Power Connection:**
 - **For Home Use (AC 120V):** Connect the AC charging cord to the AC input port on the back of the refrigerator. Plug the other end into a standard 120V wall outlet.
 - **For Car Use (DC 12V):** Connect the DC charging cord to the DC input port on the back of the refrigerator. Plug the other end into your vehicle's 12V cigarette lighter socket.
4. **Initial Cleaning:** Before first use, wipe the interior and exterior of the refrigerator with a damp cloth.
5. **Shelf Installation:** The removable shelf can be placed at different heights to accommodate various items. Insert the shelf into the desired grooves inside the refrigerator.



Image: The interior of the refrigerator with the door open, displaying the removable shelf and the internal cooling elements.

OPERATING INSTRUCTIONS

1. **Power On:** Once connected to a power source, locate the switch on the back of the unit.

2. **Select Mode:**

- For cooling, slide the switch to the "COLD" position. The green indicator light will illuminate.
- For warming (if applicable, though this model is primarily for cooling), slide the switch to the "HOT" position. The red indicator light will illuminate.
- To turn off the unit, slide the switch to the "OFF" position.

3. **Loading Contents:** Open the door using the handle. Place your beverages or other items inside. The refrigerator can hold up to six standard 12 oz cans.



Image: The RCA Mini Retro Refrigerator with its door open, revealing six beverage cans arranged on the internal shelf.

4. **Closing the Door:** Ensure the door is securely latched to maintain optimal temperature.
5. **Temperature:** This refrigerator is designed to cool items to approximately 32°F (18°C) below ambient temperature. It is not intended to freeze items.
-

MAINTENANCE AND CARE

Regular cleaning and proper care will ensure the longevity and optimal performance of your refrigerator.

Cleaning

- **Disconnect Power:** Always unplug the unit from the power source before cleaning.
- **Interior:** Wipe the interior with a soft cloth dampened with mild soap and water. Do not use abrasive cleaners or solvents.
- **Exterior:** Clean the exterior with a soft, damp cloth.
- **Drying:** Dry all surfaces thoroughly before plugging the unit back in.

Storage

- If storing the refrigerator for an extended period, ensure it is clean and dry.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Refrigerator not cooling/heating.	Not plugged in; Power switch in "OFF" position; Ventilation blocked.	Ensure unit is properly plugged in; Slide switch to "COLD" or "HOT"; Clear any obstructions from vents.
Unit is noisy.	Fan obstruction; Unit not on a stable surface.	Check for debris near the fan; Place unit on a flat, stable surface.
Condensation inside.	Door not closed properly; High humidity.	Ensure door is securely latched; This is normal in high humidity environments, wipe dry as needed.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand Name	RCA
Model Info	RMIS129-BLACK
Item Weight	0.75 Pounds (12 ounces)
Product Dimensions	11"D x 15"W x 14.5"H
Country of Origin	China
Capacity	0.15 Cubic Feet (4 Liters)

Feature	Detail
Annual Energy Consumption	200 Kilowatt Hours Per Year
Installation Type	Countertop
Form Factor	Compact
Color	Black
Voltage	120 Volts
Defrost System	Automatic
Door Hinges	Right
Material Type	Plastic
Included Components	Shelf, Charging Cords, Owners Manual

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official RCA website or the contact information provided in your original purchase documentation.

A digital version of this user manual can be found at: [RCA Mini Retro Refrigerator User Manual PDF](#)

© 2024 RCA. All rights reserved.
Model: RMIS129-BLACK

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01MRUXFJT>

More documents and user manuals: <https://manuals.plus/>