

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Feiss](#) /

› [Feiss Lighting-Angelo-Chandelier 6 Light Steel in Rustic Style-30.5 Inch Wide by 29.5 Inch High 6-Light User Manual](#)

Feiss F3134/6DWK/SGM

Feiss Angelo 6-Light Chandelier User Manual

Model: F3134/6DWK/SGM | Brand: Feiss

1. INTRODUCTION

This user manual provides detailed instructions for the safe installation, operation, and maintenance of your Feiss Angelo 6-Light Chandelier. Designed with a unique blend of rustic and industrial styles, featuring a Distressed Weathered Oak finish and Slate Grey Metal accents, this fixture is intended for indoor use in dining rooms, living rooms, or lobbies. Please read this manual thoroughly before beginning installation to ensure proper setup and to maximize the lifespan of your product.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing and operating electrical fixtures to reduce the risk of fire, electric shock, and personal injury.

- **WARNING:** Disconnect power at the circuit breaker or fuse box before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- This fixture is designed for 120 Volts AC. Ensure your power supply matches this requirement.
- Do not exceed the maximum wattage of 60 watts per bulb. Use 6 A19 Medium base incandescent bulbs (not included).
- This fixture is heavy (approximately 23 pounds). It is recommended that two people assist with the installation to ensure safety and proper mounting.
- Ensure the mounting surface can support the weight of the fixture.
- Please check your local laws and building codes before purchasing and installing this product.

3. PACKAGE CONTENTS

Carefully unpack your chandelier and identify all components. Keep all packaging materials until you are certain all parts are present and in good condition. If any parts are missing or damaged, do not attempt to assemble or install the fixture.

Typical components include:

- Chandelier Frame Assembly
- Glass Shades (6 pieces)
- Mounting Plate / Crossbar
- Mounting Screws and Wire Nuts

- Chain and Canopy
- Instruction Manual



Figure 3.1: Overview of the Feiss Angelo 6-Light Chandelier.

4. SETUP AND INSTALLATION

Before installation, ensure the power is turned off at the circuit breaker. It is highly recommended to have a second person assist with the installation due to the fixture's weight and size.

4.1 Tools Required

- Phillips Head Screwdriver
- Flathead Screwdriver
- Wire Strippers

- Pliers
- Electrical Tape
- Ladder

4.2 Mounting Instructions

1. Turn off the main power supply at the circuit breaker.
2. Attach the mounting plate/crossbar to the junction box in the ceiling using the provided screws. Ensure it is securely fastened and can support the fixture's weight.
3. Determine the desired hanging height for the chandelier. Adjust the chain length by removing links as necessary.
4. Thread the fixture's electrical wires through the chain and canopy.
5. Carefully lift the chandelier and attach the chain to the mounting plate.

4.3 Wiring Instructions

1. Connect the fixture's black wire to the house's black (hot) wire using a wire nut.
2. Connect the fixture's white wire to the house's white (neutral) wire using a wire nut.
3. Connect the fixture's ground wire (bare copper or green) to the house's ground wire and the mounting plate's ground screw.
4. Carefully tuck all wires into the junction box.
5. Slide the canopy up to the ceiling and secure it with the provided screws or collar ring.

4.4 Bulb and Shade Installation

1. Insert six (6) A19 Medium base incandescent bulbs (not included) into the sockets. Do not exceed 60 watts per bulb.
2. Carefully place each glass shade over its respective bulb socket. Ensure they are seated securely.



Figure 4.1: Feiss Angelo Chandelier installed in a room setting.

5. OPERATION

Once installation is complete and all connections are secure, restore power at the circuit breaker. The chandelier can be operated using a standard wall switch. This fixture is dimmable, allowing you to adjust the light intensity with a compatible dimmer switch (sold separately).

6. MAINTENANCE AND CARE

Regular cleaning and proper care will help maintain the appearance and functionality of your chandelier.

6.1 Cleaning

- Always turn off the power and allow the fixture to cool before cleaning.
- For the metal frame, wipe with a soft, dry cloth. Do not use abrasive cleaners or polishes as they may damage the finish.
- For the glass shades, remove them carefully and wash with mild soap and water. Rinse thoroughly and dry completely before reattaching.

6.2 Bulb Replacement

- Turn off the power to the fixture and allow bulbs to cool completely.
- Unscrew the old bulb counter-clockwise.
- Screw in a new A19 Medium base bulb, ensuring it does not exceed 60 watts.

7. TROUBLESHOOTING

If you experience issues with your chandelier, refer to the table below for common problems and solutions.

| Problem | Possible Cause | Solution |
|-------------------------|--|---|
| Light does not turn on. | No power to the fixture. | Check circuit breaker or fuse. Ensure wall switch is ON. |
| | Loose or incorrect wiring. | Turn off power. Check all wiring connections. Consult an electrician if unsure. |
| | Bulb is faulty or not screwed in properly. | Replace bulb or ensure it is screwed in tightly. |
| Light flickers. | Loose bulb or wiring. | Tighten bulbs. Check wiring connections. |
| | Incompatible dimmer switch. | Ensure dimmer switch is compatible with incandescent bulbs. |

8. SPECIFICATIONS

| Attribute | Detail |
|------------------------|---|
| Brand | Feiss |
| Model Number | F3134/6DWK/SGM |
| Dimensions (L x W x H) | 30.5" x 30.5" x 29.5" |
| Item Weight | 23 Pounds |
| Material | Steel (frame), Glass (shades) |
| Finish | Distressed Weathered Oak / Slate Grey Metal |
| Style | Rustic, Classic |

| Attribute | Detail |
|-------------------------|--------------------------------------|
| Light Source Type | A19 Medium Base Incandescent |
| Number of Light Sources | 6 |
| Voltage | 120 Volts |
| Max Wattage per Bulb | 60 Watts |
| Dimmable | Yes (with compatible dimmer switch) |
| Indoor/Outdoor Usage | Indoor |
| Assembly Required | No (minor assembly for installation) |

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This Feiss Angelo 6-Light Chandelier comes with a 1-year manufacturer's warranty. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, please refer to the documentation included with your product or contact Feiss customer support.

9.2 Customer Support

For technical assistance, missing parts, or warranty inquiries, please contact Feiss U.S.-Based Customer Support. Contact information can typically be found on the manufacturer's website or on the product packaging.

For a detailed PDF version of this manual, please visit:

<https://manuals.plus/m/35118572d7197dc81e060b32a158b65f71ad7aa5bf632fc9b179e073f013e2b7>