

[Manuals.plus](#) /

› [Energizer](#) /

› Energizer LED Tap Light Model 37107 User Manual

Energizer 37107

Energizer LED Tap Light (Model 37107) User Manual

Battery Operated Stick-On Lights

1. INTRODUCTION

Thank you for choosing the Energizer LED Tap Light. This manual provides essential information for the safe and effective use of your new battery-operated, stick-on lights. These versatile lights are designed for convenient illumination in various indoor locations such as cabinets, closets, pantries, and workstations.

Each light features a simple tap ON/OFF operation and provides soft white LED illumination. The compact design allows for easy installation without complex wiring.



Image 1.1: Energizer LED Tap Light (Model 37107) product packaging and two lights.

2. SETUP AND INSTALLATION

2.1 Battery Installation


1. Gently twist the back cover of the tap light counter-clockwise to open the battery compartment.
2. Insert three (3) AAA batteries (not included) into the compartment, ensuring correct polarity (+/-) as indicated inside.
3. Replace the back cover by aligning the tabs and twisting clockwise until securely closed.

2.2 Mounting Options

The Energizer LED Tap Light offers flexible mounting options:

- **Double-Sided Tape:** For quick and easy installation on smooth, clean surfaces. Peel the backing from the included double-sided tape and firmly press the light onto the desired location.

- **Screws:** For a more permanent fixture (screws not included). Use the screw holes on the back cover as a template to mark and pre-drill holes if necessary. Secure the light with appropriate screws for your surface.



MOUNTING OPTIONS



DOUBLE-SIDED
TAPE



SCREWS
(not included)

Image 2.1: Mounting options for the Energizer LED Tap Light.

3. OPERATING INSTRUCTIONS

To operate the Energizer LED Tap Light, simply press the center of the light lens. The light will turn ON. Press the center of the light lens again to turn the light OFF.



Image 3.1: Activating the light with a simple press.



Image 3.2: The light provides 20 lumens of bright white LED illumination.

4. MAINTENANCE

4.1 Battery Replacement

When the light begins to dim or fails to turn on, it is time to replace the batteries. Follow the steps in Section 2.1 to replace the three (3) AAA batteries. Always replace all three batteries at the same time with new ones for optimal performance.

4.2 Cleaning

To clean the light, wipe it with a soft, dry cloth. Do not use abrasive cleaners or immerse the light in water, as it is not water-resistant.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn ON.	Batteries are depleted or incorrectly installed.	Replace batteries with new AAA batteries, ensuring correct polarity.
Light is dim or flickers.	Batteries are low.	Replace batteries with new AAA batteries.
Light turns on inconsistently.	Insufficient pressure on the lens or internal connection issue.	Ensure a firm, direct tap on the center of the light lens. If the issue persists after battery replacement, contact customer support.
Light does not stick to surface.	Surface is dirty, uneven, or tape is worn.	Clean the surface thoroughly before applying tape. Use new double-sided tape or consider screw mounting for a more secure attachment.

6. SPECIFICATIONS

- **Model Number:** 37107
- **Power Source:** 3 x AAA Batteries (not included)
- **Light Source:** LED
- **Voltage:** 4.5 Volts
- **Material:** Plastic
- **Color:** Silver
- **Switch Type:** Push Button (Tap ON/OFF)
- **Dimensions (approximate):** 2.3" (Width) x 2.3" (Height) x 1.18" (Depth)
- **Item Weight:** 2.88 ounces (per light, without batteries)
- **Included Components:** 2 Tap LED lights
- **Indoor/Outdoor Usage:** Indoor use only
- **Water Resistance Level:** Not Water Resistant
- **UPC:** 030878371070



Image 6.1: Dimensions of the Energizer LED Tap Light.

7. WARRANTY INFORMATION

This Energizer LED Tap Light (Model 37107) is covered by a **90-day warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accident, modification, or unauthorized repair.

Please retain your proof of purchase for warranty claims.

8. CUSTOMER SUPPORT

For further assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact Energizer customer support. Refer to the product packaging or the official Energizer website for the most current contact information.

Manufacturer: Jasco Products Company, LLC

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question