

## **PowerLocus P1**

# **PowerLocus Wireless Bluetooth Over-Ear Stereo Foldable Headphones User Manual**

**MODEL: P1**

## **Introduction**

---

Thank you for choosing PowerLocus P1 Wireless Bluetooth Over-Ear Stereo Foldable Headphones. These headphones are designed to provide a superior audio experience with comfort and versatility. They feature Hi-Fi stereo sound, deep bass, and dynamic power, ensuring excellent audio quality at all volume levels. The P1 headphones are foldable for portability and come with soft protein foam earmuffs for extended comfort. They offer multiple connectivity options including Bluetooth, 3.5mm AUX, FM radio, and Micro SD/TF card support.



Image: PowerLocus P1 Wireless Bluetooth Over-Ear Stereo Foldable Headphones in black, accompanied by its protective carrying case.

## What's Included

Your PowerLocus P1 headphone package includes the following items:

- 1x PowerLocus P1 Wireless Headphones
- 1x 3.5mm Audio Cable
- 1x USB Charging Cable
- 1x Elegant Hard Shell Carry Case

# OUR PACKAGE INCLUDES:



**1x PowerLocus P1**  
Wireless Headphones



**3.5mm**  
**Audio Cable**



**USB-C**  
**Charging Cable**



**Elegant Hard Shell**  
**Carry Case**

Image: A visual representation of all items included in the PowerLocus P1 headphone package.

## Setup

### Charging the Headphones

Before first use, fully charge your PowerLocus P1 headphones. Connect the provided USB charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer USB port, wall adapter). The charging time is approximately 2.5 hours. A full charge provides up to 15 hours of battery life.

### Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "PowerLocus P1" from the list of found devices.
5. Once connected, the LED indicator will show a steady blue light.

The headphones support Bluetooth 5.0 for a stable connection up to 33 feet (10 meters). They are universally compatible with iOS, Android, and Windows devices, including iPhones, Samsung phones, iPads, Amazon Fire devices, and more.

# Fast & Stable Connection

## Bluetooth 5.3

Image: The PowerLocus P1 headphones feature Bluetooth 5.3 for fast and stable wireless connectivity.

### Wired Connection (AUX Mode)

For a wired connection, use the included 3.5mm audio cable. Plug one end into the AUX port on the headphones and the other end into the 3.5mm audio jack of your device. This mode is useful when the battery is low or for devices without Bluetooth capability.

## Operating Instructions

### Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator lights up.
- **Power Off:** Press and hold the Power button for approximately 3 seconds until the LED indicator turns off.

## Music Playback Controls

- **Play/Pause:** Press the Multi-function button (often marked with a play/pause icon).
- **Volume Up:** Press the Volume Up (+) button.
- **Volume Down:** Press the Volume Down (-) button.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.

## Call Handling

The headphones feature a built-in microphone for hands-free calling.

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

## FM Radio Mode

To switch to FM Radio mode, press the 'M' (Mode) button. Use the Volume Up/Down buttons to scan for stations. Short press for auto-scan, long press to switch between saved stations.

## Micro SD/TF Card Mode

Insert a Micro SD/TF card (up to 32GB) with your audio files into the designated slot. The headphones will automatically switch to Micro SD mode and begin playing music from the card. Use the playback controls as described above.



Image: The PowerLocus P1 headphones support multiple modes including Bluetooth, wired, Micro SD, and FM radio.

### Multi-Point Connection

The PowerLocus P1 headphones can connect to two Bluetooth devices simultaneously. After pairing with the first device, disable Bluetooth on that device. Pair the headphones with the second device. Once the second device is connected, re-enable Bluetooth on the first device. The headphones should now be connected to both devices, allowing seamless switching between audio sources.

# Multi Point Connection



Universally Compatible



Image: The headphones support multi-point connection, allowing two devices to be paired simultaneously.

## Maintenance

- Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- Storage:** When not in use, store the headphones in the provided hard shell carry case to protect them from dust, scratches, and impacts. The foldable design makes them compact for storage and travel.
- Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not used for extended periods.

# PORTABLE DESIGN

Foldable Design

+ Premium Carry Case



Image: The foldable design and included premium carry case ensure portability and protection for your headphones.

## Troubleshooting

Problem	Possible Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair via Bluetooth.	Ensure headphones are in pairing mode (flashing blue/red LED). Make sure Bluetooth is enabled on your device. Move headphones closer to your device. Forget "PowerLocus P1" from your device's Bluetooth list and try pairing again. Restart both the headphones and your device.

Problem	Possible Solution
No sound or low volume.	Adjust volume on both headphones and connected device. Ensure headphones are properly connected (Bluetooth or AUX cable). If using AUX, ensure the cable is fully inserted.
Sound lagging or disconnecting (especially with PC).	Ensure no strong interference sources are nearby. Update Bluetooth drivers on your PC. Try connecting to a different device to isolate the issue. Ensure the headphones are not too far from the source device.
Ear cushions peeling/disintegrating.	This can occur with extended use, especially if exposed to sweat or moisture. While not a functional issue, replacement ear cushions may be available from the manufacturer or third-party sellers. Avoid sleeping with headphones on to minimize wear.

## Specifications

Model Name	P1
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm Jack)
Wireless Communication Technology	Bluetooth 5.0
Bluetooth Range	33 Feet (10 meters)
Ear Placement	Over Ear
Audio Driver Size	40 Millimeters
Frequency Response	110 HZ – 20,000 HZ
Impedance	32 Ohm
Noise Control	Sound Isolation
Battery Life	15 Hours
Charging Time	2.5 Hours
Item Weight	5.1 ounces (0.32 Pounds)
Product Dimensions	5.9 x 6.5 x 3.6 inches
Material	Faux Leather (earmuffs), Protective Fabric (carry case)
Compatible Devices	Cellphones, Television, Tablets, Laptops, Smartphones, iOS, Android, TV, Amazon Fire TV, PS4, Xbox, Nintendo, PC

## Warranty and Support

PowerLocus provides a **24-Month Warranty** for your P1 Wireless Bluetooth Headphones. Additionally, you are covered by a **45-Day Money Back Guarantee**. If you are not satisfied with the quality, you may return the product for a full refund. For any questions, technical assistance, or warranty claims, please contact PowerLocus customer support. Refer to the official PowerLocus website or your purchase documentation for contact details.

A digital version of the user manual is also available for download: [PowerLocus P1 User Manual \(PDF\)](#).

