Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- VIAIR /
- > VIAIR 84P Portable Tire Inflator Instruction Manual

VIAIR 84P

VIAIR 84P Portable Tire Inflator Instruction Manual

Model: 84P | Brand: VIAIR

1. Introduction

The VIAIR 84P Portable Tire Inflator is a compact and efficient 12-volt air compressor designed for inflating vehicle tires and other inflatables. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new tire inflator.



Figure 1: VIAIR 84P Portable Tire Inflator

2. Product Overview & Features

The VIAIR 84P is engineered for convenience and reliability, offering quick inflation for various applications. Its compact design and included carry bag make it an ideal tool for on-the-go tire maintenance.

- 100 PSI Pressure Gauge: Integrated analog gauge for monitoring tire pressure.
- LED Work Light / Power Indicator: Provides illumination for nighttime use and indicates power status.
- Press-On Chuck: For quick and secure connection to tire valve stems.
- Accessory Power Plug: Connects to a standard 12V auxiliary outlet (cigarette lighter).
- Deluxe Carry Bag: Durable canvas bag for convenient storage and transport.
- **Versatile Inflation:** Suitable for car, truck, SUV, motorcycle, and bicycle tires, as well as various inflatables using included accessories.



Figure 2: Key features of the VIAIR 84P Air Compressor including 1-minute inflation capability and 12V cigarette lighter power.




Figure 3: Detailed features including 60 PSI max pressure, 10 ft power cord, 3 ft air hose, LED light, and built-in pressure gauge.

3. SAFETY INFORMATION

WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

- Always operate the compressor in a well-ventilated area.
- The compressor unit can become very hot during operation. Avoid touching hot surfaces.
- Ensure the vehicle engine is running when using the compressor to prevent draining the vehicle's battery.
- Do not leave the compressor unattended while in use.
- · Keep out of reach of children.

4. SETUP

1. Unpack the Inflator: Remove the VIAIR 84P from its deluxe carry bag.

- 2. **Connect to Power:** Insert the 12V accessory power plug into your vehicle's cigarette lighter outlet. Ensure the vehicle's engine is running to provide adequate power and prevent battery drain.
- 3. **Prepare Air Hose:** Uncoil the 3-foot air hose. The press-on chuck is designed for quick attachment to standard tire valve stems.
- 4. **Attach Accessories (if needed):** For inflating items other than standard tires (e.g., sports balls, pool floats), select the appropriate accessory tip and attach it to the press-on chuck.



Figure 4: Connecting the 12V accessory power plug to the vehicle's cigarette lighter outlet.



Figure 5: Included inflation accessories for various items.

5. OPERATING INSTRUCTIONS

Follow these steps to inflate your tires or other items:

- 1. Plug into Cigarette Lighter: Insert the power plug into your vehicle's 12V outlet.
- 2. **Start Engine:** Start the engine of your vehicle.
- 3. **Connect Air Hose:** Securely attach the press-on chuck to the tire's valve stem.
- 4. **Power On:** Flip the ON/OFF switch on the compressor to the 'ON' position. The LED work light will illuminate.
- 5. **Monitor Pressure:** Observe the analog pressure gauge on the unit. Inflate to the desired pressure as recommended by your vehicle manufacturer.
- 6. **Power Off & Disconnect:** Once the desired pressure is reached, flip the ON/OFF switch to 'OFF'. Disconnect the chuck from the valve stem.

4 Easy Steps To Inflate Your Tires




Figure 6: Visual guide for the 4 easy steps to inflate your tires.



Figure 7: Close-up of the integrated analog pressure gauge.



Figure 8: The LED work light and ON/OFF switch for easy operation.

Video 1: An instructional video demonstrating the use of the VIAIR 84P tire inflator.

6. MAINTENANCE

• Keep the compressor clean and free of dirt and debris.

- Store the inflator in its deluxe carry bag in a dry, cool place when not in use.
- Regularly inspect the power cord, air hose, and chuck for any signs of wear or damage. Replace components if necessary.
- Ensure the rubber feet are intact to minimize vibration during operation.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|------------------------------|---|---|
| Compressor does not turn on. | No power from 12V outlet; vehicle engine not running; blown fuse in power plug. | Ensure 12V outlet is functional and vehicle engine is running. Check and replace fuse in the power plug if necessary. |
| Slow inflation. | Low vehicle battery voltage; air leak in hose/chuck connection. | Ensure vehicle engine is running. Check all connections for tightness. |
| Inaccurate pressure reading. | Gauge malfunction; improper connection. | Ensure chuck is properly seated on valve stem. Use a separate, calibrated gauge to verify accuracy. |

8. SPECIFICATIONS

| Feature | Specification |
|----------------------------|----------------------------|
| Brand | VIAIR |
| Model Name | 84 |
| Voltage | 12 Volts |
| Power Source | 12V Auxiliary Outlet |
| Maximum Operating Pressure | 60 PSI |
| AC Adapter Current | 15 Amps |
| Air Flow Capacity | 1.26 Cubic Feet Per Minute |
| Motor Horsepower | 0.2 horsepower |
| Hose Length | 3 Feet |
| Item Weight | 4.3 Pounds |
| Product Dimensions | 9.1"L x 3.1"W x 5.6"H |
| Noise Level | 76 Decibels |
| Special Feature | LED Light |

9. WARRANTY AND SUPPORT

The VIAIR 84P Portable Tire Inflator comes with a Manufacturer Warranty. For warranty claims, technical support, or general inquiries, please contact VIAIR Corporation directly.

• Website: www.viaircorp.com

• Email: techsupport@viaircorp.com

• Phone: 1 (949) 585-0011

Related Documents - 84P



VIAIR 84P Portable Compressor User Manual

User manual for the VIAIR 84P Portable Compressor, Sport Compact Series. Includes operating instructions, safety warnings, features, specifications, and warranty information for this 12V DC air compressor.



VIAIR 450P-RV Automatic Portable Compressor: User Manual, Operation, and Specifications

Official user manual for the VIAIR 450P-RV Automatic Portable Compressor Kit (Part No. 45053). Covers safety, operation, troubleshooting, accessories, specifications, and warranty for this RV tire inflator.



VIAIR 84P Portable Compressor User Manual - Model 00084

User manual for the VIAIR 84P Portable Compressor (Part No. 00084). Includes operating instructions, safety guidelines, features, specifications, and warranty information for this 12V DC air compressor.





I is assessful to the part of the product of this product made and an extended the second of the product made and antended the second of this manual before the producting and analysis product. 5-WE THE SMALLE CONTURER ESTRICTION LINES MANUAL CONTURER ESTRICTION LINES MANUAL

VIAIR 450P-RV Automatic Portable Compressor User Manual

User manual for the VIAIR 450P-RV Automatic Portable Compressor (Extreme Series, Part No. 45053). Covers safety, operation, accessories, maintenance, troubleshooting, and specifications for this 12V portable air compressor.



VIAIR 400P-RV Automatic Portable Compressor User Manual & Specifications

Comprehensive user manual and specifications for the VIAIR 400P-RV Automatic Portable Compressor (Model 40047). Includes operating instructions, safety precautions, troubleshooting guide, and warranty information.



<u>VIAIR EVC85P Digital Portable Air Compressor User Manual - Safety, Operation, and Specs</u>

Comprehensive user manual for the VIAIR EVC85P Digital Portable Air Compressor. Includes detailed operating instructions, safety warnings, troubleshooting guide, product specifications, and limited warranty information.