

[Manuals.plus](#) /

- › [Christopher Knight Home](#) /
- › Christopher Knight Home Hermosa Acacia Wood Dining Set Instruction Manual

Christopher Knight Home 296620

Christopher Knight Home Hermosa Acacia Wood Dining Set


Model: 296620

Brand: Christopher Knight Home

PRODUCT OVERVIEW

This manual provides instructions for the Christopher Knight Home Hermosa Acacia Wood Dining Set. This 5-piece set includes a dining table and four armchairs, designed for outdoor use. The set features a teak finish and water-resistant fabric cushions.

Create a life you love



CHRISTOPHER KNIGHT®
HOME

Image: The Hermosa Acacia Wood Dining Set, showcasing the table and four chairs in an outdoor setting.

SAFETY INFORMATION

WARNING:

- Assembly may involve handling sharp objects. Always follow instructions carefully.
- This product is intended for outdoor use and should be cared for accordingly to prevent damage or mold growth.
- Keep away from heat sources and do not expose to excessive water.
- Always supervise children around this product to prevent injury from sharp edges or tip-over risks.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- One (1) Dining Table
- Four (4) Arm Chairs
- Four (4) Seat Cushions (Water Resistant Fabric)

- Assembly Hardware (Bolts, Washers, Allen Wrench)

ASSEMBLY INSTRUCTIONS

Assembly is required for this dining set. It is recommended to have two people for assembly. Please refer to the detailed instructions provided in the included Installation Manual (PDF) for step-by-step guidance.

Ensure all bolts are tightened securely but do not overtighten.

For detailed assembly steps, you may also refer to the official installation videos below:

Table Assembly Video

Video: Official assembly guide for the Hermosa Acacia Wood Square Table, demonstrating how to attach the legs to the tabletop using the provided hardware.

Chair Assembly Video

Video: Official assembly guide for the Outdoor Acacia Wood Arm Chairs, showing the process of securing chair components.

Key Dimensions for Assembly Planning



Image: Dining Chair Dimensions: 27.50" deep x 24.00" wide x 34.25" high. Seat Dimensions: 19.00" deep x 20.50" wide x 17.50" high. Arm Height: 26.25".



Image: Dining Table Dimensions: 31.50" deep x 31.50" wide x 30.00" high.

OPERATING INSTRUCTIONS

This dining set is designed for general outdoor dining and seating. Ensure the set is placed on a flat, stable surface to prevent wobbling. The chairs are designed for comfortable seating, and the table provides a stable surface for meals and activities.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your acacia wood dining set.

- **Cleaning:** Wipe with a dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Wood Protection:** As an outdoor wood product, regular maintenance is recommended. Applying a teak sealer (not oil) can protect the wood from weathering, fading, and rot, especially in humid or coastal environments. Apply sealer as soon as possible after assembly for best results.
- **Cushion Care:** The cushions are made from water-resistant fabric. Spot clean as needed. For prolonged life, store cushions indoors during inclement weather or when not in use.
- **Storage:** During off-seasons or extended periods of non-use, consider covering the furniture with a waterproof cover or storing it in a sheltered area to protect it from extreme weather conditions.

TROUBLESHOOTING

Missing or Damaged Parts

If you find any parts missing or damaged upon delivery, please contact Christopher Knight Home customer service immediately. Do not attempt to assemble the product with missing or damaged components.

Wobbly Table or Chairs

Ensure all bolts are fully tightened. If wobbling persists, check that the furniture is placed on a level surface. Adjust furniture placement as necessary.

SPECIFICATIONS

Feature	Detail
Brand	Christopher Knight Home
Model Number	296620
Set Name	Hermosa
Material	Acacia Wood
Finish	Teak Finish
Cushion Material	Water Resistant Fabric
Table Dimensions	31.50 inches (D) x 31.50 inches (W) x 30.00 inches (H)
Table Weight Capacity	300 lbs
Chair Dimensions	27.50 inches (D) x 24.00 inches (W) x 34.25 inches (H)
Chair Seat Dimensions	19.00 inches (D) x 20.50 inches (W) x 17.50 inches (H)
Chair Arm Height	26.25 inches
Chair Weight Capacity	400 lbs
Assembly Required	Yes
Included Components	One (1) Dining Table and Four (4) Dining Chairs

WARRANTY AND SUPPORT

This product is eligible for a 30-day return policy through Amazon. For specific warranty details or customer support inquiries, please refer to the documentation included with your purchase or contact Christopher Knight Home customer service directly. Many users have reported positive experiences with their responsive customer service.

Additional support documents:

- [User Manual \(PDF\)](#)
- [Installation Manual \(PDF\)](#)

