

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [hansgrohe](#) /

› [hansgrohe Talis S Modern 1-Handle Bathroom Sink Faucet Instruction Manual \(Model 72010001\)](#)

hansgrohe 72010001

hansgrohe Talis S Modern 1-Handle Bathroom Sink Faucet Instruction Manual

Model: 72010001

PRODUCT OVERVIEW

The hansgrohe Talis S Modern 1-Handle Bathroom Sink Faucet (Model 72010001) is designed for contemporary bathrooms, offering both aesthetic appeal and functional efficiency. This faucet features a single lever for water control and incorporates hansgrohe's ComfortZone, EcoRight, AirPower, and QuickClean technologies for enhanced user experience and water conservation.




Image: hansgrohe Talis S Modern 1-Handle Bathroom Sink Faucet in Chrome. This image displays the complete faucet unit, highlighting its sleek design and chrome finish.

Key features include:

- **EcoRight Technology:** Automatically restricts flow rate to a maximum of 1.2 GPM, conserving water and energy without compromising performance.
- **ComfortZone:** Provides ample space between the spout and the sink for comfortable use.
- **AirPower:** Enriches water with air, creating fuller, lighter, and softer droplets for a more pleasant experience.
- **QuickClean:** Allows for easy removal of limescale by simply wiping the silicone insert on the spout.
- **Durable Chrome Finish:** Ensures a lasting shine and easy maintenance.

SETUP AND INSTALLATION

Installation of the hansgrohe Talis S faucet requires careful attention to detail. It is strongly recommended that a licensed plumber performs the installation to ensure proper function and adherence to local plumbing codes.

Included Components:

- Single-lever bathroom faucet
- Connection hoses
- Shaft attachment
- Drain assembly (Pop-Up Drain)
- Assembly instructions (refer to the physical manual for detailed diagrams)

Installation Notes:

1. Ensure all necessary tools and materials are available before beginning installation.
2. Turn off the main water supply before disconnecting any existing fixtures.
3. This faucet is designed for a single-hole deck mount installation. Verify your sink or countertop has the appropriate hole configuration.
4. Connect the hot and cold water supply lines to the corresponding inlets on the faucet.
5. Install the drain assembly according to the provided instructions, ensuring a watertight seal.
6. After installation, slowly turn on the water supply and check for any leaks.

OPERATION

The hansgrohe Talis S faucet features a single lever for intuitive control of water flow and temperature.

Water Flow and Temperature Control:

- **Flow Control:** Lift the lever upwards to increase water flow. Push it downwards to decrease or stop the flow.
- **Temperature Control:** Move the lever to the left for hot water and to the right for cold water. Adjust the position between left and right to achieve the desired water temperature.

The integrated EcoRight technology ensures efficient water usage by limiting the maximum flow rate to 1.2 gallons per minute (GPM), contributing to water and energy savings.

AirPower technology mixes air into the water stream, resulting in a softer, more voluminous spray that feels pleasant on the skin and reduces splashing.

MAINTENANCE

Regular cleaning and maintenance will preserve the appearance and functionality of your hansgrohe Talis S faucet.

Cleaning Instructions:

- Use only mild soap and water or a non-abrasive liquid cleaner specifically designed for chrome finishes.
- Avoid abrasive cleaners, scouring pads, or cleaners containing alcohol, ammonia, bleach, or phosphoric acid, as these can damage the finish.
- After cleaning, rinse the faucet thoroughly with clean water and dry it with a soft cloth to prevent water spots.
- **QuickClean Feature:** To remove limescale from the aerator, gently rub the silicone nozzles on the spout. This dislodges mineral deposits, restoring optimal spray performance.

The durable chrome finish is designed for easy care and to maintain its shine over time with proper cleaning.

TROUBLESHOOTING

If you encounter issues with your hansgrohe Talis S faucet, consider the following common troubleshooting steps. For

complex problems, contact a licensed plumber or hansgrohe customer support.

Common Issues and Solutions:

- **Low Water Flow:**
 - Check if the shut-off valves under the sink are fully open.
 - Inspect the aerator for mineral buildup. Clean it using the QuickClean feature or by unscrewing and rinsing it.
 - Ensure supply lines are not kinked.
- **Leaking Faucet:**
 - Check all connections for tightness. Do not overtighten.
 - If leaking from the handle or spout, internal components may need inspection by a professional.
- **Inconsistent Water Temperature:**
 - Verify that both hot and cold water supplies are functioning correctly.
 - Ensure the water heater is set to an appropriate temperature.

SPECIFICATIONS

Detailed specifications for the hansgrohe Talis S Modern 1-Handle Bathroom Sink Faucet, Model 72010001.

Brand	hansgrohe
Model Name	Talis S
Part Number	72010001
Color	Chrome
Material	Brass
Mounting Type	Deck Mount
Installation Type	Single Hole
Number of Handles	1
Maximum Flow Rate	1.2 Gallons Per Minute (GPM)
Spout Height	4.9 Inches
Item Weight	4.14 Pounds
Product Dimensions	16.5"D x 10"W x 2.99"H
Recommended Uses	Bathroom

WARRANTY AND SUPPORT

Warranty Information:

Hansgrohe, Inc. warrants to the original consumer purchaser that hansgrohe products will be free from defects in material and workmanship for as long as the original consumer purchaser owns both the product and the home in which the product was originally installed. For commercial purchasers, the warranty period is one (1) year from the date of

purchase. The warranty period for products in Rubbed Bronze, Matte Black, and Matte White finishes is three (3) years from the date of purchase. This warranty is non-transferable.

This warranty does not cover hansgrohe products purchased from unauthorized sellers, unless otherwise prohibited by law. Authorized sellers can be found on hansgrohe branded websites. Additional warranty restrictions apply. Refer to the manufacturer's official website for complete warranty details.

Customer Support:

For further assistance, technical support, or warranty claims, please visit the official hansgrohe website or contact their customer service department. You can also visit the [hansgrohe Store on Amazon](#) for product information and resources.