Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SIMPLIHOME 3AXCHRP-03

SIMPLIHOME Harper 54" Wide Solid Wood 3-Drawer Console Table User Manual

Model: 3AXCHRP-03

Important Safety Information

This product can expose you to chemicals including formaldehyde, phthalates, and lead which are known to the State of California to cause cancer or birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov/furniture.

General Safety Precautions:

- Always assemble furniture on a soft, clean surface to prevent scratches.
- Ensure all parts are securely fastened before use. Periodically check and re-tighten all connections.
- Do not overload the table. The maximum weight recommendation is 150 pounds.
- Keep small parts and packaging materials away from children during assembly.
- Use the product on a level and stable surface to prevent tipping.

Product Overview

The SIMPLIHOME Harper Console Table is a mid-century modern piece designed to add elegance and practical storage to your home. Handcrafted from durable rubberwood with a rich walnut brown finish, it features clean lines, tapered legs, and three spacious drawers with integrated notched handles.



Image: The Harper Console Table in a living room, showcasing its design and functionality.

Key Features:

- **Room-Friendly Size:** Measures 16" D x 54" W x 31" H, ideal for various spaces.
- **Handcrafted Solid Wood:** Constructed from premium rubberwood with a durable NC lacquer finish.
- **Efficient Storage:** Three spacious drawers with smooth metal glides and notched pulls.
- **Mid-Century Modern Style:** Features streamlined edges and tapered solid wood legs.



Image: Detailed dimensions of the Harper Console Table.

Package Contents

This product requires full assembly. Please ensure all parts and hardware are present before beginning. Refer to the official Installation Manual (PDF) for a complete and detailed list of all components and hardware included in your package.

Assembly Instructions

This console table requires full assembly. For detailed, step-by-step instructions, please refer to the official Installation Manual (PDF) provided by SIMPLIHOME. It contains diagrams and specific guidance for each step of the assembly process.

Download Official Installation Manual (PDF)

General Assembly Tips:

- Clear a spacious, well-lit area for assembly.
- Lay out all components and hardware, checking against the parts list in the manual.
- Follow the manual's sequence carefully to ensure correct assembly.
- Do not overtighten screws; tighten until snug.
- Assembly is recommended for two people to ensure safety and ease.

Operating Instructions

This console table is designed for general indoor use in living rooms, hallways, entryways, or behind sofas. It provides a stable surface for decorative items and convenient storage.

Drawer Operation

The three drawers feature smooth metal glides for easy opening and closing. Use the integrated notched handles to access the drawer contents. Avoid forcing drawers if they feel stiff; check for obstructions or ensure the table is on a level surface.



Image: A drawer of the Harper Console Table partially open, showing its interior.

Maintenance and Care

To maintain the beauty and longevity of your SIMPLIHOME Harper Console Table:

- Wipe clean with a soft, dry cloth.
- Avoid using harsh chemicals, abrasive cleaners, or furniture polish containing silicone.
- Protect the surface from heat and moisture by using coasters or placemats.
- Avoid direct sunlight exposure to prevent fading and wood damage.
- Periodically check and tighten all hardware connections to ensure stability.
- If spills occur, wipe them immediately with a clean, dry cloth.

Troubleshooting

Drawers Not Sliding Smoothly

Check for any obstructions within the drawer glides or the drawer itself. Ensure the table is placed on a level surface, as unevenness can affect drawer alignment.

Table Wobbles

Verify that all leg connections and other hardware are securely tightened. Ensure the table is placed on a flat, even floor. If the floor is uneven, consider using furniture levelers under the legs.

Surface Scratches

For minor scratches, furniture repair markers or touch-up pens matching the walnut finish can be used. For deeper

damage, professional furniture repair may be required.

Specifications

Brand	SIMPLIHOME
Model Name	Harper 54W Console Table with 3 Drawers
Model Number	3AXCHRP-03
Product Dimensions	16"D x 54"W x 31"H
Item Weight	68.3 pounds
Maximum Weight Recommendation	150 pounds
Frame Material	Rubber Wood
Color	Walnut Brown
Number of Drawers	3
Assembly Required	Full Assembly Required

Official Product Video

Your browser does not support the video tag.

Video: This official manufacturer video showcases the SIMPLIHOME Harper collection, including the console table, end table, and coffee table, highlighting their design, features, and how they can complement various home decors.

Warranty Information

The SIMPLIHOME Harper Console Table is warranted to be free from defects in material and workmanship for a period of **one (1) year** from the date of purchase to the original owner. This warranty covers manufacturing defects under normal household use.

For warranty claims, please retain your proof of purchase and contact SIMPLIHOME customer support directly. The warranty does not cover damage due to misuse, abuse, improper assembly, or normal wear and tear.

Customer Support

For assistance with assembly, missing parts, product inquiries, or warranty claims, please visit the official SIMPLIHOME website or contact their customer service department.

You can also visit the SIMPLIHOME store on Amazon for more information and product offerings:

Visit the SIMPLIHOME Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MTYR3KZ

More documents and user manuals: **https://manuals.plus/**