

[Manuals.plus](#) /

› [SUNCROWN](#) /

› SUNCROWN 3 Piece Outdoor Rocking Bistro Set User Manual

SUNCROWN Outdoor 3-Piece Rocking Wicker

SUNCROWN 3 Piece Outdoor Rocking Bistro Set User Manual

Model: **Outdoor 3-Piece Rocking Wicker**

Brand: **SUNCROWN**

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your SUNCROWN 3 Piece Outdoor Rocking Bistro Set. Designed for comfort and durability, this set is perfect for enhancing your outdoor living space.

Please read this manual thoroughly before assembly and use to ensure safe and proper operation of your furniture set.



Image: The SUNCROWN 3 Piece Outdoor Rocking Bistro Set, featuring two black wicker rocking chairs with beige cushions and a matching glass-top coffee table.

2. SAFETY INFORMATION

- Ensure all parts are securely fastened before and during use. Regularly check and tighten all bolts and connections.
- Do not exceed the maximum load capacity of **250 pounds (approx. 113 kg)** per chair.
- Keep the furniture away from open flames and excessive heat sources.
- Avoid standing on the chairs or table.
- Place the furniture on a flat, stable surface to prevent tipping.
- Supervise children when they are near or using the furniture.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Two (2) Rocking Chairs (Wicker body with steel frame)
- One (1) Glass Coffee Table (Wicker body with steel frame and tempered glass top)
- Two (2) Seat Cushions (Beige polyester with foam core)
- Two (2) Back Cushions (Beige polyester with foam core)
- Assembly Hardware (Bolts, washers, Allen wrench - if applicable, though product states "no tools required" for assembly time, some basic hardware is usually included)

4. SETUP AND ASSEMBLY

The SUNCROWN 3 Piece Outdoor Rocking Bistro Set is designed for super easy assembly, typically taking only 20-25 minutes to complete. No additional tools are required beyond what is provided (if any).

Assembly Steps:

1. Carefully unpack all components and lay them out on a soft, clean surface to prevent scratching.
2. Assemble the frame of each rocking chair according to the included diagram. Ensure all connections are aligned before tightening.
3. Attach the armrests to the chair frames, ensuring they are securely fastened.
4. Assemble the coffee table frame and carefully place the tempered glass top into position.
5. Place the seat and back cushions onto the assembled chairs.
6. Once assembled, gently rock each chair to ensure stability and proper function.



Thickened Seat Cushion

Provide more comfortable rest experience.

High Quality Hand Woven Rattan

Beautiful and durable, waterproof design is easy to clean.



Image: A detailed diagram illustrating the dimensions of the rocking chair and coffee table, along with a visual breakdown of their components for assembly reference.

5. OPERATING INSTRUCTIONS

Your SUNCROWN rocking bistro set is designed for comfortable and relaxing outdoor use.

Rocking Function:

The rocking chairs feature adjustable screws at the bottom of the chair legs. These allow you to fine-tune the comfortable swing range, providing a smooth and enjoyable rocking experience. The integrated armrests and connected legs are designed to offer additional support and balance while rocking.



Image: A visual representation of the rocking chair's ergonomic armrests and the smooth rocking mechanism, emphasizing comfort and stability.

Coffee Table Use:

The glass coffee table provides a convenient surface for drinks, books, or small decorative items. The tempered glass top is durable and easy to clean.



Image: A detailed view of the coffee table, showcasing its durable construction with cross-braced frames and the strong, easy-to-clean tempered glass top.

6. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your SUNCROWN bistro set.

Cleaning Instructions:

- For general cleaning, wipe the wicker and steel frames with **adamp cloth**.
- For tougher stains, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- The cushion covers are **removable and washable**. Refer to the care label on the cushions for specific washing instructions.
- Clean the tempered glass table top with a glass cleaner and a soft cloth.

Storage:

To protect your furniture from harsh weather conditions and prolong its lifespan, it is recommended to store the set indoors or cover it with a weather-resistant cover during the winter months or prolonged periods of non-use.



Image: A detailed view of the chair's thickened seat cushion and the high-quality hand-woven rattan, highlighting their comfort and durability.

7. TROUBLESHOOTING

If you encounter any issues with your SUNCROWN 3 Piece Outdoor Rocking Bistro Set, please refer to the following common solutions:

- **Wobbly Chairs/Table:** Check all bolts and connections to ensure they are fully tightened. Ensure the furniture is placed on a level surface.
- **Difficulty Rocking:** Verify that the adjustable screws at the bottom of the chair legs are set correctly and

that there are no obstructions beneath the rocking base.

- **Cushion Discoloration/Wear:** Ensure cushions are stored away from direct prolonged sunlight and harsh weather when not in use. Follow washing instructions carefully.

For any issues not resolved by the above steps, or for further assistance, please contact SUNCROWN customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	SUNCROWN
Model Number	Outdoor 3-Piece Rocking Wicker
Chair Dimensions (L x W x H)	28.5 x 23 x 36 inches (approx. 72.4 x 58.4 x 91.4 cm)
Armchair Size (H x W x L)	32.4" x 24.9" x 28.2" (from image)
Table Dimensions (H x W x D)	19" x 18" x 18" (approx. 48.3 x 45.7 x 45.7 cm)
Item Weight	55.8 pounds (approx. 25.3 kg)
Load Capacity (per chair)	250 pounds (approx. 113 kg)
Material	Durable Rattan Wicker, Powder-Coated Solid Steel Frame, Tempered Glass (table top), Polyester (cushions)
Color	Black Wicker, Beige Cushions
Product Care	Wipe Clean, Wipe with Damp Cloth (cushion covers removable and washable)

9. WARRANTY AND CUSTOMER SUPPORT

SUNCROWN is dedicated to providing high-quality products and an unmatched customer experience. While specific warranty details are not provided in the product information, SUNCROWN prides itself on responsive customer service.

If you have any questions about your product, require assistance with assembly, or need to report any issues, please do not hesitate to contact SUNCROWN customer support via Amazon message. All inquiries are typically answered within 24 hours.

For more information about SUNCROWN products, you can visit the official SUNCROWN Store on Amazon:

[**Visit the SUNCROWN Store**](#)