Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TOKK TOK-00329

TOKK Smart Wearable Assistant Hands-Free Bluetooth Speaker Phone (TOK-00329) User Manual

Model: TOK-00329

1. Introduction

The TOKK Smart Wearable Assistant is a versatile, hands-free Bluetooth speaker phone designed for convenience and portability. It integrates a high-quality microphone and speaker, offering a solution for hands-free communication and audio playback.

1.1. Package Contents

Please verify that all items are present in your package:

- TOKK Smart Wearable Assistant (TOK-00329)
- Charging Cable (typically Micro-USB)



Figure 1.1: The TOKK Smart Wearable Assistant, a compact, circular device with an integrated magnetic clip.



Figure 1.2: The TOKK device is highly portable, fitting easily into daily essentials.

2. Setup

2.1. Charging the Device

1. Connect the charging cable to the TOKK device's charging port.
2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The device typically takes approximately 1 hour to fully charge. A full charge provides up to 4 hours of continuous usage or 40 hours of standby time.
4. An indicator light (usually red for charging, off/blue for full) will show the charging status.

2.2. Powering On/Off

- **To Power On:** Press and hold the multi-function button (usually the main button on the device) for a few seconds until you hear an audible prompt or see an indicator light (e.g., blue LED) illuminate.
- **To Power Off:** Press and hold the multi-function button again for a few seconds until you hear an audible prompt or the indicator light turns off.

2.3. Bluetooth Pairing

To use the TOKK Smart Wearable Assistant, it must be paired with a Bluetooth-enabled device (e.g., smartphone, tablet).

1. Ensure the TOKK device is powered on and in pairing mode. (Often, it enters pairing mode automatically on first power-on, or by holding the power button longer until the indicator light flashes rapidly).
2. On your smartphone or other device, navigate to the Bluetooth settings.
3. Turn on Bluetooth and search for available devices.
4. Select "TOKK" or a similar name from the list of found devices.
5. Once connected, the TOKK device will usually provide an audible confirmation, and its indicator light may change to a steady blue.



Figure 2.1: The TOKK device ready for Bluetooth connection, highlighting its core functions.

3. Operating Instructions

The TOKK Smart Wearable Assistant offers several functions through its intuitive controls.

3.1. Hands-Free Calling

- **Answering/Ending Calls:** Press the multi-function button once to answer an incoming call. Press it again to end an active call.
- **Rejecting Calls:** Press and hold the multi-function button for approximately 2 seconds to reject an incoming call.
- **Voice Dialing/Assistant:** Double-press the multi-function button to activate your smartphone's voice assistant (Siri, Google Now, Cortana). You can then issue voice commands for dialing contacts or other tasks.

3.2. Music Playback

- **Play/Pause:** Press the multi-function button once to play or pause music.
- **Volume Control:** Use the volume buttons (typically marked '+' and '-') on the device to adjust the audio output level.
- **Next/Previous Track:** Specific controls for track skipping may vary; often, a long press on volume buttons or a double/triple press on the multi-function button is used. Refer to the device's quick start guide for exact sequence if needed.

3.3. Remote Shutter Function

The TOKK device can act as a remote shutter for your smartphone camera.

1. Open the camera application on your iPhone or Android device.
2. Press either the '+' or '-' volume button on your TOKK device. This will trigger your phone's camera to take a picture.



Figure 3.1: The TOKK device magnetically attaches to clothing for convenient, hands-free use.



Figure 3.2: The TOKK device provides hands-free audio and communication while on the go.



Figure 3.3: The TOKK device is designed to be compact and deliver clear audio for active lifestyles.



Figure 3.4: The TOKK device enables hands-free communication, ideal for use in vehicles.

4. Maintenance

4.1. Cleaning

- Wipe the device with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or strong chemicals, as these may damage the device's finish or internal components.
- Avoid getting moisture into any openings. The device is not waterproof.

4.2. Storage

- Store the TOKK device in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, ensure the device has some charge (e.g., 50%) to help preserve battery health.

5. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Battery is depleted.	Charge the device for at least 15-30 minutes, then try powering on again.
Cannot pair with smartphone.	Bluetooth is off on phone; device not in pairing mode; too far from phone.	Ensure Bluetooth is enabled on your phone. Put TOKK device into pairing mode (flashing LED). Keep devices within 1 meter during pairing. Try restarting both devices.
No sound or poor sound quality.	Volume too low; device not connected; interference.	Increase volume on both TOKK and your phone. Ensure TOKK is connected. Move closer to your phone or away from other wireless devices.
Remote shutter not working.	Camera app not open; device not connected.	Ensure your phone's camera app is open and active. Verify the TOKK device is connected via Bluetooth.

6. Specifications

Model Number	TOK-00329
Brand	TOKK

Connectivity Technology	Bluetooth
Speaker Maximum Output Power	6 watts
Audio Output Mode	Stereo
Control Method	Voice
Battery Average Life	4 hours (continuous usage)
Battery Charge Time	1 hour
Standby Time	40 hours
Item Weight	27.22 g
Color	Black
Water Resistance Level	Not Water Resistant
Compatible Devices	Smartphone, Tablet, MP3 Player, Laptop

7. Warranty and Support

7.1. Warranty Information

The TOKK Smart Wearable Assistant (TOK-00329) comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the documentation included with your purchase or contact the manufacturer directly. The product is identified as "TOKK2" in warranty descriptions.

7.2. Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact the manufacturer:

- **Manufacturer:** Pred Technologies USA, Inc
- Please visit the official TOKK website or refer to your product packaging for the most current contact information (phone, email, support portal).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MXHGKBU

More documents and user manuals: **https://manuals.plus/**