

Sportneer 4333560717

Sportneer Compass Instruction Manual

INTRODUCTION

Welcome to your Sportneer Compass. This precision instrument is designed for reliable navigation in various outdoor conditions. Please read this manual carefully to understand its features and ensure optimal performance.

PRODUCT FEATURES

- **High-Precision:** Engineered for superior accuracy with a rear sight lens that magnifies the dial for precise and effortless readings. For optimal performance, keep the compass level to ensure the magnetic needle rotates freely and points accurately to magnetic north.
- **Durable Construction:** Crafted with a durable metal base and cover, this compass is built to withstand years of rugged outdoor use. Its waterproof and shock-resistant construction ensures reliable performance in harsh weather and tough terrains.
- **Versatile Use:** This precision compass delivers reliable bearings and sighting for camping, hiking, hunting, and scouting. Its rugged navigation capabilities keep you on course in any terrain, making it an essential adventure companion.
- **Nighttime Visibility:** After sufficient exposure to light, the north indicator and dial markings glow in the dark with a fluorescent coating, providing clear and reliable readings even in complete darkness. Ideal for night navigation or low-light conditions.
- **Portable Design:** This lightweight compass easily slips into any pocket or backpack, making it a must-have for outdoor adventures. With its simple navigation and handy lanyard, it's great for kids learning about the outdoors and perfect as a thoughtful gift for hikers, campers, and nature lovers of all ages.



This diagram highlights the main components of the compass, including the fluorescent directional arrow for accurate readings day and night, the sturdy metallic cover for protection, the reference window with cross-lines for precise measurements, the fluorescent dial for low-light visibility, the glass cover, the integrated spirit level, and the measurement scale.

WHAT'S IN THE BOX

- 1 x Sportneer Military Compass
- 1 x Strap
- 1 x Storage Pouch



The image displays the Sportneer Compass, its adjustable strap, and a protective storage pouch, all included with the product.

SETUP

Unpacking and Initial Inspection

Carefully remove the compass from its packaging. Inspect the compass for any visible damage. Ensure all components listed in 'What's in the Box' are present.

Attaching the Strap

Attach the provided strap to the compass for secure carrying. The strap can be worn around the neck or attached to gear.

Magnetic Interference Warning

WARNING: Avoid strong magnetic fields.

For accurate readings, keep the compass away from sources of magnetic interference such as power lines, mobile phones, magnets, vehicles, and other metal objects. These can cause the magnetic needle to deviate, leading to incorrect readings.

MAGNETIC INTERFERENCE WARNING:
Avoid strong magnetic fields (power lines, phones, magnets, vehicles, metal objects)



**For accurate readings:
Level the compass until the green bubble centers**



This image illustrates the importance of avoiding magnetic interference by showing the compass in an outdoor setting with a clear warning against nearby electronic devices and metal objects.

OPERATING INSTRUCTIONS

1. Leveling the Compass

Before taking any reading, ensure the compass is perfectly level. Use the integrated spirit level (bubble level) to achieve

this. The magnetic needle must be able to rotate freely.



This visual guide shows the correct way to hold the compass level, with the green bubble centered in the spirit level, and an example of an incorrect, tilted position that would result in inaccurate readings.

2. Taking a Bearing

1. Open the compass fully so the sighting mirror is upright and the compass dial is visible.
2. Align the sighting line on the mirror with your target.

3. Look through the rear sight lens to read the bearing on the compass dial. The rear sight lens magnifies the dial for easier reading.
4. Rotate the bezel until the orienting arrow aligns with the travel arrow (red line) on the dial. The red line should be directly under the number '36' on the bezel for a North alignment.
5. The number indicated by the travel arrow on the bezel is your bearing.


Your browser does not support the video tag.

This video provides a visual guide on how to operate the Sportneer Compass, showing steps like rotating the bezel to align arrows and ensuring the compass is level for accurate readings.

3. Nighttime Navigation (Glow-in-the-Dark Feature)

For use in low-light or nighttime conditions, expose the compass to a light source (like sunlight or a flashlight) for a sufficient period during the day. The fluorescent coating on the north indicator and dial markings will then glow, providing visibility in the dark.

WATERPROOF



SHOCKPROOF

This image demonstrates the compass's glow-in-the-dark feature, showing how the dial and north indicator illuminate after exposure to light, making it usable for night navigation.

MAINTENANCE

- **Cleaning:** Wipe the compass with a soft, dry cloth. Avoid abrasive cleaners or solvents that could damage the finish or internal components.
- **Storage:** Store the compass in its protective pouch when not in use to prevent scratches and damage. Keep it in a

cool, dry place away from strong magnetic fields.

- **Avoid Drops:** While shockproof, repeated drops can affect calibration and accuracy. Handle with care.

TROUBLESHOOTING

Inaccurate Readings

- **Check for Magnetic Interference:** Ensure you are not near any electronic devices, metal objects, or power lines that could disrupt the magnetic needle.
- **Level the Compass:** Verify the compass is perfectly level using the spirit level. A tilted compass will give incorrect readings.
- **Free Movement:** Ensure the magnetic needle can rotate freely without sticking. If it sticks, gently tap the compass to free it. If the issue persists, the compass may be damaged.

Difficulty Reading Dial in Dark

- **Re-expose to Light:** The glow-in-the-dark feature requires prior exposure to light. Re-expose the compass to sunlight or a strong artificial light source for several minutes.

SPECIFICATIONS

Feature	Detail
Brand	Sportneer
Model Number	4333560717
Material	Metal
Item Weight	7.2 ounces
Product Dimensions	3.3"L x 2.5"W
Special Feature	Waterproof
UPC	860000054072
Included Components	Military compass, strap, storage pouch

WARRANTY & SUPPORT

Warranty Information

According to product specifications, there is no explicit warranty provided for this item. Please refer to the retailer's return policy for details on returns or exchanges.

Customer Support

For any questions, concerns, or assistance with your Sportneer Compass, please contact Sportneer customer service through their official website or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question