

[manuals.plus](#) /› [Scosche](#) /› [Scosche Magnetic Phone Mount with USB Charger \(Model MAG12V\) - Instruction Manual](#)**Scosche MAG12V**

Scosche Magnetic Phone Mount with USB Charger (Model MAG12V) - Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the Scosche Magnetic Phone Mount with USB Charger, designed for convenient and secure mounting of your smartphone in your vehicle. This device plugs directly into a standard 12V power outlet, offering both a stable magnetic hold for your phone and an integrated USB charging port.

MAGNETIC MOUNT FOR MOBILE DEVICES

100% Safe for Smartphones



NEODYMIUM MAGNETS

Provide A Stronger More Secure Hold



CRADLE-FREE DESIGN

Allows Access To All Ports And Controls



TEMPERATURE RESISTANT

To Hot And Cold Days



Image: Overview of the Scosche Magnetic Phone Mount with USB Charger, highlighting its magnetic capabilities, cradle-free design, and temperature resistance.

WHAT'S IN THE BOX

Verify that all components are present in your package:

- Magnetic Phone Mount with USB Charger
- MagicPlates (for device attachment)
- User Manual (this document)

SETUP INSTRUCTIONS

Attaching the MagicPlate

The MagicPlate is essential for the magnetic connection. Choose the appropriate plate and placement based on your phone and case:

1. Clean the back of your device or phone case thoroughly.
2. For phones with thin cases, attach the MagicPlate directly to the back of your phone or inside the case.
3. For phones with rugged or thick cases, attach the MagicPlate to the exterior of your phone case for a stronger magnetic hold.



Image: Visual guide for attaching the MagicPlate to a phone with a thin case (inside) and a rugged/thick case (outside).

Mounting the Device

Follow these steps to install the mount and secure your phone:

1. Insert the mount firmly into a standard 12V front-facing power outlet in your vehicle. Ensure it is not a recessed or angled socket for proper fitment.
2. Once the mount is securely in place, hover your device (with the MagicPlate attached) near the magnetic surface of the mount. The magnets will instantly secure your device.
3. Connect your charging cable to the USB port on the mount and to your device if charging is desired.

Your browser does not support the video tag.

Video: Demonstration of the Scosche MagicMount Power Outlet Mount installation and usage, showing how to secure a mobile device and utilize the USB port.

MAGICPLATE INSTALLATION

Attach the Included Metal Plate Directly to Your Device or Case to Ensure a Secure Magnetic Connection



**PHONES WITH
THIN CASES**

**PHONES WITH
RUGGED/THICK CASES**

Image: The magnetic phone mount installed in a car's 12V outlet, holding a smartphone and providing charge.

OPERATING INSTRUCTIONS

Adjusting the Viewing Angle

The mount features a 4-Axis, 360-degree adjustable ball joint neck with a lock nut. This allows you to position your phone for optimal viewing in both portrait and landscape orientations. Simply loosen the lock nut, adjust the phone to your desired angle, and then tighten the lock nut to secure it.

Fully Adjustable Design

Place it where you need it



Adjustable Mount
with Lock Nut

Image: Illustration of the fully adjustable design, showing the flexible neck and 360-degree rotating mount head with a lock nut.

Using the USB Charging Port

The integrated USB-A port provides 12W (2.4 Amps) of power, allowing you to charge your device while it is mounted. The port illuminates for easy visibility in low-light conditions. This eliminates the need for an additional cigarette lighter adapter for charging.

PHONE COMPATIBILITY

Must Use Included **MagicPlate** (Not MagSafe Compatible)



iPhone 16



iPhone 15



iPhone 14



iPhone 13



Google Pixel



Galaxy S25



Galaxy S24



OnePlus 13



Motorola Razr+



Motorola Edge



Older Phones Too!

Image: Details on the fast charging capability, indicating 12W 2.4 Amps of power output from the USB port.

PHONE COMPATIBILITY

This magnetic phone mount is compatible with a wide range of smartphones. It is designed to work best with standard-size cell phones (under 9 oz) and slim-profile cases. The included MagicPlate is required for magnetic attachment.

Compatible devices include, but are not limited to:

- Apple iPhone models (e.g., iPhone 17, 16, 15, 14, 13, 12, 11, X, XR, Xs, Xs Max, 8, 7, 6, 6S, Plus, SE)
- Samsung Galaxy models (e.g., S25, S24, S23, S22, S21, S20, Note series, Z Fold/Flip series, A series)
- Google Pixel models (e.g., Pixel 10, 9, 8, 7, 6, 5, 4, 3, 2, XL, a series, Fold)
- LG, OnePlus, Motorola, Sony, Nokia, XiaoMi, Huawei, Nintendo Switch, and other similar devices.



Image: A chart illustrating various compatible phone models, emphasizing the need for the included MagicPlate.

MAINTENANCE

To ensure optimal performance and longevity of your Scosche Magnetic Phone Mount, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the mount and magnetic surface regularly. Avoid abrasive cleaners or solvents.
- **Handling:** When inserting or removing the mount from the 12V socket, always grip the plug portion, not the flexible neck, to prevent damage.
- **Magnetic Plates:** Ensure the MagicPlates remain securely attached to your device or case. If they become loose, re-adhere them or replace them if necessary.

TROUBLESHOOTING

If you encounter any issues with your magnetic phone mount, refer to the following common solutions:

- **Weak Magnetic Hold:** If your phone does not hold securely, ensure the MagicPlate is correctly positioned on your device or case. Thick or rugged phone cases can reduce magnetic strength; consider attaching the plate to the outside of such cases for a stronger hold. The mount is optimized for devices under 9 oz.
- **Wireless Charging Interference:** The metal MagicPlate can interfere with wireless charging capabilities. If your device supports wireless charging, you may need to remove the MagicPlate or use a different mounting solution when wireless charging is desired.
- **Mount Instability:** Ensure the mount is fully and securely inserted into a standard 12V power socket. The friction-locked base requires a snug fit for maximum stability.
- **USB Port Not Charging:** Verify that the mount is properly seated in the 12V socket and that your vehicle's ignition is on (if required for the 12V outlet). Check your USB cable for damage and ensure it is correctly connected to both the mount and your device.

SPECIFICATIONS

Feature	Detail
Product Dimensions	1.68 x 4.68 x 8.47 inches
Item Weight	3.2 ounces
Item Model Number	MAG12V
Special Features	Adjustable, Rotatable
Color	Black
Mounting Type	Magnetic Mount
USB Output	12W (2.4 Amps)

SAFETY INFORMATION

WARNING: This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.

- Ensure the mount does not obstruct your view of the road, airbags, or vehicle controls.
- Do not attempt to disassemble or modify the product.
- Keep out of reach of children.
- Avoid exposing the product to extreme temperatures or direct sunlight for prolonged periods.

WARRANTY AND SUPPORT

Scosche products are backed by a limited warranty. For specific warranty details, product registration, or technical support, please visit the official Scosche website or contact their customer service department. Keep your purchase receipt for warranty claims.

Online Support: Visit www.scosche.com