

[Manuals.plus](#) /

› [Hotpoint](#) /

› Hotpoint Genuine Washing Machine Part C00082696 Instruction Manual

Hotpoint C00082696

Hotpoint Genuine Washing Machine Part C00082696 Instruction Manual

Model: C00082696 | Brand: Hotpoint

PRODUCT OVERVIEW

This document provides essential instructions for the installation and maintenance of the Hotpoint Genuine Washing Machine Part, reference C00082696. This part is designed as a direct replacement component for specific Hotpoint and Ariston washing machine models. The part is identified by its dimensions: 35x62-75x7-10.



Image of the Hotpoint Genuine Washing Machine Part C00082696. This component is a critical internal part, typically a seal or bearing, essential for the proper functioning of the washing machine drum assembly.

SAFETY INFORMATION

Please read and understand all safety precautions before attempting installation or maintenance.

- Always disconnect the washing machine from the power supply before attempting any installation or maintenance.
- Wear appropriate personal protective equipment, such as gloves, to prevent injury.
- If you are unsure about any step, consult a qualified technician.
- Keep small parts away from children.

INSTALLATION INSTRUCTIONS

This part is an internal component and requires disassembly of the washing machine. Professional installation is recommended.

1. **Preparation:** Ensure the washing machine is unplugged and the water supply is turned off. Drain any residual water.

2. **Access:** Depending on your washing machine model, access to the component may require removing the back panel, top panel, or front panel. Refer to your specific washing machine's service manual for detailed disassembly instructions.
3. **Removal of Old Part:** Carefully locate the existing part (e.g., drum seal or bearing). Note its orientation and how it is secured. Use appropriate tools to remove it, taking care not to damage surrounding components.
4. **Installation of New Part:** Position the new Hotpoint Genuine Part C00082696 in the exact location and orientation of the old part. Ensure it fits securely and correctly. Apply any necessary lubricants or sealants as specified by your washing machine's service manual.
5. **Reassembly:** Reassemble the washing machine by reversing the disassembly steps. Ensure all connections are secure and panels are correctly fitted.
6. **Testing:** Before full operation, perform a test cycle with no laundry to check for leaks or unusual noises.

FUNCTION AND OPERATION

The Hotpoint Genuine Washing Machine Part C00082696 is a critical component designed to restore or maintain the proper mechanical function of your washing machine. Depending on its specific application (e.g., drum seal, bearing), it ensures water containment, smooth drum rotation, or structural integrity. Correct installation is essential for optimal washing machine performance and longevity.

MAINTENANCE

As an internal component, this part generally requires no routine user maintenance after correct installation.

- **Regular Inspection:** During any other washing machine maintenance, visually inspect the area around this part for signs of wear, leaks, or damage.
- **Cleaning:** Avoid using harsh chemicals near the component. If cleaning is necessary, use a damp cloth with mild detergent.

TROUBLESHOOTING

If issues arise after replacing this part, consider the following:

Problem	Possible Cause	Solution
Water Leakage	Part not seated correctly, damaged during installation, or surrounding seals compromised.	Recheck installation, ensure all seals are intact and properly aligned. Tighten connections.
Unusual Noise (e.g., grinding, squealing)	Incorrect installation of bearing, foreign object, or other damaged components.	Verify correct bearing installation. Inspect for obstructions. If noise persists, professional inspection is recommended.
Machine not operating	Electrical connection issues during reassembly, or other unrelated fault.	Check all electrical connections. Ensure power supply is connected. Consult washing machine's main manual for general troubleshooting.
Part appears damaged upon receipt	Shipping damage or manufacturing defect.	Do not install. Contact your supplier for a replacement.

SPECIFICATIONS

- **Part Reference:** C00082696
- **Manufacturer Reference:** 35X62-75X7-10
- **Brand:** Hotpoint
- **Type:** Genuine Manufacturer Replacement Part for Washing Machines
- **Compatibility:** Refer to the product description for a list of compatible washing machine models (e.g., ARISTON AAX149L, ALD120FR, AVL125X, W129XFR, WIL1400OTFR, etc.).
- **Material:** Original manufacturer specification.

WARRANTY AND SUPPORT

Information regarding the availability of spare parts and specific warranty details for this component is not provided in the product data. For any warranty claims or technical support, please contact the original point of purchase or Hotpoint customer service directly, providing your washing machine model number and the part reference C00082696.