

## tectake 402286

# tectake Garden Roller 60 cm Instruction Manual

Model: 402286

## 1. INTRODUCTION

---

This manual provides instructions for the safe and effective use of your tectake Garden Roller 60 cm. Please read these instructions carefully before assembly and operation. Keep this manual for future reference.

The tectake Garden Roller is designed to compact freshly sown lawns or flowerbeds, ensuring seeds are well-pressed into the soil for optimal germination. Its robust steel construction and ergonomic design make it a versatile tool for garden care.

## 2. SAFETY INSTRUCTIONS

---

- Always operate the garden roller on level ground.
- Ensure the filling cap is securely tightened before use to prevent leakage.
- Do not overfill the roller. Refer to the specifications for maximum capacity.
- Keep hands and feet clear of moving parts during operation.
- Store the roller in a dry, protected area when not in use.
- This product is intended for garden use only. Do not use for purposes other than those specified.
- Children should not operate this equipment.

## 3. PACKAGE CONTENTS

---

Please check that all parts are present before assembly:

- 1x Garden Roller drum
- 1x Handle assembly (including scraper)
- Assembly hardware (bolts, nuts, washers)
- Illustrated assembly instructions

## 4. SETUP AND ASSEMBLY

---

The tectake Garden Roller requires assembly. Follow the included illustrated instructions carefully. A general overview of the assembly process is provided below:

1. Unpack all components and lay them out on a clean, flat surface.
2. Attach the handle assembly to the roller drum using the provided hardware. Ensure all bolts are securely tightened.
3. Position the scraper bar so it is close to the roller surface but does not impede its rotation.
4. Verify that all connections are stable and secure before proceeding to fill the roller.

**tectake**  
garden

## Dettagli prodotto

### MISURE

**Altezza totale con impugnatura**  
107 cm

**Larghezza rullo**  
60 cm

**Diametro rullo**  
31 cm

**Impugnatura imbottita**  
17 x 3,5 cm

**Diametro apertura di riempimento**  
1,8 cm

Tutte le misure sono indicative

### DATI TECNICI

**Volume di riempimento (rullo) 50 l**

**Peso (a vuoto) ca. 10 kg**

**Materiale** acciaio verniciato a polvere

### CONTENUTO

Rullo per prato

Materiale di montaggio

Istruzioni di montaggio




**Figure 4.1:** Diagram illustrating the dimensions and key components of the garden roller, including total height, roller width, and diameter.

## 5. OPERATING INSTRUCTIONS

### 5.1 Filling the Roller

The garden roller can be filled with either sand or water to achieve the desired weight for compaction. The filling opening is located on the side of the roller drum.

- **For lighter compaction:** Fill with water. The maximum weight when filled with water is approximately 60 kg.
  - **For heavier compaction:** Fill with sand. The maximum capacity is approximately 50 liters.
1. Unscrew the filling cap on the side of the roller.
  2. Carefully fill the roller with water or sand using a funnel if necessary.
  3. Do not exceed the maximum capacity of 50 liters.
  4. Securely screw the filling cap back on to prevent leakage during operation.



**Figure 5.1:** Image demonstrating the filling process of the garden roller with sand or water through the side opening.

## 5.2 Using the Garden Roller

The garden roller is used to compact soil, press seeds into the ground, and level surfaces in your garden.

- **For newly sown lawns:** Gently push or pull the roller across the freshly sown area. The weight of the roller will press the seeds into the soil, improving contact and germination rates.
- **For leveling soil:** Use the roller to smooth out uneven patches in garden beds or before laying turf.

- The integrated scraper prevents soil and debris from accumulating on the roller surface, ensuring smooth operation.

# tectake

garden

**Utilizzo versatile**  
per compattare, livellare o  
pressare le sementi

**Pressione regolabile**  
tramite riempimento con  
sabbia o acqua

**Struttura robusta**  
in resistente acciaio  
verniciato a polvere

**Con raschietto antiscorco**  
per un lavoro ancora  
più uniforme

**Impugnatura imbottita**  
assicura una migliore  
maneggevolezza

**Materiale di montaggio**  
incluso, per assemblarlo in  
modo rapido e semplice

**Figure 5.2:** An individual using the tectake Garden Roller to compact a lawn area, highlighting its ergonomic design and scraper feature.

# INCREDIBILMENTE versatile.

Con questo robusto accessorio potrai pressare il prato appena seminato, livellare il terreno e tanto altro. Un pratico aiutante per tutte le tue attività in giardino.



Scorrevole  
struttura in acciaio



Livellare il suolo



Pressare le sementi



Far aderire tappeti erbosi

**Figure 5.3:** Visual representation of the garden roller's versatile applications, including soil leveling, seed pressing, and turf adhesion.

## 6. MAINTENANCE

---

- **Cleaning:** After each use, clean the roller drum and scraper with water to remove any soil or debris. Dry thoroughly to prevent rust.
- **Storage:** When not in use, empty the roller of its contents (water or sand) to prevent freezing damage in cold weather and to reduce storage weight. Store in a dry, covered area.
- **Inspection:** Periodically check all bolts and connections for tightness. Tighten if necessary. Inspect the roller surface for any damage or excessive wear.
- **Rust Prevention:** The roller is made of steel. While it may have a protective coating, prolonged exposure to moisture can lead to rust. Ensure it is dry before storage.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Roller not compacting effectively.	Roller is not heavy enough.	Fill the roller with sand for increased weight, or ensure it is fully filled with water.
Soil sticking to the roller.	Scraper is not properly adjusted or is damaged.	Adjust the scraper to be closer to the roller surface. Clean the scraper. Replace if damaged.
Water leaking from the roller.	Filling cap is loose or damaged.	Ensure the filling cap is tightly secured. Inspect the cap and its seal for damage and replace if necessary.
Difficulty rolling.	Uneven ground or debris obstructing movement.	Clear the area of large debris. Ensure the ground is prepared for rolling.

## 8. SPECIFICATIONS

<b>Model Number:</b>	402286
<b>Brand:</b>	tectake
<b>Total Height (with handle):</b>	107 cm
<b>Roller Width:</b>	60 cm
<b>Roller Diameter:</b>	31 cm
<b>Filling Capacity (Roller):</b>	Approx. 50 liters
<b>Weight (empty):</b>	Approx. 10 kg
<b>Weight (filled with water max.):</b>	Approx. 60 kg
<b>Material:</b>	Alloy Steel
<b>Power Source Type:</b>	Manual
<b>Color:</b>	Green

## 9. WARRANTY AND SUPPORT

Specific warranty information is not provided in the product details. For warranty claims or technical support, please contact your retailer or the manufacturer directly using the contact information provided at the point of purchase.

For further assistance, please refer to the tectake official website or contact their customer service department.

