

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gator Frameworks](#) /
- › [Gator Frameworks GFW-UTL-WS250 Adjustable T-Stand Instruction Manual](#)

Gator Frameworks GFW-UTL-WS250

Gator Frameworks GFW-UTL-WS250 Adjustable T-Stand Instruction Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Gator Frameworks GFW-UTL-WS250 Adjustable T-Stand. Designed for versatility and stability, this folding T-stand is suitable for supporting various equipment, including keyboards, mixers, DJ controllers, and DJ coffins. Please read this manual thoroughly before assembly and operation to ensure proper usage and longevity of your product.



Figure 1: The Gator Frameworks GFW-UTL-WS250 T-Stand in its fully assembled configuration, ready for use as a workstation or keyboard stand.

2. PRODUCT OVERVIEW

The GFW-UTL-WS250 T-Stand is engineered for durability and ease of use. Key features include:

- **Versatile Workstation:** Ideal for keyboards, mixers, DJ controllers, and DJ coffins.
- **Quick & Easy Setup:** Features a quick-pull leg height adjustment for fast configuration.
- **Adjustable & Customizable:** Legs adjust for various setup configurations to fit your needs.
- **Compact & Portable:** Collapsible design folds down for easy transport and storage.
- **Protective Pads:** Adjustable rubber bumper pads provide a soft and secure platform, preventing scratches.

3. SETUP INSTRUCTIONS

The GFW-UTL-WS250 T-Stand is designed for quick and straightforward setup.

1. **Unfolding the Stand:** Place the folded stand on a flat surface. Gently pull the legs outwards until they lock into an open position. Ensure all four legs are fully extended and stable.



Figure 2: Top view of the Gator Frameworks T-Stand in its compact, folded state, highlighting its portability.

2. **Adjusting Height:** Locate the quick-pull leg lock releases on each leg. Pull the release pin and slide the inner leg section to your desired height. Ensure the pin snaps securely into one of the adjustment holes. Repeat for all four legs to achieve a level surface.





Figure 3: A close-up of the quick-pull leg lock release mechanism, used for adjusting the stand's height.

- 3. Adjusting Width:** The horizontal support bars can be adjusted to accommodate different equipment widths. Loosen the knobs on the central crossbar, slide the arms to the desired width, and then tighten the knobs securely.
- 4. Positioning Equipment:** Place your keyboard, mixer, or other equipment onto the stand's support arms. Ensure the adjustable rubber bumper pads are correctly positioned to provide maximum grip and protection for your gear.



Figure 4: Detail of the rubber bumper pads on the stand's support arms, designed to protect equipment and prevent slipping.

4. OPERATING INSTRUCTIONS

The GFW-UTL-WS250 T-Stand offers flexible configurations to suit various needs.

- **Height Adjustment:** The stand's height can be adjusted from 25.75 inches (654mm) to 35.50 inches (902mm). This allows for comfortable playing or working positions, whether seated or standing.
- **Width Adjustment:** The width is adjustable from 27.375 inches (695mm) to 47.75 inches (1213mm), accommodating a wide range of equipment sizes.

- **Versatile Use:** Use the stand for a single keyboard, a DJ controller setup, or an audio mixer. The robust design supports up to 250 lbs.



Figure 5: The T-Stand configured to hold a keyboard, demonstrating its use as a musical instrument stand.



Figure 6: The T-Stand supporting a DJ controller and laptop stand, showcasing its versatility as a DJ workstation.



Figure 7: The T-Stand holding an audio mixer, illustrating its suitability for various audio equipment.

5. MAINTENANCE

To ensure the longevity and optimal performance of your T-Stand, follow these maintenance guidelines:

- **Cleaning:** Wipe down the stand with a soft, damp cloth to remove dust and grime. Avoid abrasive cleaners or solvents that could damage the powder-coated finish.
- **Inspection:** Periodically check all adjustment knobs, pins, and hinges for tightness and proper function. Ensure rubber bumper pads are intact and providing adequate grip.
- **Storage:** When not in use, fold the stand to its compact dimensions (3.75" x 3.75" x 47.75") and store it in a dry, cool place to prevent rust or damage.

6. TROUBLESHOOTING

If you encounter any issues with your T-Stand, refer to the following common troubleshooting tips:

- **Stand is Unstable:** Ensure all leg lock release pins are fully engaged in their respective holes. Verify that the width adjustment knobs are tightened securely. Check that the stand is placed on a flat, even surface.

- **Difficulty Adjusting Height/Width:** Ensure the quick-pull release pins are fully disengaged before attempting to slide the legs. For width adjustment, ensure the central knobs are sufficiently loosened. Do not force adjustments.
- **Equipment Slipping:** Verify that the rubber bumper pads are clean and properly positioned under your equipment. Replace any worn or damaged pads.

7. SPECIFICATIONS

Model Number	GFW-UTL-WS250
Brand	Gator Frameworks
Material	Aluminum or Plastic
Finish Type	Powder Coated
Color	Black
Load Capacity	250 lbs (113.4 kg)
Minimum Height	25.75" (654mm)
Maximum Height	35.50" (902mm)
Minimum Width	27.375" (695mm)
Maximum Width	47.75" (1213mm)
Folded Dimensions (L x W x H)	47.75" x 3.75" x 3.75" (1213mm x 95mm x 95mm)
Item Weight	18.2 lbs (8.26 kg)
Assembly Required	No

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Gator Frameworks website or contact their customer service directly. Keep your purchase receipt for any warranty claims.