



[Manuals.plus](#) /

› [Hansgrohe](#) /

› Hansgrohe Croma100 VarioEco Hand Shower Head Instruction Manual

Hansgrohe 28535454

Hansgrohe Croma100 VarioEco Hand Shower Head

Model: 28535454

INTRODUCTION

The Hansgrohe Croma100 VarioEco Hand Shower Head is designed to provide a comfortable and efficient showering experience. This product incorporates advanced features such as QuickClean for easy maintenance, EcoSmart for water savings, and multiple spray modes for personalized comfort. This manual provides essential information for the proper installation, operation, and care of your new shower head.

SAFETY INFORMATION

Please read all instructions carefully before installation and use. Retain this manual for future reference. Ensure that all plumbing connections are secure to prevent leaks. Do not use abrasive cleaners or harsh chemicals on the product, as this may damage the finish or internal components. Always turn off the water supply before performing any maintenance or installation.

PRODUCT OVERVIEW

The Hansgrohe Croma100 VarioEco Hand Shower Head combines innovative technology with ergonomic design to enhance your daily shower. Key features include:

- **QuickClean Function:** Silicone nozzles allow for easy removal of limescale deposits by simply rubbing them with a finger.
- **EcoSmart Water Saving:** Achieves approximately 30% water savings compared to conventional shower heads. The EcoSmart insert can be removed in low water pressure areas for improved flow.
- **Phoenix Design:** Features an aesthetic design crafted by the renowned global design team, Phoenix Design.
- **XXL Performance:** Designed with a large spray disc diameter of 100mm for a more enveloping shower experience.
- **Multiple Spray Modes:** Offers four distinct spray modes: Soft, Normal, Medium, and Hard, allowing you to customize your shower.



Figure 1: Front view of the Hansgrohe Croma100 VarioEco Hand Shower Head, showing the spray plate and mode labels.





Figure 2: The Hansgrohe Cromo100 VarioEco Hand Shower Head displayed in its transparent retail packaging.




Figure 3: The Hansgrohe Croma100 VarioEco Hand Shower Head mounted on a wall, connected to a shower hose.

SETUP AND INSTALLATION

This hand shower head is designed for easy installation with standard shower hoses. No specialized tools are typically required.

1. **Prepare:** Ensure the main water supply to your shower is turned off.
2. **Remove Old Shower Head:** Unscrew your existing shower head from the shower hose by turning it counter-clockwise.
3. **Clean Threads:** If necessary, clean any residue from the shower hose threads.
4. **Install New Shower Head:** Screw the Hansgrohe Croma100 VarioEco Hand Shower Head onto the shower hose by turning it clockwise until hand-tight. Do not overtighten.
5. **Check for Leaks:** Turn on the main water supply and check for any leaks at the connection point. If leaks occur, tighten slightly more or ensure a rubber washer is properly seated within the connection.

OPERATING INSTRUCTIONS

The Hansgrohe Croma100 VarioEco features an intuitive spray mode selector on the shower head face.

1. **Turn on Water:** Activate your shower's water flow.
2. **Select Spray Mode:** Rotate the outer ring of the spray disc to cycle through the four available spray modes: Soft, Normal, Medium, and Hard. Each mode offers a different water intensity and pattern.



Figure 4: The shower head demonstrating a wide spray pattern, likely the 'Normal' or 'Soft' mode.



Figure 5: The shower head demonstrating a more focused spray pattern, possibly the 'Medium' or 'Hard' mode.

MAINTENANCE

Regular cleaning will ensure optimal performance and longevity of your Hansgrohe shower head.

- **QuickClean:** To remove limescale and mineral deposits from the silicone nozzles, simply rub them with your finger or a soft cloth while the water is running. This should be done regularly, especially in hard water areas.
- **General Cleaning:** Clean the surface of the shower head with a soft cloth and a mild, non-abrasive cleaner. Rinse thoroughly with water and dry with a soft cloth to prevent water spots. Avoid using cleaners containing alcohol, hydrochloric acid, formic acid, acetic acid, or chlorine bleach, as these can damage the finish.




Figure 6: A finger demonstrating the QuickClean function by rubbing the silicone nozzles to remove deposits.

TROUBLESHOOTING

If you encounter issues with your shower head, refer to the following common solutions:

Problem	Possible Cause	Solution
Low water pressure	Clogged nozzles; EcoSmart insert in low pressure area; kinked hose	Perform QuickClean; remove EcoSmart insert (if applicable); straighten hose
Water leaking from connection	Loose connection; missing/damaged washer	Tighten connection; check and replace washer if necessary
Uneven spray pattern	Clogged nozzles	Perform QuickClean to clear blockages

SPECIFICATIONS

Detailed specifications for the Hansgrohe Croma100 VarioEco Hand Shower Head:

Attribute	Detail
Brand	Hansgrohe
Product Model Number	28535454
Package Dimensions	34.2 x 15.2 x 8 cm
Item Weight	358.34 g
Color	White

Attribute	Detail
Material	Silicone, Metal
Quantity	1
Accessories	None
Shape	Round
Finish Type	Brushed
Installation Type	Wall Mount

WARRANTY INFORMATION

Hansgrohe products are manufactured to high quality standards and are backed by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Hansgrohe website. Keep your proof of purchase for warranty claims.

SUPPORT AND CONTACT

For further assistance, technical support, or inquiries regarding your Hansgrohe Croma100 VarioEco Hand Shower Head, please visit the official Hansgrohe website or contact their customer service department. Contact details can typically be found on the Hansgrohe website or product packaging.