

[manuals.plus](#) /› [Casio](#) /› [Casio Enticer MTP-V300G-9AUDF Analog Watch User Manual](#)**Casio MTP-V300G-9AUDF**

Casio Enticer MTP-V300G-9AUDF Analog Watch User Manual

INTRODUCTION

This manual provides essential information and instructions for the proper use and care of your Casio Enticer MTP-V300G-9AUDF analog watch. Please read this manual thoroughly to ensure correct operation and to maximize the lifespan of your timepiece. Keep this manual for future reference.

PRODUCT OVERVIEW

The Casio Enticer MTP-V300G-9AUDF is an analog watch featuring a gold-tone stainless steel band and case, a gold dial, and multiple indicators for date, day, and 24-hour time. It is designed for daily wear with water resistance for normal use.




Image: Front view of the Casio Enticer MTP-V300G-9AUDF analog watch, showcasing its gold dial, hands, and stainless steel band. The watch features three sub-dials for day, date, and 24-hour time.

SETUP AND INITIAL ADJUSTMENT

1. Setting the Time

1. Pull the crown (the knob on the side of the watch) out to the second click position.
2. Rotate the crown to move the hour and minute hands to set the correct time. Pay attention to the 24-hour indicator to distinguish between AM and PM for accurate date change.
3. Push the crown back in to the normal position to start timekeeping.

2. Setting the Date and Day

1. Pull the crown out to the first click position.
2. Rotate the crown to adjust the date and day indicators. Rotate in one direction for date, and the other for day. Avoid setting the date between 9:00 PM and 1:00 AM, as this may interfere with the automatic date change mechanism.
3. Push the crown back in to the normal position.

3. Adjusting the Band Length

The stainless steel band features a foldover clasp. If the band is too long, links may need to be removed by a qualified jeweler or watch technician. Do not attempt to remove links yourself unless you have the proper tools and experience, as this can damage the band.



Image: Side view of the watch, highlighting the crown used for setting time and date. The watch case and band are gold-toned stainless steel.

OPERATING THE WATCH

Timekeeping

Once set, the watch will continuously display the current time (hour, minute, second). The sub-dials indicate the day of the week, the date, and a 24-hour format for the current time.

Water Resistance

This watch is water resistant. This means it is suitable for everyday use and can withstand splashes or brief immersion in water. However, it is not suitable for swimming, diving, or showering with hot water, as steam and pressure can compromise the seals. Do not operate the crown while the watch is wet.

MAINTENANCE AND CARE

Cleaning

- Wipe the watch case and band periodically with a soft, dry cloth to remove dirt and moisture.
- For stainless steel bands, a soft brush and mild soapy water can be used, followed by thorough rinsing and drying. Ensure the crown is pushed in completely before cleaning with water.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish.

Battery Replacement

The watch is powered by a lithium metal battery. When the watch stops or the second hand moves erratically, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance integrity.

Storage

When not in use, store your watch in a dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields.



Image: Rear view of the watch, displaying the stainless steel case back with "WATER RESISTANT" and "STAINLESS STEEL BACK" engravings, along with the model number and other identifiers.

TROUBLESHOOTING

- Watch has stopped:** The battery may be depleted. Contact a qualified watch technician for battery replacement.
- Incorrect time/date:** Refer to the "Setup and Initial Adjustment" section to reset the time and date. Ensure the crown is fully pushed in after adjustment.
- Condensation inside the watch:** This indicates a loss of water resistance. Immediately take the watch to a service center to prevent further damage.
- Band discomfort:** Ensure the band is not too tight or too loose. If adjustment is needed, consult a jeweler.

SPECIFICATIONS

Model Number	MTP-V300G-9AUDF
Movement Type	Quartz
Dial Color	Gold
Band Material	Stainless Steel
Case Material	Gold Tone
Case Diameter	41.5 Millimetres
Water Resistance	Yes (suitable for splashes, not swimming/diving)
Battery Type	1 Lithium Metal battery (included)
Product Dimensions	20.5 x 0.9 x 3.5 cm
Item Weight	96 Grams
Included Components	Extra Clasp



Image: Visual representation of the watch's dimensions, indicating a case length of 47 mm, for size reference.

WARRANTY INFORMATION

Your Casio Enticer MTP-V300G-9AUDF watch comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, service, or inquiries regarding your Casio watch, please contact Casio customer service or visit their official website. Contact details can typically be found on the warranty card or Casio's regional support pages.

Manufacturer: Casio India Co Pvt Ltd

Address: A-41, 1st Floor, MCIE, Mathura Road, New Delhi-110044, India