SVINZ SDC008W

SVINZ Dementia Clock (Model SDC008W) Instruction Manual

Your guide to setting up and using your SVINZ Digital Day Clock.

INTRODUCTION

Thank you for choosing the SVINZ Dementia Clock. This 8-inch high-resolution digital alarm clock is designed to clearly display the time, day, date, week, month, and year, making it ideal for seniors, individuals with vision impairment, or those experiencing memory loss. It features multiple alarms, an auto-dimming option, and versatile mounting capabilities.

SETUP

Follow these steps to set up your SVINZ Dementia Clock:

1. **Unboxing:** Carefully remove the clock and all accessories from the packaging. Ensure you have the clock unit, power adapter, and user manual.

2. **Power Connection:** Connect the provided power adapter to the DC IN port on the back of the clock. Plug the adapter into a standard electrical outlet. The clock will power on automatically.

3. **Initial Display:** Upon first power-on, the clock may display a default time and date.

4. **Positioning:** The clock can be placed on a desk or bedside table using its integrated stand, or mounted on a wall using the two hanging holes on the back.

Image: The SVINZ Dementia Clock, its power adapter, and the welcome guide, neatly packaged. This image illustrates the items included in the box, ready for setup.

Image: Rear view of the SVINZ Dementia Clock, highlighting the enlarged control buttons, power port, and two hanging holes for wall mounting. This shows the physical controls and installation flexibility.

OPERATING INSTRUCTIONS

The SVINZ Dementia Clock features intuitive controls for easy operation. All settings are accessed via the buttons on the back of the unit.

Setting Time and Date

1. Press the **MENU** button on the back of the clock to enter the settings menu.

2. Use the **UP** and **DOWN** arrow buttons to navigate through the menu options (Set Time, Set Date, Time Mode, etc.).

3. Press the **OK** button to select an option.

4. Use the **LEFT** and **RIGHT** arrow buttons to adjust values (e.g., hours, minutes, month, day, year).

5. Press **OK** to confirm your selection and move to the next setting, or **MENU** to exit the current setting.

Video: This video demonstrates the features of the SVINZ Dementia Clock, including how to navigate the menu and adjust settings like time, date, and alarms. It highlights the ease of use for setting up the device.

Time Mode (12/24 Hour)

In the settings menu, select "Time Mode" and use the arrow buttons to switch between 12-hour and 24-hour formats.

Alarm Settings

The clock supports up to 5 individual alarms. Each alarm can be set with a specific time and frequency (e.g., Once, Everyday, Mon-Fri, Weekend, Off).

1. From the settings menu, select "Alarm Time 1" (or any other alarm).

2. Adjust the alarm time using the **LEFT** and **RIGHT** arrow buttons.

3. Select "Alarm Frequency" to choose how often the alarm repeats.

4. To disable an alarm, set its frequency to "Off".

Image: A close-up of the clock's menu displaying options for setting time, date, time mode, and multiple alarms with their frequencies. This image illustrates the user-friendly interface for alarm configuration.

Snooze Function

The clock features an easy-to-access SNOOZE button on the top. When an alarm sounds, press the SNOOZE button to temporarily silence it. You can set the snooze duration in the settings menu (3 or 5 times).

Image: A hand is shown pressing the large, clearly labeled "SNOOZE" button located on the top edge of the SVINZ Dementia Clock. This highlights the accessibility of the snooze feature.

Auto-Dimming

The clock can automatically adjust its brightness. It dims at 7:00 PM and brightens at 7:00 AM. This feature can be turned off in the settings menu if you prefer a consistent brightness level.

Image: A visual representation of the clock's auto-dimming feature, showing the display brightness during the day (7:00 AM) and dimmed at night (7:00 PM). This illustrates how the clock adapts to ambient light conditions.

Color Mode

Choose your preferred display color from the settings menu: White, Yellow, or Black (white text on black background).

Language Settings

The clock supports 8 languages: English, Français, Deutsche, Italiano, Polskie, Español, Nederlands, and Cymraeg. Select your desired language in the settings menu.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and exterior of the clock. Avoid using abrasive cleaners or solvents.

- **Power:** Always use the provided power adapter. Disconnect power during electrical storms or when not in use for extended periods.

- **Placement:** Avoid placing the clock in direct sunlight or near heat sources, as this may affect its performance and lifespan.

TROUBLESHOOTING

- **Clock not powering on:** Ensure the power adapter is securely connected to both the clock and a working electrical outlet.

- **Display is dim or too bright:** Check the "Auto-Dimming" setting in the menu. Adjust the brightness manually or turn auto-dimming off if preferred.

- **Alarm not sounding:** Verify that the alarm time and frequency are correctly set and that the alarm is not set to "Off". Check the volume setting.

- **Incorrect time/date:** Enter the settings menu and manually adjust the time and date.

SPECIFICATIONS

Feature	Detail
Brand	SVINZ
Model Number	SDC008W
Display Type	Digital
Screen Size	8 inches
Product Dimensions	7.4"W x 7.4"H
Item Weight	1.2 Pounds
Power Source	Corded Electric
Special Features	Alarm, Enlarged control buttons, Large digital display, Spanish switch, Auto-Dimming
Supported Languages	English, Français, Deutsche, Italiano, Polskie, Español, Nederlands, Cymraeg

WARRANTY

The SVINZ Dementia Clock comes with a manufacturer warranty for 12 months from the date of purchase. Please retain your proof of purchase for warranty claims.

Support

For further assistance, please refer to the contact information provided in your product's welcome guide or visit the official SVINZ website.