

Galanz GL27BK

Galanz 2.7 Cubic Foot Compact Refrigerator User Manual

Model: GL27BK

INTRODUCTION

Thank you for choosing the Galanz 2.7 Cubic Foot Compact Refrigerator. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read it thoroughly before use and retain it for future reference.



Front view of the Galanz 2.7 Cubic Foot Compact Refrigerator, featuring a sleek black finish and the 'Galanz' logo.

SAFETY INFORMATION

Your safety and the safety of others are very important. We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.

- **DANGER:** Risk of fire or explosion. Flammable refrigerant used. Do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail

applications.

SETUP

Unpacking

Remove all packaging materials, including foam base and adhesive tape. Inspect the refrigerator for any damage. Keep packaging materials out of reach of children.

Placement

- Place the refrigerator on a flat, solid surface that is strong enough to support the unit when fully loaded.
- Allow at least 5 inches (12.7 cm) of space between the back and sides of the refrigerator and any adjacent walls to ensure proper air circulation.
- Avoid placing the refrigerator in direct sunlight or near heat sources like stoves or heaters.
- Ensure the refrigerator is level by adjusting the leveling feet.

Power Connection

Plug the refrigerator into a dedicated, grounded electrical outlet. Do not use extension cords or adapter plugs.

Door Reversal

The door of this refrigerator can be reversed to open from either the left or right side. To reverse the door, carefully remove the plastic caps and screws from the top hinge, then remove the adjustable leg and screws from the bottom hinge. Reattach all components to the opposite side. This process typically takes about 5 minutes.

OPERATING INSTRUCTIONS

Temperature Control

The refrigerator features an adjustable thermostat control located inside the unit. Turn the dial to your desired setting. A higher number indicates a colder temperature. Allow several hours for the refrigerator to reach the set temperature after initial startup or adjustment.

Initial Startup

After plugging in the refrigerator, allow it to run for at least 2-3 hours before placing food items inside. This ensures the interior reaches a stable cooling temperature.

Storage Capacity

This 2.7 cubic foot compact refrigerator offers ample storage for beverages and small food items. It includes multiple wire shelves for organization and a separate ice cube chamber for freezing small quantities of ice.

MAINTENANCE

Cleaning

Regular cleaning helps maintain the efficiency and appearance of your refrigerator. Unplug the unit before cleaning. Use a soft cloth with a mild detergent and warm water to clean the interior and exterior surfaces. Avoid abrasive cleaners or harsh chemicals. The interior shelves are easy to remove for thorough cleaning.

Defrosting

This refrigerator features a manual defrost system. Frost will gradually accumulate on the freezing plate. When the frost layer becomes too thick (approximately 1/4 inch or 0.6 cm), manually defrost the unit. To defrost, unplug the refrigerator, remove all food items, and leave the door open. Place a towel at the bottom to absorb melted ice. Do not use sharp objects or heating devices to speed up the defrosting process.

TROUBLESHOOTING

If your refrigerator is not operating correctly, check the following common issues before contacting customer support:

- **Refrigerator does not operate:** Check if the power cord is securely plugged into the outlet. Verify the circuit breaker or fuse.
- **Temperature is not cold enough:** Ensure the temperature control is set correctly. Avoid frequent door openings. Check for proper air circulation around the unit.
- **Unusual noises:** Minor noises are normal during operation. Ensure the refrigerator is level and not touching any walls or cabinets.
- **Door does not close completely:** Check for obstructions, ensure the refrigerator is level, and inspect the door gasket for damage.

SPECIFICATIONS

Feature	Specification
Brand	Galanz
Model Number	GL27BK
Capacity	2.7 Cubic Feet
Product Dimensions (D x W x H)	18"D x 21"W x 26"H
Color	Black
Configuration	Compact Internal Freezer
Installation Type	Freestanding
Number of Doors	1
Defrost System	Manual
Cooling Method	Compressor
Adjustable Temperature Control	Yes
Refrigerant	R-600A
Item Weight	0.01 Ounces

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Galanz customer service. Keep your purchase receipt for warranty claims.