

Sony XBR65X900E

Sony XBR-65X900E 65-inch 4K HDR Smart LED TV User Manual

Model: XBR-65X900E | Brand: Sony

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Sony XBR-65X900E 65-inch 4K HDR Smart LED TV. This television combines stunning 4K Ultra HD clarity with High Dynamic Range (HDR) for a lifelike picture, powered by the 4K HDR Processor X1. Enjoy smart functionality with Android TV, offering access to a wide range of apps and content.

2. WHAT'S IN THE BOX

- Sony XBR-65X900E 65-inch 4K HDR Smart LED TV
- Power Cable
- Remote Control
- TV Stand


3. SETUP

3.1 Unboxing and Stand Installation

Carefully remove the TV from its packaging. It is recommended that two people handle the TV due to its size and weight. Attach the included stand to the bottom of the TV using the provided screws. Ensure the stand is securely fastened before placing the TV on a stable surface.




The Sony XBR-65X900E TV with its included stand. Ensure proper installation for stability.



Close-up view of the TV stand attachment points. Secure with provided screws.

3.2 Wall Mounting

The TV can also be wall-mounted. It features standard VESA screw holes for compatible wall mounts (sold separately). Refer to your wall mount's instructions for proper installation. Ensure the wall can support the TV's weight (approximately 77.2 pounds).



The Sony XBR-65X900E TV mounted on a wall, showcasing its slim profile.

3.3 Connecting Peripherals

Connect your devices to the TV's various input ports:

- **HDMI:** 4 HDMI ports for high-definition devices like Blu-ray players, gaming consoles, and cable boxes.
- **USB:** 2 USB 2.0 ports and 1 USB 3.0 port for connecting external storage or other USB devices.
- **Component/Composite Hybrid:** 1 port for older video devices.
- **Composite:** 1 dedicated composite video input.
- **LAN:** Ethernet port for wired network connection.
- **Optical Digital Audio Out:** For connecting to a soundbar or audio receiver.
- **Antenna/Cable:** For connecting an antenna or cable TV.

Your browser does not support the video tag.

Video demonstrating the unboxing and initial setup of a Sony X900E series TV, including connecting cables.

3.4 Initial Power On & Network Setup

After connecting all necessary cables, plug the power cable into an electrical outlet. Press the power button on the remote control. Follow the on-screen instructions to complete the initial setup, including connecting to your Wi-Fi network and logging into your Google account for Android TV features.

4. OPERATING YOUR TV

4.1 Remote Control

The included remote control provides easy access to all TV functions. Key buttons include:

- **Power:** Turns the TV on/off.
- **Input:** Selects the input source (HDMI, USB, etc.).
- **Volume +/-:** Adjusts the volume.
- **Channel +/-:** Changes TV channels.
- **Home:** Accesses the Android TV home screen.
- **Navigation Pad:** For navigating menus and selecting options.

- **Voice Control:** Activates Google Assistant for voice commands.
- **Dedicated App Buttons:** Quick access to popular streaming services like Netflix, Amazon Video, Hulu, and YouTube.

Your browser does not support the video tag.

Video showcasing the remote control and its voice command features for the Sony X900E series TV.

4.2 Android TV Features

Your Sony XBR-65X900E is equipped with Android TV, providing a smart and intuitive user experience. Access thousands of apps from Google Play, including Netflix, Amazon Video, Hulu, and YouTube. The TV is also Google Home-compatible, allowing for seamless integration with your smart home ecosystem.



The Sony XBR-65X900E TV displaying a live football game, highlighting its vibrant picture quality.



A smartphone casting content to the Sony XBR-65X900E TV, demonstrating its smart connectivity.

4.3 Picture Settings

Experience exceptional picture quality with advanced Sony technologies:

- **4K HDR Processor X1:** Enhances clarity, color, and contrast for a more realistic image.
- **TRILUMINOS Display:** Reproduces a wider, more vivid spectrum of colors.
- **4K HDR Super Bit Mapping:** Optimizes colors for rich and natural results.
- **4K X-Reality PRO:** Upscales images to near 4K clarity.
- **X-tended Dynamic Range PRO 5x:** Delivers five times the contrast range of conventional LED TVs.
- **Motionflow XR 960:** Ensures smooth, clear fast-moving action scenes.



The Sony XBR-65X900E TV demonstrating enhanced contrast and detail in a scene with a building.



The Sony XBR-65X900E TV displaying vibrant colors and clarity, highlighting its picture quality.

4.4 Sound Settings

The TV features balanced light output across the screen for greater brilliance in every scene. For enhanced audio, connect an external sound system via the optical digital audio out port.

4.5 Input Selection

To switch between connected devices, press the 'Input' button on your remote control and select the desired source from the on-screen menu.

5. MAINTENANCE

5.1 Cleaning

To clean the TV screen, gently wipe it with a soft, dry cloth. For stubborn smudges, lightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals or abrasive materials. Clean the TV's frame and stand with a soft, dry cloth.

5.2 Software Updates

Your Android TV will periodically receive software updates to improve performance and add new features. Ensure your TV is connected to the internet to receive these updates automatically. You can also manually check for updates in the TV's settings menu.

6. TROUBLESHOOTING

If you encounter any issues with your TV, try the following basic troubleshooting steps:

- **No Power:** Ensure the power cable is securely plugged into both the TV and the electrical outlet. Try a different outlet.
- **No Picture/Sound:** Check the selected input source. Ensure all cables are securely connected to the TV and external devices.

- **Remote Not Responding:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Network Connection Issues:** Restart your router and modem. Check the TV's network settings to ensure it's connected to the correct Wi-Fi network or that the Ethernet cable is properly connected.
- **Android TV Lag:** Restart the TV by unplugging it from the power outlet for a few minutes, then plugging it back in. Close unused applications.

For more detailed troubleshooting, refer to the comprehensive help guide available through the TV's Android TV interface or visit the Sony support website.

7. SPECIFICATIONS

Feature	Specification
Model Number	XBR65X900E
Screen Size	65 Inches
Resolution	4K Ultra HD (3840 x 2160)
Display Technology	LED with Full-Array Local Dimming
Refresh Rate	120Hz Native (Motionflow XR 960)
Processor	4K HDR Processor X1
Smart TV Platform	Android TV (Google Home Compatible)
Dimensions (without stand)	57" x 32.8" x 2.4" (W x H x D)
Dimensions (with stand)	57" x 35.3" x 10.3" (W x H x D)
Item Weight	77.2 pounds
HDMI Inputs	4
USB Ports	2 (USB 2.0), 1 (USB 3.0)
Connectivity	Wi-Fi, Ethernet
Power Consumption	212 watts




Diagram illustrating the dimensions of the Sony XBR-65X900E TV.

8. WARRANTY AND SUPPORT

Your Sony XBR-65X900E TV comes with a manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your product or visit the official Sony support website. For technical assistance, product registration, or service inquiries, please contact Sony Customer Support.