

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WELLAND](#) /

› [WELLAND 12-Inch Deep Floating Wall Shelf \(Model WSV119-240 BLK\) User Manual](#)

WELLAND WSV119-240 BLK

WELLAND 12-Inch Deep Floating Wall Shelf (Model WSV119-240 BLK) User Manual

Model: WSV119-240 BLK

1. IMPORTANT SAFETY INFORMATION

Always follow the included installation instructions for safe mounting. Do not exceed the maximum weight capacity of **25 pounds (11.3 kg)**. Ensure the shelf is securely fastened to a wall stud or appropriate wall anchors to prevent injury or damage.

2. PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- 1 x WELLAND 12-Inch Deep Floating Wall Shelf (23.62" L x 11.81" D x 2" T)
- Necessary Hardware (screws, wall anchors)
- Installation Instructions

Much deeper than normal floating shelves!

Full Width 11.8in = More Surface Area!




Image: Shelf dimensions (23.6" L x 11.8" D x 2" T).

3. SPECIFICATIONS

Brand	WELLAND
Model Number	WSV119-240 BLK
Product Dimensions	23.62" L x 11.81" D x 2" T (60cm L x 30cm D x 5cm T)
Material	Engineered Wood (MDF with honeycomb board filling)
Color	Black
Weight Limit	25 Pounds (11.3 kg)
Installation Type	Wall Mount

Assembly Required	No (Installation required)
Item Weight	5.5 Pounds (2.5 kg)



Image: The 11.8-inch depth provides ample surface area for various items.

4. SETUP AND INSTALLATION

The WELLAND Floating Wall Shelf is designed for straightforward installation. Please follow these steps carefully. Installation typically takes less than 15 minutes.

Tools Required (Not Included):

- Pencil
- Measuring Tape
- Level
- Drill with appropriate drill bits (for pilot holes and anchors)
- Screwdriver (Phillips head recommended)
- Stud Finder (recommended for optimal stability)

Installation Steps:

1. **Choose Location:** Select a suitable wall location. Use a stud finder to locate wall studs for the most secure mounting. If studs are not available, use appropriate wall anchors for drywall or plaster.
2. **Mark Pilot Holes:** Hold the mounting bracket (or the shelf itself, if the bracket is integrated) against the wall at the desired height. Use a level to ensure it is perfectly horizontal. Mark the positions for the pilot holes with a pencil.

3. **Drill Pilot Holes:** Drill pilot holes at the marked locations. The size of the drill bit will depend on whether you are drilling into a stud or using wall anchors. Follow the instructions provided with your wall anchors for correct drill bit size.
4. **Insert Wall Anchors (if needed):** If not drilling into studs, insert the plastic wall anchors into the pilot holes until they are flush with the wall surface.
5. **Attach Mounting Bracket:** Align the mounting bracket with the drilled holes (or anchors). Insert the screws through the bracket and tighten them securely into the wall studs or wall anchors using a screwdriver. Do not overtighten.
6. **Mount the Shelf:** Slide the floating shelf onto the installed mounting bracket. Ensure the shelf is fully seated and flush against the wall. The shelf should fit snugly over the bracket.
7. **Secure the Shelf (if applicable):** Some floating shelves may have small set screws on the underside to further secure them to the bracket. If present, tighten these screws.



Image: Example of internal mounting bracket for secure installation.

5. OPERATING AND USAGE GUIDELINES

The WELLAND Floating Wall Shelf is designed to provide a stylish and functional display or storage solution. To ensure longevity and safety, adhere to the following guidelines:

- **Weight Capacity:** Do not exceed the maximum weight limit of **25 pounds (11.3 kg)**. Distribute weight evenly across the shelf surface.
- **Suitable Items:** This shelf is ideal for displaying photos, small decorative items, books, DVDs, toys, and other light knickknacks.
- **Avoid Overloading:** Overloading the shelf can compromise its stability and lead to damage or injury.
- **Placement:** Consider the placement of heavier items closer to the wall for better balance.



Image: Example of shelf usage in a kitchen setting.

Large

V S

Small



Our

Deeper & Wider

Ots

Narrower & Shallower



Image: Example of shelf usage in a living room setting.

6. MAINTENANCE

To keep your WELLAND Floating Wall Shelf in optimal condition, follow these simple maintenance steps:

- **Cleaning:** Wipe the shelf surface with a dry, soft cloth to remove dust and light smudges.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish.
- **Moisture:** Avoid prolonged exposure to moisture. If spills occur, wipe them immediately with a dry cloth.
- **Regular Checks:** Periodically check the mounting screws and connections to ensure they remain tight and secure.




Image: Shelf displaying a plant and books. Regular cleaning helps maintain its appearance.

7. TROUBLESHOOTING

If you encounter any issues with your WELLAND Floating Wall Shelf, refer to the following common solutions:

- **Shelf feels wobbly:**
 - Ensure all mounting screws are tightened securely.
 - Verify that the shelf is properly seated onto the internal mounting bracket.
 - If installed into drywall without a stud, ensure appropriate wall anchors were used and installed correctly. Consider relocating to a wall stud if possible for maximum stability.
- **Shelf is not level:**
 - Loosen the mounting screws slightly, adjust the shelf using a level, and then re-tighten the screws.
 - Ensure the pilot holes were drilled accurately and the bracket is not bent.

- **Difficulty sliding shelf onto bracket:**

- Check for any obstructions inside the shelf's cavity or on the bracket rods.
- Ensure the bracket is installed straight and not at an angle.

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your WELLAND Floating Wall Shelf, please contact WELLAND customer service. Refer to your purchase documentation for specific warranty details.

You can visit the WELLAND Store for more information:[WELLAND Store](#)