De'Longhi KBOV1200J-GR

De'Longhi ICONA Vintage Collection 1.0L Electric Kettle KBOV1200J-GR User Manual

1. Introduction

Thank you for choosing the De'Longhi ICONA Vintage Collection Electric Kettle. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before use and keep them for future reference.

2. Important Safety Instructions

- Read all instructions before using the kettle.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or the kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the heating cycle.
- Ensure the lid is securely closed before operating.
- This appliance is for household use only.

3. Product Overview

3.1 Components

The De'Longhi ICONA Vintage Collection Electric Kettle features a classic design with modern functionality. It includes a main kettle body, a removable lid, a comfortable handle, a water level indicator, and a 360-degree swivel base with integrated cord storage.



Image: The De'Longhi ICONA Vintage Collection Electric Kettle (Model KBOV1200J-GR) in Olive Green, showing its overall design and approximate dimensions (Height: 235mm, Width: 210mm).

3.2 Key Features

- **1.0 Liter Capacity:** Ideal for individual use or small households.
- **Water Level Indicator:** A clear window allows for easy monitoring of water levels.
- **Removable Filter:** Located in the spout, it helps prevent limescale from entering your cup.
- **Automatic Shut-off:** The kettle automatically turns off once water reaches boiling point.
- **Boil-Dry Protection:** Prevents the kettle from operating when empty, enhancing safety.
- **360° Swivel Base:** Allows for cordless operation and easy placement from any angle.
- **Integrated Cord Storage:** The base includes a compartment to neatly store excess power cord.



Image: A detailed view highlighting the kettle's wide spout with a removable filter, and the clear water level gauge with markings for 0.5L, 0.75L, and 1.0L (MAX). Text indicates features like 'Wide spout, removable filter' and 'Easy-to-read water gauge, automatic power off, boil-dry prevention function'.



Image: The kettle's power base, illustrating the cord storage feature (left) and the 360-degree swivel capability (right). Text indicates 'Power cord holder: When not using the kettle, the power cord can be wound around the holder' and '360° rotation: Convenient as it does not choose a direction'.

4. Initial Setup

1. **Unpack:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Clean Before First Use:** Before using for the first time, fill the kettle with cold water up to the 'MAX' level. Boil the water, then discard it. Repeat this process at least twice to remove any manufacturing residues.
3. **Position the Base:** Place the power base on a flat, stable, heat-resistant surface, away from the edge of the countertop.
4. **Cord Management:** Adjust the length of the power cord by winding it around the storage area under the base to

prevent tangling.

5. Operating Instructions

5.1 Boiling Water

1. **Fill the Kettle:** Remove the lid and fill the kettle with the desired amount of cold water. Do not fill below the 'MIN' mark or above the 'MAX' mark on the water level indicator.
2. **Close the Lid:** Ensure the lid is securely closed before placing the kettle on its base.
3. **Place on Base:** Position the kettle firmly on the power base.
4. **Connect to Power:** Plug the power cord into a suitable wall outlet.
5. **Switch On:** Press the ON/OFF switch located at the bottom of the handle. The indicator light will illuminate, signifying that the kettle is heating.
6. **Automatic Shut-off:** The kettle will automatically switch off once the water has boiled, and the indicator light will turn off.
7. **Pour Water:** Carefully lift the kettle from its base and pour the hot water.

Note: *The kettle body may become hot during operation. Always use the handle when pouring.*

6. Maintenance

6.1 Cleaning the Exterior

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the finish.
- Ensure no water enters the electrical components.

6.2 Cleaning the Filter

- The removable filter in the spout should be cleaned regularly to prevent limescale buildup.
- Remove the filter by gently pulling it upwards.
- Rinse the filter under running water and brush it with a soft brush if necessary.
- Reinsert the filter into its slot until it clicks into place.

6.3 Descaling

Limescale buildup can affect the kettle's performance and lifespan, especially in hard water areas. Descale your kettle regularly (e.g., monthly or bi-monthly depending on water hardness).

1. Fill the kettle with a mixture of water and white vinegar (e.g., 1 part vinegar to 2 parts water) or a commercial

descaling solution according to product instructions.

2. Bring the mixture to a boil.
3. Allow the solution to soak in the kettle for at least 30 minutes, or longer for heavy buildup.
4. Discard the solution and rinse the kettle thoroughly several times with fresh water.
5. Boil fresh water in the kettle and discard it to remove any residual taste or odor from the descaling agent.

7. Troubleshooting

Problem	Possible Cause	Solution
Kettle does not turn on.	No power supply; Kettle not properly seated on base; Boil-dry protection activated.	Check power outlet; Ensure kettle is correctly placed on base; Allow kettle to cool down, then refill with water.
Water does not boil.	Insufficient water; Kettle not switched on.	Ensure water level is above 'MIN' mark; Press the ON/OFF switch.
Water has an unusual taste/odor.	New appliance residue; Limescale buildup.	Perform initial cleaning steps (boil and discard water several times); Descale the kettle.
Kettle switches off before boiling.	Excessive limescale buildup.	Descale the kettle thoroughly.

8. Technical Specifications

- **Model Name:** KBOV1200J-GR
- **Capacity:** 1.0 Liters
- **Material:** Plastic, Stainless Steel
- **Color:** Olive Green
- **Product Dimensions:** 8.27"L x 6.5"W x 9.25"H
- **Item Weight:** 1.87 pounds (0.85 Kilograms)
- **Cable Length:** 1.3 Meters
- **Power:** (Voltage and Wattage typically found on product label or base)

9. Warranty and Support

9.1 Warranty Information

This De'Longhi product is covered by a manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary by region. Please refer to the warranty card included with your product or visit the official De'Longhi website for detailed information.

9.2 Customer Support

For technical assistance, product registration, or to locate an authorized service center, please visit the De'Longhi official website or contact their customer service department. Contact details can typically be found in the product packaging or on the official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question