

[Manuals.plus](#) /

› [Faladesa](#) /

› Faladesa Ceiling Lamp User Manual

Faladesa 63-1079/3BLC

Faladesa Ceiling Lamp User Manual

Model: 63-1079/3BLC

PRODUCT OVERVIEW

The Faladesa Ceiling Lamp is a modern close-to-ceiling light fixture designed to provide illumination in various indoor settings. Featuring a metal base and a glass shade, this lamp is available in different colors to complement your decor. It is designed for ceiling mount installation and uses three E-27 bulbs (not included).



Figure 1: Front view of the Faladesa Ceiling Lamp, showcasing its glass shade and sleek design.

SETUP AND INSTALLATION

Before beginning installation, ensure the power supply to the installation area is turned off at the circuit breaker to prevent electrical shock. It is recommended that installation be performed by a qualified electrician.

- 1. Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the packing list (not provided in this manual) are present and undamaged.
- 2. Prepare Wiring:** Identify the live, neutral, and ground wires from your ceiling electrical box.
- 3. Mount Base:** Secure the lamp's metal base to the ceiling electrical box using appropriate mounting screws. Ensure the base is firmly attached and flush with the ceiling surface.
- 4. Connect Wiring:** Connect the lamp's wires to the corresponding house wires (live to live, neutral to neutral, ground to ground) using wire nuts. Ensure all connections are secure and insulated.
- 5. Install Bulbs:** This fixture requires three E-27 type bulbs. Insert the bulbs into the sockets. **Note: Bulbs are NOT INCLUDED.**
- 6. Attach Shade:** Carefully attach the glass shade to the metal base, securing it according to the fixture's design. Ensure it is stable and properly aligned.
- 7. Restore Power:** Once installation is complete and all components are securely in place, restore power at the circuit breaker.

For safety, always consult local electrical codes and regulations.

OPERATING INSTRUCTIONS

The Faladesa Ceiling Lamp operates via a standard wall switch connected to your home's electrical system. Simply toggle the wall switch to turn the lamp on or off.

- Turning On:** Flip the connected wall switch to the 'ON' position.
- Turning Off:** Flip the connected wall switch to the 'OFF' position.

This lamp is designed to be shock and vibration resistant, ensuring stable performance.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your Faladesa Ceiling Lamp.

- Cleaning:**

Before cleaning, ensure the lamp is turned off and cool to the touch. Use a soft, dry, or slightly damp cloth to wipe down the metal base and glass shade. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or glass.
- Bulb Replacement:**

When replacing bulbs, ensure the power to the fixture is turned off at the circuit breaker. Allow old bulbs to cool before removal. Replace with E-27 type bulbs of the correct wattage as specified for the fixture (max 60W per bulb, typical for E27). Do not exceed the recommended wattage.
- Inspection:**

Periodically inspect the wiring and connections for any signs of wear or damage. If any issues are found, consult a qualified electrician.

TROUBLESHOOTING

If you encounter issues with your Faladesa Ceiling Lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on.	- No power to the fixture. - Loose wiring connection. - Faulty bulb(s). - Faulty wall switch.	- Check circuit breaker and ensure it is in the 'ON' position. - Turn off power at the breaker and check all wire connections. Re-secure if loose. - Replace bulb(s) with new, working E-27 bulbs. - Test the wall switch. If faulty, replace it (consult an electrician).
Light flickers.	- Loose bulb. - Incorrect bulb type/wattage. - Loose wiring connection.	- Tighten bulb(s) in their sockets. - Ensure E-27 bulbs are used and wattage is within limits. - Turn off power at the breaker and check all wire connections.

If the problem persists after trying these solutions, please contact a qualified electrician.

SPECIFICATIONS




Figure 2: Dimensions and various color options for the Faladesa Ceiling Lamp.

Feature	Detail
Brand	Faladesa
Model Name	Lampara plafon. Ceiling lamp
Part Number	63-1079/3BLC
UPC	633653096504
Product Dimensions (L x W x H)	12.99" x 2.75" x 12.99" (33 cm x 7 cm x 33 cm)
Item Weight	1.5 Pounds (0.68 kg)

Feature	Detail
Material	Glass, Metal
Color	Glass (available in various colors)
Style	Modern
Light Fixture Form	Ceiling (Close To Ceiling Lights)
Power Source	Corded Electric
Light Source Type	E-27 (Bulbs NOT INCLUDED)
Number of Light Sources	3
Special Feature	Shock and vibration resistant
Mounting Type	Ceiling Mount
Specification Met	UL
Manufacturer	The Gallery Lighting and Design by DISTINLAMP

© 2024 Faladesa. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

