Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Villeroy & Boch 1953008131

Villeroy & Boch vivo Group Voice Basic Champagne Glass Set

Model: 1953008131

Introduction

This manual provides essential information for the Villeroy & Boch vivo Group Voice Basic Champagne Glass Set. These high-quality crystal glasses are designed for both everyday use and special occasions, offering a timeless and elegant form. Please read these instructions carefully to ensure proper handling, care, and longevity of your champagne glasses.



Image: The Villeroy & Boch vivo Group Voice Basic Champagne Glass Set, showcasing its elegant design.

Setup

1. **Unpacking:** Carefully remove the champagne glasses from their packaging. Inspect each glass for any signs of damage during transit.
2. **Initial Cleaning:** Before first use, wash the glasses thoroughly. Refer to the "Maintenance" section for detailed cleaning instructions.
3. **Placement:** Store glasses in a stable, secure location to prevent accidental tipping or breakage.

Operating (Usage)

The Villeroy & Boch vivo Group Voice Basic Champagne Glasses are designed for serving champagne and sparkling wines.

- **Holding:** Hold the glass by the stem to prevent warming the champagne with your hand and to maintain its chilled temperature.
- **Pouring:** Tilt the glass slightly and pour the champagne slowly down the side to minimize foam and preserve effervescence.
- **Serving Temperature:** Champagne is best served chilled, typically between 8-10°C (47-50°F).



Image: Champagne glasses in use, demonstrating their suitability for various occasions.

Maintenance and Care

Proper care ensures the longevity and pristine appearance of your crystal champagne glasses.

- **Dishwasher Safe:** These glasses are designed to be dishwasher safe. Place them securely in the dishwasher, ensuring they do not touch other items to prevent chipping or scratching. Use a gentle cycle and a mild detergent.
- **Hand Washing:** For best results and to maintain a long-lasting shine, hand washing is recommended. Use warm water, a mild dish soap, and a soft sponge or cloth.
- **Drying:** Dry immediately after washing with a lint-free cloth to prevent water spots and enhance shine. Avoid twisting the stem and bowl in opposite directions, as this can cause breakage.
- **Storage:** Store glasses upright in a cabinet or on a shelf where they are protected from dust and accidental knocks.




Image: Icons illustrating that the glasses are made of crystal glass and are dishwasher safe, highlighting key care features.



Image: Icons representing timeless design, easy care, and durability, reinforcing the product's quality and maintenance benefits.

Troubleshooting

- **Water Spots/Cloudiness:** If glasses appear cloudy or have water spots after washing, ensure they are dried immediately with a lint-free cloth. Hard water can contribute to mineral deposits; consider using a rinse aid in the dishwasher or a vinegar solution for hand washing.
- **Breakage:** Crystal glass, while durable, can break if subjected to sudden temperature changes or impact. Avoid pouring very hot liquids into cold glasses or vice versa. Handle with care during washing and storage.
- **Scratches:** To prevent scratches, avoid abrasive cleaning materials and ensure glasses do not rub against each other or other hard objects in the dishwasher or during storage.

Specifications

Brand	Villeroy & Boch

Model Number	1953008131
Material	Crystal Glass (Recyclable)
Color	Transparent
Capacity	283 Milliliters
Special Feature	Dishwasher Safe
Item Weight	0.65 Kilograms (for the set)
Individual Glass Dimensions	Approximately 7 cm (2.75 inches) width, 23 cm (9.05 inches) height
Number of Items	4 glasses
Reusability	Reusable



Image: A diagram illustrating the approximate dimensions of a single champagne glass: 23 cm height and 7 cm width at the base.

Warranty Information

Specific warranty details for the Villeroy & Boch vivo Group Voice Basic Champagne Glass Set are not provided in the product data. Please refer to the manufacturer's official website or contact their customer service for information regarding product warranties.

Support

For further assistance, questions, or concerns regarding your Villeroy & Boch vivo Group Voice Basic Champagne Glass Set, please contact Villeroy & Boch customer support directly.

- **Manufacturer:** Villeroy & Boch
- **Website:** www.villeroy-boch.com (Please visit the official website for contact details specific to your region.)

© 2024 Villeroy & Boch. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N1GQF9D

More documents and user manuals: **https://manuals.plus/**