Mattel FCW02

Mattel Disney Pixar Cars 3 Ultimate Florida Speedway Track Set Instruction Manual

Model: FCW02 | Brand: Mattel

Introduction

Welcome to the exciting world of the Disney Pixar Cars 3 Ultimate Florida Speedway Track Set! This playset brings the thrilling, climatic race from Disney Pixar Cars 3 right into your home. Designed for ages 4-8 years, this track set features a motorized booster, themed play areas, and a raised track for increased velocity, ensuring continuous racing action. Prepare for high-speed fun as your favorite Cars characters compete for victory.

Setup Instructions

Follow these steps to assemble your Ultimate Florida Speedway Track Set:

1. **Unboxing:** Carefully remove all components from the packaging. Ensure all parts listed in the product manual are present.
2. **Assembly:** The track pieces are designed for easy, click-together assembly. Follow the visual instructions provided in the included manual to connect the track sections, motorized booster, and themed play areas. While the product description mentions 'no assembly required' for some parts, the main track structure will need to be clicked together.
3. **Battery Installation:** The motorized booster requires 4 D batteries (not included). Locate the battery compartment on the booster unit, insert the batteries according to the polarity indicators, and secure the cover.
4. **Placement:** Due to its epic 5 feet length, ensure you have a large, flat surface for optimal setup and play. The track performs best on thin rugs or hard floors.



Figure 1: Top-down view of the fully assembled Ultimate Florida Speedway Track Set, showcasing its extensive layout and various play zones.

Operating Instructions

Experience the thrill of racing with your track set:

1. **Place Cars:** Position your 1:55 scale Disney Pixar Cars vehicles (one Lightning McQueen vehicle included) on the starting lines of the track. Ensure they are die-cast vehicles for best performance, as lighter plastic cars may not track as well.
2. **Activate Motorized Booster:** Turn on the motorized booster. This feature propels vehicles around the track at thrilling speeds, ensuring continuous play.
3. **Utilize the Diverter:** As cars race, use the diverter mechanism to switch lanes, adding strategic depth to the competition.
4. **Finish Line Action:** The track is designed for exciting finishes, with cars racing into the winner's circle.



Figure 2: A close-up view of a Lightning McQueen vehicle engaging with the motorized booster, ready to be propelled into the race.



Figure 3: Two children are shown enthusiastically interacting with the track set, highlighting the dynamic racing experience with multiple cars in motion.

Official Product Video

Video 1: Official demonstration of the Disney Pixar Cars 3 Ultimate Florida Speedway Track Set in action, showcasing its features and racing capabilities.

Maintenance

To ensure the longevity and optimal performance of your track set:

- **Cleaning:** Wipe down track surfaces and vehicles with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, disassemble the track and store it in its original packaging or a suitable container to prevent damage and loss of parts.
- **Battery Care:** Remove batteries from the motorized booster if the toy will not be used for an extended period to prevent leakage.

Troubleshooting

If you encounter any issues with your track set, consider the following:

- **Cars Not Moving:** Check if the motorized booster has fresh batteries and is turned on. Ensure cars are placed correctly on the track and are not obstructed.
- **Cars Falling Off Track:** Verify that all track connections are secure and the track is on a flat, stable surface. Ensure only appropriate 1:55 scale die-cast vehicles are used.
- **Track Noise:** Some noise from the motorized booster is normal during operation.

Specifications

Feature	Detail
Product Dimensions	4.25 x 30 x 24 inches
Item Weight	2.2 pounds
Item Model Number	FCW02
Manufacturer Recommended Age	4 - 8 years
Batteries Required	4 D batteries (not included)
Included Vehicle	1:55 scale Lightning McQueen
Special Features	Motorized booster, diverter, connects to other Cars 3 sets

Warranty and Support

For warranty information or product support, please refer to the contact details provided in the original product packaging or visit the official Mattel website. Keep your proof of purchase for any warranty claims.

© 2023 Mattel. All rights reserved. Disney/Pixar.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question