

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Wacom](#) /
- › [Wacom Intuos Pro Medium \(PTH-660\) Digital Pen Tablet User Manual](#)

Wacom PTH660

Wacom Intuos Pro Medium (PTH-660) Digital Pen Tablet User Manual

Model: PTH-660 | Brand: Wacom

1. INTRODUCTION

The Wacom Intuos Pro Medium (PTH-660) is a professional-grade digital pen tablet designed for artists, designers, and creative professionals. It offers an intuitive and natural pen-on-paper feel, enhancing your digital workflow with precision and control. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.



Figure 1: Wacom Intuos Pro Medium Digital Pen Tablet.

2. WHAT'S IN THE BOX

Upon unboxing your Wacom Intuos Pro Medium, ensure all the following components are present:

- Wacom Intuos Pro Medium Tablet
- Wacom Pro Pen 2 (with eraser)
- Pen Stand (includes 6 standard nibs, 4 felt nibs, and a color ring)
- Overlay Sheet Sample
- USB Cable (USB Type-C to USB)
- Quick Start Guide
- Regulation Sheet
- Warranty Card
- Online Manual & Important Product Information (IPI)



Figure 2: Included components of the Wacom Intuos Pro Medium tablet.

3. SETUP

Follow these steps to set up your Wacom Intuos Pro Medium tablet:

1. **Connect the Tablet:** Connect the tablet to your computer using the provided USB Type-C to USB cable. Alternatively, you can connect wirelessly via Bluetooth.
2. **Install Drivers:** Download and install the latest drivers for your operating system (Windows 7 or later, Mac OS X 10.10 or later) from the official Wacom website. Ensure the latest Service Pack is applied for Windows.
3. **Power On:** The tablet is powered via the USB connection or its internal Lithium Ion battery. Ensure it is sufficiently charged for wireless use.
4. **Customize Settings:** Open the Wacom Tablet Properties software (installed with the drivers) to customize pen settings, ExpressKeys, and Touch Ring functions according to your preferences.



Figure 3: Wacom Intuos Pro Medium connected and ready for use.

4. OPERATING THE TABLET

The Wacom Intuos Pro Medium offers various input methods for a versatile creative experience.

4.1. Wacom Pro Pen 2

The Wacom Pro Pen 2 utilizes electromagnetic induction for precise input. It features 8192 levels of pressure sensitivity, allowing for fine control over line weight and opacity, mimicking traditional art tools. The pen also includes an eraser function and customizable side buttons.

プロフェッショナルな編集も
思いのままに



Figure 4: Using the Wacom Pro Pen 2 for digital drawing.

4.2. ExpressKeys and Touch Ring

The tablet features customizable ExpressKeys and a Touch Ring for quick access to shortcuts and functions. These can be programmed via the Wacom Tablet Properties to streamline your workflow in various applications.

クリエイターの創造力をサポートする 多彩な機能でワークフローを効率化



ショートカットキー
を割当てできる
エクスプレスキーと
タッチホイール

Figure 5: Utilizing ExpressKeys and Touch Ring for efficient operation.

4.3. Multi-Touch Functionality

The tablet supports multi-touch gestures, allowing you to pan, zoom, and navigate your canvas using your fingers, similar to a smartphone or trackpad. This feature can be toggled on or off as needed.

5. CUSTOMIZATION

The Wacom Intuos Pro Medium offers extensive customization options to tailor the device to your personal workflow.

5.1. Software Settings

Use the Wacom Tablet Properties application to:

- Adjust pen pressure sensitivity and tilt response.
- Assign custom functions to the pen buttons and eraser.
- Program the ExpressKeys for application-specific shortcuts.
- Configure the Touch Ring for functions like zoom, brush size, or canvas rotation.


- Enable or disable multi-touch gestures.

5.2. Pen Customization

The Wacom Pro Pen 2 comes with various replacement nibs (standard and felt) stored within the pen stand. These allow you to customize the feel of the pen on the tablet surface. The color ring on the pen stand can also be used to personalize your pen.

Wacom Pro Pen 2 が付属している製品なら同じペンが
使用できます。

例えば自宅の Intuos Pro で作業して、職場の液タブで
続きを作業するという使い方ができます。



職場と自宅で同じペンが使用できる

Figure 6: Wacom Pro Pen 2 and its customizable components.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Wacom Intuos Pro Medium.

- **Cleaning:** Use a soft, lint-free cloth to gently wipe the tablet surface and pen. Avoid harsh chemicals or abrasive materials.
- **Nib Replacement:** If the pen nib becomes worn, use the nib removal tool (located in the pen stand) to carefully pull out the old nib and insert a new one.
- **Storage:** Store the tablet and pen in a safe place when not in use to prevent scratches or damage. The pen stand provides secure storage for the pen and extra nibs.

7. TROUBLESHOOTING

If you encounter issues with your Wacom Intuos Pro Medium, try the following:

- **No Pen Input:** Ensure the tablet is properly connected (USB or Bluetooth) and that the drivers are correctly installed and up-to-date. Restart your computer.
- **Inaccurate Cursor:** Recalibrate the pen in the Wacom Tablet Properties. Check for any interference from other electronic devices.
- **Multi-Touch Not Working:** Verify that multi-touch is enabled in the Wacom Tablet Properties.
- **ExpressKeys/Touch Ring Not Responding:** Check the settings in Wacom Tablet Properties to ensure they are correctly assigned and enabled.
- **Intermittent Connection:** Try a different USB port or cable. For Bluetooth, ensure the tablet is charged and within range.

8. SPECIFICATIONS

Feature	Specification
Model Number	PTH-660
Dimensions (L x W x H)	338 x 219 x 8 mm (13.31 x 8.62 x 0.31 inches)
Weight	0.7 kg (1.54 pounds)
Pen Input Method	Electromagnetic Induction
Scanning Resolution	Up to 0.005 mm
Pen Pressure Levels	8192 Levels
Connectivity	USB Type-C, Bluetooth
Operating System Compatibility	Windows 7 or later (latest SP applied), Mac OS X 10.10 or later
Special Feature	Multi-Touch Screen

ワコム製品ガイド

板型ペンタブレット シリーズ

One by Wacom®
Wacom® Intuos
Wacom® Intuos Pro



ワコム板型ペンタブレット比較			
	初めてのペンタブ向け	初心者向け	プロフェッショナル向け
			
	One by Wacom	Wacom Intuos	Wacom Intuos Pro
サイズ	Medium	Small, Medium	Small, Medium, Large
描き味	○ 思ったとおりに描ける	○ 思ったとおりに描ける	◎ さらにクリエイティブを追い求めた描き味
カスタマイズ	×	替え芯	替え芯、オーバーレイシート、オプションペン
カラー	● ブラック	● ブラック ● ビスタチオグリーン ● ベリーピンク	● ブラック
ワイヤレス	×	○*1	○
付属ソフトウェア**	CLIP STUDIO PAINT DEBUT	Corel® Painter® Essentials™ 7 (64bit) (90日ライセンス) Corel® Aftershot™ 3 (90日ライセンス) CLIP STUDIO PAINT PRO (2年ライセンス)	Adobe Premiere Pro (2ヶ月ライセンス) Adobe After Effects (2ヶ月ライセンス)

*1 Wacom Intuos Small ベーシックは非対応です。 *2 ダウンロードが必要です。機種により異なります。

Figure 7: Wacom Intuos Pro series size comparison.

9. OFFICIAL PRODUCT VIDEO

Video 1: Official Wacom video demonstrating digital and 3D art creation with Intuos Pro. This video highlights the tablet's responsiveness and integration into a creative workflow.

10. WARRANTY AND SUPPORT

Please note that this product is a Japan Import and may not include a manufacturer's warranty valid in your region. For support, please refer to the included Regulation Sheet and Warranty Card for specific details regarding your purchase.

For technical assistance, driver updates, and additional resources, please visit the official Wacom support website or contact their customer service in your region.

Online Manual and Important Product Information (IPI) are available digitally for further details.

