

TCL 43S405

TCL 43S405 43-Inch 4K Ultra HD Roku Smart LED TV User Manual

Model: 43S405 | Brand: TCL

INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your TCL 43S405 43-Inch 4K Ultra HD Roku Smart LED TV. This television combines 4K Ultra HD picture clarity with High Dynamic Range (HDR) technology for enhanced contrast and color. Featuring the Roku TV smart platform, it offers access to a vast library of streaming content and intuitive navigation.

Video: Overview of the TCL 43S405 4K Ultra HD Roku Smart TV.

WHAT'S IN THE BOX

- TCL 43S405 43-Inch 4K Ultra HD Roku Smart LED TV
- TV Stand (2 pieces)
- Remote Control
- 2 x AA Batteries
- Power Cord
- Quick Start Guide

SETUP

Physical Installation

Before proceeding, ensure the TV is placed on a stable surface or securely mounted. The TV can be placed on its included stand or mounted to a wall using a compatible VESA mount (VESA Hole Pattern: 3.93 inches (V) x 3.93 inches (H)).



Image: The TCL 43S405 4K Roku Smart LED TV displayed on a media console, illustrating its design with the included stand.

Initial Power-On and Network Connection

1. Connect the power cord to the TV and then to a power outlet.
2. Insert the included AA batteries into the remote control.
3. Press the power button on the remote to turn on the TV.
4. Follow the on-screen instructions to complete the initial Roku TV setup, including language selection and network connection.
5. Select your Wi-Fi network and enter the password to connect to the internet.

CONNECTIONS

The TCL 43S405 TV offers various ports for connecting external devices. These ports are typically located on the side and back of the television for easy access.



Image: Side view of the TCL 43S405 TV, highlighting the accessible input ports for various devices.

- **HDMI Ports:** Connect devices such as Blu-ray players, gaming consoles, and cable boxes. The TV features multiple HDMI inputs, including one with Audio Return Channel (ARC) support.
- **USB Port:** For connecting USB storage devices to play media files.
- **Ethernet Port:** For a wired internet connection, offering greater stability than Wi-Fi.
- **Cable/Antenna Input:** For connecting an antenna or cable TV feed.
- **AV In (Adapter):** For connecting older devices using composite video and stereo audio cables (adapter may be required).
- **Optical Digital Audio Out:** For connecting to a soundbar or home theater system for high-quality digital audio.
- **Headphone Output:** For connecting headphones for private listening.







Image: Rear view of the TCL 43S405 TV, providing a comprehensive look at all available input and output ports.

OPERATING INSTRUCTIONS

Roku TV Interface

The TCL 43S405 features the Roku TV operating system, providing a user-friendly interface for accessing streaming content and TV functions. The home screen displays your installed streaming channels, input selections, and quick access to settings.



Image: The TCL 43S405 TV screen showing the Roku TV home interface, with icons for various streaming applications and input sources.

Remote Control Navigation

Use the included remote control to navigate the Roku TV interface. The directional pad allows you to move between options, and the 'OK' button confirms selections. Dedicated buttons provide quick access to popular streaming

services and TV functions.

Smart Features

The TV is compatible with voice assistants like Alexa and Google Assistant, allowing for hands-free control of certain functions when integrated with a compatible smart home device.

PICTURE AND SOUND SETTINGS

Optimize your viewing and listening experience by adjusting the picture and sound settings. Access these options through the 'Settings' menu on the Roku TV home screen.

- **Picture Settings:** Adjust brightness, contrast, color, and sharpness. Select from predefined picture modes (e.g., Movie, Sports, Vivid) or customize your own. The TV supports 4K Ultra HD resolution and High Dynamic Range (HDR) for enhanced visual quality.
- **Sound Settings:** Adjust volume, bass, treble, and choose from various sound modes (e.g., Standard, Music, Movie). The TV features 2-channel x 8W audio power.
- **Refresh Rate:** The TV has a 120Hz refresh rate, which helps reduce motion blur in fast-moving scenes.

Video: Expert review highlighting key features and performance of the TCL S405 TV.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and TV cabinet. Avoid abrasive cleaners or solvents.
- **Ventilation:** Ensure adequate ventilation around the TV to prevent overheating. Do not block ventilation openings.
- **Software Updates:** The Roku TV system automatically checks for and installs software updates to ensure optimal performance and access to the latest features.

TROUBLESHOOTING

If you encounter issues with your TV, try the following basic troubleshooting steps:

- **No Power:** Check if the power cord is securely connected to both the TV and the power outlet. Ensure the outlet is functional.
- **No Picture/Sound:** Verify that the correct input source is selected. Check all cable connections to external devices.
- **Remote Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Network Connection Issues:** Restart your router and modem. Re-enter your Wi-Fi password in the TV's network settings.
- **General Performance Issues:** Perform a system restart from the Roku TV settings menu (Settings > System > Power > System restart).

For more detailed troubleshooting or persistent issues, refer to the full user manual available online or contact TCL customer support.

SPECIFICATIONS



Image: The TCL 43S405 TV with key dimensions (width, height, depth) clearly indicated for planning placement.

Feature	Detail
Model Number	43S405
Screen Size	43 Inches
Display Technology	LED
Resolution	4K Ultra HD
Refresh Rate	120 Hz
High Dynamic Range (HDR)	Supported
Smart TV Platform	Roku TV
Audio Power	2 Channel x 8W
Connectivity	HDMI, Wi-Fi, Ethernet, USB
Dimensions (without stand)	38.3" W x 22.2" H x 2.9" D

Dimensions (with stand)	38.3" W x 24.4" H x 7.5" D
Item Weight	16.8 Pounds
VESA Hole Pattern	3.93 inches (V) x 3.93 inches (H)

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official TCL support website. Keep your purchase receipt for proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question