

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Livoo](#) /

› [LIVO CLIPSONIC TEC589 Smartwatch User Manual](#)

Livoo TEC589

LIVO CLIPSONIC TEC589 Smartwatch User Manual

Model: TEC589 | Brand: Livoo

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your LIVO CLIPSONIC TEC589 Smartwatch. Please read this manual carefully before using the device to ensure proper functionality and to avoid damage. The LIVO CLIPSONIC TEC589 is a versatile smartwatch featuring a SIM card slot, Bluetooth connectivity, and various activity tracking functions. It is compatible with both iOS and Android devices, offering call management, contact synchronization, and multimedia capabilities.

PRODUCT OVERVIEW

Familiarize yourself with the components of your smartwatch.



Image: Front view of the LIVO CLIPSONIC TEC589 Smartwatch. The screen shows icons for Messages, Calls, Bluetooth, and BT Dialer, indicating its communication features.

Key Components:

- **1.54" Touch Screen:** For interactive control and display of information.
- **SIM Card Slot:** Allows for independent cellular functionality.
- **Memory Card Slot:** Supports up to 32GB for expanded storage.
- **Microphone:** For calls and voice commands.
- **Speaker:** For audio output during calls and media playback.
- **Power Button:** For turning the device on/off and screen control.
- **USB Charging Port:** For connecting the included USB charging cable.

SETUP

1. SIM Card Installation

The smartwatch supports a micro-SIM card for independent call and SMS functionality. Locate the SIM card slot, typically on the side or under the back cover. Carefully insert the SIM card with the gold contacts facing down, ensuring it clicks into place.

2. Memory Card Installation

To expand storage for music, photos, or other files, insert a microSD card (up to 32GB) into the designated memory card slot. Ensure the card is inserted correctly to avoid damage.

3. Charging the Device

Before first use, fully charge the smartwatch. Connect the included USB charging cable to the watch's charging port and a compatible USB power source (e.g., computer USB port or wall adapter). The screen will indicate charging status. A full charge typically takes 1-2 hours.

4. Power On/Off

To power on, press and hold the power button until the screen illuminates. To power off, press and hold the power button until the power-off options appear, then select "Power Off".

5. Bluetooth Pairing (for Smartphone Connectivity)

1. Ensure Bluetooth is enabled on both the watch and your smartphone.
2. On the smartwatch, navigate to the Bluetooth settings and enable Bluetooth.
3. Search for available devices on your smartphone.
4. Select "TEC589" or a similar device name from the list.
5. Confirm the pairing request on both devices if prompted.

For Android users, download the companion application (if available, check the manual or product packaging for QR code/name) to enable additional features like SMS reception, message reading, notification synchronization, and remote camera control.

OPERATING INSTRUCTIONS



Image: A user interacting with the LIVO CLIPSONIC TEC589 Smartwatch. The image demonstrates the touch screen functionality and how to navigate the watch's interface.

Navigation

The smartwatch features a 1.54-inch touch screen. Swipe left/right or up/down to navigate through menus and applications. Tap an icon to open an application or select an option.

1. Call Management

- **Making Calls:** Use the dialer application on the watch or select a contact from your synchronized phonebook (via Bluetooth or SIM card).
- **Receiving Calls:** When a call comes in, the watch will display the caller ID. Tap the green icon to answer or the red icon to reject.

2. Contact Synchronization

When connected via Bluetooth to your smartphone, the watch can synchronize your phone's contacts, allowing you to make calls directly from your wrist.

3. Activity Tracking

The smartwatch includes sensors to monitor daily activity:

- **Pedometer:** Tracks your steps taken throughout the day.
- **Calorie Counter:** Estimates calories burned based on your activity.
- **Sleep Quality Monitor:** Analyzes your sleep patterns.

Access these features through their respective applications on the watch. Data can often be viewed in more detail via the companion app on your smartphone (for Android users).



Image: A comprehensive view of the LIVO CLIPSONIC TEC589 Smartwatch's user interface, showcasing multiple watch faces and various application icons such as Pedometer, Sleep Monitor, Alarm, Calculator, Calendar, Settings, Camera, and Stopwatch.

4. Music Playback

You can play music stored on the inserted memory card or control music playback on your connected smartphone via Bluetooth.

5. Additional Functions

- **Alarm:** Set alarms for reminders.
- **Anti-Loss:** Alerts you if your connected phone moves too far away (requires companion app for Android).
- **Calculator:** Basic arithmetic functions.
- **Stopwatch:** For timing events.
- **Calendar:** View dates and schedule events.
- **Remote Camera Control (Android only):** Control your smartphone's camera remotely via the watch (requires companion

app).

- **SMS & Notifications (Android only):** With the companion app, receive and read SMS messages and other notifications directly on your watch. With a SIM card, you can send/receive SMS on both Android and iOS.

MAINTENANCE

Cleaning

Wipe the watch screen and body with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials, which can damage the finish or screen. The device is not waterproof; avoid exposure to water.

Battery Care

To prolong battery life, avoid extreme temperatures. Charge the device regularly and do not allow the battery to fully deplete for extended periods. Use only the provided charging cable.

TROUBLESHOOTING

Problem	Solution
Watch does not power on.	Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
Cannot pair via Bluetooth.	<ul style="list-style-type: none">• Ensure Bluetooth is enabled on both the watch and your smartphone.• Make sure the devices are within close proximity.• Restart both devices and try pairing again.• Clear previous Bluetooth connections on your phone if necessary.
SIM card not detected.	<ul style="list-style-type: none">• Ensure the SIM card is inserted correctly and fully seated in its slot.• Check if the SIM card is active and functional in another device.• Restart the smartwatch.
Notifications not received (Android).	<ul style="list-style-type: none">• Ensure the companion application is installed and running on your Android phone.• Verify that notification access is granted to the app in your phone's settings.• Check Bluetooth connection status.
Touch screen unresponsive.	Restart the smartwatch. If the issue persists, contact customer support.

SPECIFICATIONS

Model: TEC589

Brand: Livoo (CLIPSONIC)

Screen: 1.54 inches, Touch Screen

Operating System Compatibility: Android, iOS

Connectivity: Bluetooth, Cellular (with SIM card)

SIM Card Slot: Yes

Memory Card Slot: Yes, supports up to 32GB (MicroSD)

Battery: Lithium-ion (included)

Special Features: Alarm, Pedometer, Calorie Counter, Sleep Monitor, Calculator, Stopwatch, Calendar, Anti-loss (Android app dependent), Remote Camera Control (Android app dependent).

Color: Black and Metal

Charging: USB cable (included)

WARRANTY AND SUPPORT

Information regarding specific warranty terms and conditions for the LIVOCLIPSONIC TEC589 Smartwatch is not available in this document. Please refer to the warranty card included with your product or contact the retailer/manufacturer directly for details on warranty coverage and customer support.

For technical assistance or further inquiries, please visit the official Livoo or Clipsonic website, or contact their customer service department.