

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Alverlamp](#) /

› [Alverlamp LSFI0414W LED Spherical Filament Bulb 4W E14 6000K User Manual](#)

Alverlamp LSFI0414W

Alverlamp LSFI0414W LED Spherical Filament Bulb User Manual

Model: LSFI0414W

INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your Alverlamp LSFI0414W LED Spherical Filament Bulb. Please read these instructions carefully before use and retain them for future reference.

The Alverlamp LSFI0414W is a 4-watt LED bulb with an E14 base, offering a 6000K cool white light. It features a spherical filament design and is dimmable, providing versatile lighting options for various environments.

SAFETY INSTRUCTIONS

Always follow basic safety precautions when installing or using electrical products to reduce the risk of fire, electric shock, and personal injury.

- **Power Disconnection:** Ensure the power supply is switched off at the main circuit breaker before installing or replacing the bulb.
- **Correct Base:** Only use this bulb in fixtures designed for an E14 base.
- **Voltage Compatibility:** Verify that the fixture's voltage rating matches the bulb's requirements.
- **Indoor Use:** This bulb is designed for indoor use in dry locations unless otherwise specified by the fixture.
- **Heat:** LED bulbs generate less heat than traditional incandescent bulbs, but they can still be warm to the touch. Allow the bulb to cool before handling.
- **Dimmer Compatibility:** As this bulb is dimmable, ensure your dimmer switch is compatible with LED technology to avoid flickering or damage. Consult your dimmer's manual for compatibility.
- **Disposal:** Dispose of used bulbs according to local regulations.

SETUP AND INSTALLATION

Follow these steps to safely install your Alverlamp LSFI0414W LED bulb:

1. **Turn Off Power:** Locate the light fixture's power switch and turn it to the "OFF" position. For added safety, turn off the power at the main circuit breaker.
2. **Remove Old Bulb (if applicable):** If replacing an existing bulb, allow it to cool completely before carefully unscrewing it counter-clockwise from the E14 socket.
3. **Insert New Bulb:** Gently screw the Alverlamp LSF10414W bulb clockwise into the E14 socket until it is snug. Do not overtighten.
4. **Restore Power:** Turn the power back on at the main circuit breaker, then use the light fixture's switch to turn on the light.



Image: Alverlamp LSF10414W LED Spherical Filament Bulb. This image shows the bulb's spherical shape and E14 screw base, ready for installation into a compatible light fixture.

OPERATING INSTRUCTIONS

The Alverlamp LSF10414W LED bulb operates like a standard light bulb but offers dimming capabilities.

- **Turning On/Off:** Use the standard wall switch connected to your light fixture to turn the bulb on or off.
- **Dimming Function:** If installed in a fixture connected to a compatible LED dimmer switch, you can adjust the light intensity by operating the dimmer control. Ensure your dimmer is specifically designed for LED bulbs to prevent performance issues.

MAINTENANCE

The Alverlamp LSF10414W LED bulb requires minimal maintenance.

- **Cleaning:** Before cleaning, ensure the power is off and the bulb is cool. Wipe the bulb gently with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Replacement:** LED bulbs have a long lifespan. Replace the bulb only when it reaches the end of its operational life.

TROUBLESHOOTING

If you encounter issues with your Alverlamp LSF10414W LED bulb, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bulb does not light up.	<ul style="list-style-type: none">No power to the fixture.Bulb not screwed in properly.Bulb is faulty.	<ul style="list-style-type: none">Check power supply and circuit breaker.Ensure bulb is securely screwed into the socket.Test the bulb in another working fixture or replace it.
Bulb flickers or hums.	<ul style="list-style-type: none">Incompatible dimmer switch.Loose connection.	<ul style="list-style-type: none">Ensure dimmer is compatible with LED bulbs. Replace if necessary.Tighten the bulb in the socket.
Light output is too low or inconsistent.	<ul style="list-style-type: none">Dimmer setting too low.Bulb nearing end of life.	<ul style="list-style-type: none">Adjust dimmer to a higher setting.Replace the bulb.

SPECIFICATIONS

Feature	Detail
Model Number	LSF10414W
Brand	Alverlamp
Type	LED Spherical Filament Bulb
Wattage	4 Watts
Bulb Base	E14
Color Temperature	6000 Kelvin (Cool White)
Special Feature	Dimmable
Number of Units	1.0 Count

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Alverlamp website. Keep your proof of purchase for any warranty claims.

