

EcoPure EPW2F

EcoPure EPW2F Premium Universal Whole Home Carbon Filter Instruction Manual

Model: EPW2F

Brand: EcoPure

1. PRODUCT OVERVIEW

The EcoPure EPW2F Premium Universal Whole Home Carbon Filter is designed to deliver cleaner, clearer, and better-tasting water throughout your entire home. Utilizing advanced FACT (Flow and Capture Technology) media, this filter provides superior filtration without significantly reducing water flow.

This premium carbon filter is NSF certified to effectively reduce chlorine taste and odor, sediment, sand, silt, and rust. With a micron rating of less than 1, it captures even the smallest contaminants, making it suitable for both municipal and well water supplies. The EPW2F filter is engineered for an extended lifespan, lasting up to 6 months, which is double the duration of many standard whole home carbon filters.

The universal design ensures compatibility with EcoPure models EPW2VC, EPW2, and most standard capacity whole home water filtration systems from various brands, including Whirlpool, Omni, Culligan, Watts, Filtrete, 3M, GE, and DuPont.

Find the Right Whole Home Filter

				
BEST	BETTER	GOOD	GOOD	GOOD
EPW2F	EPW2C	EPW2B	EPW2S	EPW2P
Premium Carbon Filter	Carbon Filter	Melt Blown Filter	String Wound	Pleated Filter
Micron Size: <1	Micron Size: 5	Micron Size: 5	Micron Size: 10	Micron Size: 30
Reduces Chlorine (Taste & Odor) & Sediment	Reduces Chlorine (Taste & Odor) & Sediment	Reduces Sediment	Reduces Sediment	Reduces Sediment
Filter Life: 6 months	Filter Life: 3 months	Filter Life: 3 months	Filter Life: 3 months	Filter Life: 3 months

Figure 1: EcoPure EPW2F Premium Universal Whole Home Carbon Filter.




Figure 2: Product packaging for the EcoPure EPW2F filter.

2. INSTALLATION INSTRUCTIONS

These instructions outline the general procedure for replacing a whole home water filter. Always refer to your specific filter housing manual for detailed safety and installation guidelines.

1. **Turn Off Water Supply:** Locate the main water shut-off valve for your home and turn it off.
2. **Relieve Pressure:** Open a nearby cold water faucet to relieve pressure in the system.
3. **Open Filter Housing:** Use the provided wrench (if applicable) to unscrew and remove the filter housing sump.
4. **Remove Old Filter:** Carefully remove the old filter cartridge and dispose of it according to local regulations.
5. **Clean Housing:** Clean the inside of the filter housing sump with warm, soapy water. Rinse thoroughly. Inspect and lubricate the O-ring with silicone grease if necessary.
6. **Insert New Filter:** Unwrap the new EcoPure EPW2F filter. Ensure the filter is correctly oriented (if directional) and carefully insert it into the housing sump.
7. **Secure Housing:** Screw the filter housing sump back onto the cap, hand-tightening it first, then using the wrench for a snug fit (do not overtighten).
8. **Restore Water Supply:** Slowly turn the main water supply back on.
9. **Check for Leaks:** Monitor the filter housing for any leaks. If leaks occur, turn off the water, relieve pressure, and re-tighten the housing.
10. **Flush System:** Run cold water from a nearby faucet for several minutes to flush out any air or carbon fines from the new filter.



Figure 3: Examples of compatible filter systems.



Figure 4: Various filter housings compatible with EcoPure filters.

3. OPERATION

Once properly installed, the EcoPure EPW2F filter operates automatically as water flows through your home's main water line. The filter continuously works to reduce impurities, providing filtered water to all faucets and appliances.

- **Flow Rate:** The filter is designed to maintain a water flow rate of approximately 1 gallon per minute (GPM).
- **Filter Life:** The EPW2F filter has a rated lifespan of up to 6 months, depending on water quality and usage.

4. MAINTENANCE AND FILTER REPLACEMENT

Regular maintenance, primarily filter replacement, is crucial for optimal performance of your whole home filtration system. The EcoPure EPW2F filter should be replaced every 6 months or sooner if you notice a significant drop in water pressure or a return of chlorine taste and odor.

When to Replace Your Filter:

- Every 6 months under normal conditions.
- If water flow significantly decreases.
- If you detect chlorine taste or odor in your water.
- If water appears cloudy or contains visible sediment.

Follow the installation instructions (Section 2) in reverse to remove the old filter and install a new one.

100 Years of Innovation

Since 1925, we've led the way in smarter, more sustainable home water solutions.



Figure 5: EcoPure filter comparison, highlighting EPW2F's 6-month filter life.

5. TROUBLESHOOTING

If you encounter issues with your EcoPure EPW2F filter, consult the following common troubleshooting steps:

Problem	Possible Cause	Solution
Reduced Water Flow	Clogged filter cartridge	Replace the filter cartridge (refer to Section 4).
Water has taste/odor	Filter cartridge is exhausted	Replace the filter cartridge (refer to Section 4).
Leaking from filter housing	Improperly seated O-ring or loose housing	Turn off water, relieve pressure, check O-ring for damage or proper seating, re-tighten housing.
Visible sediment in water	Filter cartridge is exhausted or damaged	Replace the filter cartridge (refer to Section 4).

6. SPECIFICATIONS

- **Model Number:** EPW2F
- **Filter Type:** Premium Carbon Filter with FACT Media
- **Micron Rating:** <1 micron
- **Filter Life:** Up to 6 months
- **Reduces:** Chlorine taste & odor, sediment, sand, silt, dirt, rust
- **Material:** Carbon Fiber
- **Item Weight:** 0.5 Pounds (8 ounces)
- **Product Dimensions:** 2.75 x 5.5 x 9.75 inches
- **External Testing Certification:** NSF

- **Compatible Water Purifier Models:** EcoPure EPW2VC, EPW2; Aquasana WH-1000, GE GNSV70R, Whirlpool WHKF-GD05, and most standard capacity whole home systems.
- **Included Components:** 2 EPW2F Filters (per pack)
- **UPC:** 819561011550

7. WARRANTY AND SUPPORT

For specific warranty information regarding your EcoPure EPW2F Premium Universal Whole Home Carbon Filter, please refer to the documentation included with your original purchase or visit the official EcoPure website. EcoPure products are manufactured by Water Channel Partners.

For additional support, product information, or to explore other EcoPure water solutions, please visit the [EcoPure Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question