

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [OXO](#) /

> [OXO Good Grips 2-in-1 Salt & Pepper Grinder & Shaker Instruction Manual](#)

OXO 11187100

OXO Good Grips 2-in-1 Salt & Pepper Grinder & Shaker

Model: 11187100

INTRODUCTION

The OXO Good Grips 2-in-1 Salt & Pepper Grinder & Shaker combines two essential seasoning tools into one convenient design. This versatile kitchen gadget allows you to shake salt from the top and grind fresh pepper from the base, offering both functionality and ease of use. It features a durable, non-corrosive ceramic grinder that will not absorb flavors or odors, ensuring pure seasoning every time. The unit comes pre-filled with black peppercorns and granulated salt, ready for immediate use.

Key Features:

- Dual functionality: Salt shaker on top, pepper grinder on bottom.
- Adjustable grind-selector with 5 settings for fine to coarse pepper.
- Non-corrosive ceramic grinder for consistent performance.
- Easy to refill salt and peppercorn chambers.
- Durable construction with plastic and stainless steel components.

PRODUCT OVERVIEW

The OXO Good Grips 2-in-1 Grinder & Shaker is designed for intuitive use and durability. The clear body allows you to easily monitor salt and peppercorn levels.





The OXO Good Grips 2-in-1 Salt & Pepper Grinder & Shaker, showcasing its clear body and dual chambers.

Components:

- **Salt Shaker Top:** Stainless steel cap with holes for dispensing salt.
- **Salt Chamber:** Upper clear compartment for granulated salt.
- **Pepper Grinder Body:** Lower clear compartment for peppercorns, featuring the ceramic grinding mechanism.

- **Grind Selector:** Located at the base, allowing adjustment of pepper coarseness.
- **Base:** Stainless steel base for stability and housing the grind selector.

SETUP AND REFILLING

The Grinder & Shaker comes pre-filled, but refilling is simple when needed.

Refilling Salt

1. Unscrew the stainless steel cap from the top of the unit.
2. Pour granulated salt into the upper clear chamber.
3. Securely screw the cap back onto the unit.





Refilling the salt chamber by unscrewing the top cap.

Refilling Peppercorns

1. Remove the entire salt chamber from the top of the unit by pulling it upwards.
2. Pour whole peppercorns into the lower clear chamber.
3. Align and firmly press the salt chamber back into place until it clicks securely.



Refilling the peppercorn chamber by removing the salt chamber.

OPERATING INSTRUCTIONS

Using your OXO 2-in-1 Grinder & Shaker is straightforward.

Shaking Salt

To dispense salt, simply hold the unit with the salt shaker top facing downwards and shake gently over your food. The pre-drilled holes in the stainless steel cap will release the salt.



Shaking salt from the top of the unit.

Grinding Pepper

1. Invert the unit so the pepper grinder base is facing downwards.
2. Twist the salt shaker top (which acts as a knob) to activate the ceramic grinder.
3. Continue twisting until the desired amount of freshly ground pepper is dispensed.

Adjusting Grind Coarseness

The pepper grinder features a grind-selector at its base, allowing you to choose from 5 different settings, from fine to coarse.

1. Locate the small lever or indicator at the bottom of the grinder.
2. Slide the lever to the desired setting. Smaller dots typically indicate a finer grind, while larger dots

indicate a coarser grind.



Adjusting the grind coarseness using the selector at the base.

Official Product Video

This video demonstrates the features and operation of the OXO Good Grips 2-in-1 Salt & Pepper Grinder & Shaker, including how to shake salt, grind pepper, and adjust the grind settings.

MAINTENANCE AND CARE

Proper care will ensure the longevity and performance of your Grinder & Shaker.

- **Cleaning:** The unit is **not dishwasher safe**. Hand wash all components with warm, soapy water. Rinse thoroughly and dry completely before reassembling or refilling.
- **Storage:** Store in a cool, dry place away from direct sunlight to maintain the freshness of your salt and peppercorns.
- **Grinder Mechanism:** The ceramic grinder is designed to be non-corrosive and resist absorbing flavors. Avoid using abrasive cleaners or tools that could damage the mechanism.

TROUBLESHOOTING

If you encounter any issues with your Grinder & Shaker, consider the following:

- **No Salt Dispensing:** Ensure the salt chamber is filled and the top cap is clear of any blockages.
- **No Pepper Grinding:** Check that the peppercorn chamber is filled and the salt chamber (acting as the grinding knob) is securely attached and being twisted correctly. Ensure no large debris is obstructing the grinding mechanism.
- **Inconsistent Grind:** Verify that the grind selector at the base is set to your desired coarseness and is not stuck between settings.

SPECIFICATIONS





Product dimensions for the OXO 2-in-1 Grinder & Shaker.

Feature	Detail
Brand	OXO
Model Number	11187100
Material	Plastic, Stainless Steel
Color	Silver
Product Dimensions	2.5"W x 6.5"H
Item Weight	0.22 Kilograms
Operation Mode	Manual
Recommended Uses	Kitchen
Dishwasher Safe	No
UPC	719812048727

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please visit the official OXO website or contact their customer service department. Keep your purchase receipt for any warranty claims.

Contact Information:

- **Website:** www.oxo.com
- Refer to product packaging for specific customer service contact details.

