Hyperkin M07232

Hyperkin NES Controller to NES Classic Edition Adapter

Model: M07232

Introduction

The Hyperkin NES Controller to NES Classic Edition Adapter allows you to connect your original NES controllers, including joysticks, to your NES Classic Edition console. This adapter provides a convenient way to utilize your classic peripherals with modern retro gaming systems, enhancing your gaming experience with familiar controls.



Image: The Hyperkin NES Controller to NES Classic Edition Adapter shown alongside its retail packaging, highlighting its compact design and purpose.

Setup and Installation

1. **Identify Ports:** Locate the controller ports on your NES Classic Edition console. These are typically on the front of the console.
2. **Connect Adapter to Console:** Plug the smaller, rectangular end of the Hyperkin NES Controller to NES Classic Edition Adapter into an available controller port on your NES Classic Edition console. Ensure it is fully inserted.
3. **Connect NES Controller to Adapter:** Take your original NES controller or compatible joystick and plug its connector into the 9-pin D-sub port on the Hyperkin adapter. This port is designed to accept standard NES controller plugs.
4. **Power On Console:** Once both connections are secure, power on your NES Classic Edition console.
5. **Controller Recognition:** The console should automatically recognize the connected NES controller through the adapter.

The adapter features a 6-inch cable for flexible placement. It is compatible with most original NES controllers and joysticks.



Image: A visual representation of the Hyperkin adapter connecting an original NES controller to the NES Classic Edition console, demonstrating the setup process.

Operating Instructions

Once the Hyperkin NES Controller to NES Classic Edition Adapter is properly connected, your original NES controller will function as a standard controller for the NES Classic Edition. No additional drivers or software are required.

- **Basic Functionality:** All standard buttons (D-pad, A, B, Start, Select) on your NES controller will map directly to their corresponding functions on the NES Classic Edition.
- **Joystick Compatibility:** The adapter supports NES joysticks, allowing for an authentic arcade-style experience with compatible games.
- **Multiplayer:** For two-player games, ensure both player ports on the NES Classic Edition console have an adapter and controller connected.

Maintenance

To ensure the longevity and optimal performance of your Hyperkin NES Controller to NES Classic Edition Adapter, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the adapter. Avoid using liquid cleaners or abrasive materials, as these can damage the device.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Handling:** Always grasp the plug when connecting or disconnecting the adapter from the console or controller. Avoid pulling on the cable, as this can damage internal wiring.

Troubleshooting

Problem	Possible Cause / Solution
Controller not responding or intermittent functionality.	**Connection Issue:** Ensure both ends of the adapter are fully and securely plugged into the NES Classic Edition console and the NES controller. **Console Power Cycle:** If the controller is not recognized, try completely powering off your NES Classic Edition console, then plugging in the adapter and controller, and powering the console back on. **Controller Compatibility:** While generally compatible, some specific third-party or modified NES controllers may not function optimally. Test with an official NES controller if possible.
NES Advantage joystick or similar advanced controllers not working correctly (e.g., simultaneous button presses fail).	**Power Requirements:** Some older, more complex NES controllers (like the NES Advantage) may require a full 5V power source, which the NES Classic Edition's 3V logic might not consistently provide. **Player Port Sensitivity:** Some users have reported better success with the NES Advantage when connected to the Player 2 port, or by ensuring all turbo/slow buttons are off before connecting. **Limited Functionality:** Due to voltage differences, full functionality for all features (e.g., turbo functions) on certain vintage controllers may not be guaranteed.
Adapter does not work with WiiMote or Wii U.	**Intended Use:** This adapter is specifically designed for the NES Classic Edition console. It is not intended for use with WiiMotes, Wii U, or other Nintendo systems, as they operate on different voltage and communication protocols.

Specifications

Feature	Detail
Model Number	M07232
ASIN	B01N3LNI3Q
Compatibility	NES Classic Edition console, Original NES controllers (including joysticks)

Feature	Detail
Cable Length	6 inches
Item Weight	1.58 ounces (approx. 45 grams)
Package Dimensions	6.4 x 1.8 x 1.2 inches
Manufacturer	Hyperkin
Release Date	November 9, 2016

Warranty and Support

This Hyperkin product comes with a**1 Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For technical support, warranty claims, or further inquiries, please visit the official Hyperkin website or contact their customer service department. Keep your proof of purchase for warranty validation.

Manufacturer: Hyperkin

For the most up-to-date support information, please refer toHyperkin's official website.

© 2024 Hyperkin. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question