Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Outsunny 84C-020

Outsunny 20 x 40 ft Heavy Duty Party Tent Instruction Manual

Model: 84C-020

Brand: Outsunny

Important Safety Information

This tent is designed for temporary use and should not be left unattended for extended periods, especially during adverse weather conditions. Proper anchoring is crucial for stability.

- Do not leave the canopy up overnight or under bad weather conditions (e.g., heavy rain, strong winds, snow).
- Assembly requires 4-6 people for safety and efficiency.
- Ensure all connections are secure and ropes are properly tensioned.
- Always use ground stakes and additional weights (like sandbags) to secure the tent, especially on hard surfaces or in windy conditions.
- Keep away from open flames and heat sources.

Product Overview

The Outsunny 20 x 40 ft Heavy Duty Party Tent is a versatile outdoor shelter designed for various events such as wedding receptions, birthday parties, graduation celebrations, and barbecues. It features a robust galvanized steel frame and a durable, UV-blocking canopy with removable sidewalls and windows.




Figure 1: Outsunny 20 x 40 ft Heavy Duty Party Tent, fully assembled.

Key Features

- **Upgraded Galvanized Frame:** Constructed with 38 mm diameter and 0.7 mm thick galvanized steel for enhanced durability and resistance to rust and corrosion.
- **Reinforced for Maximum Stability:** Designed with top triangular brackets, extra side beams, and a strengthened base frame for superior wind resistance and improved load capacity.
- **UV-Blocking Canopy:** Sun-filtering canopy controls sun exposure, providing a cool and protected environment.
- **Removable Sidewalls & Windows:** Features stylish cathedral-style windows that allow natural light while minimizing glare. Sidewalls are removable for an open, breezy setup.
- **Double Zippered Doors:** Two zippered doors offer quick access and improved airflow.




Figure 2: Close-up of the heavy-duty galvanized steel frame and connectors.



Figure 3: View of the tent's windows and zippered doors.

Setup Guide

Setting up the Outsunny Party Tent requires careful attention to detail and the assistance of 4-6 people. Plan for several hours for initial assembly.

Unpacking and Component Identification

Carefully unpack all components and verify against the parts list provided in your packaging. Ensure all galvanized steel poles, connectors, canopy sections, and sidewalls are present and undamaged.

Frame Assembly

1. Lay out the base frame components on a flat, clear surface.
2. Connect the horizontal and vertical poles using the provided connectors, ensuring all snap pins are securely

engaged.

3. Assemble the roof truss sections on the ground.
4. With the help of others, carefully lift the assembled frame sections and connect them to form the complete structure.




Figure 4: Initial assembly of the tent's galvanized steel frame components.

Canopy and Sidewall Installation

1. Drape the main canopy cover over the assembled frame, ensuring it is centered and evenly distributed.
2. Secure the canopy to the frame using the bungee ties or straps provided.
3. Attach the sidewalls to the frame using the integrated Velcro straps. Ensure the zippered doors are positioned as desired.



Figure 5: Attaching the sidewalls, showing the window design.

Securing the Tent

For optimal stability, especially in varying weather conditions, secure the tent using the provided ground stakes and guy ropes. For hard surfaces, consider using additional weights like sandbags or water barrels tied to the poles.




Figure 6: Illustration of securing the tent with spiral ground stakes and ropes.

Official Setup Videos

Watch these official videos from Outsunny for a visual guide on setting up your tent:

Your browser does not support the video tag.

Video 1: Outsunny 20' x 40' Heavy Duty Party Tent & Carport - A visual guide to the tent's features and assembly process.

Your browser does not support the video tag.

Video 2: Outsunny 20' x 40' Large Party Tent Wedding & Carport with Removable Sidewalls and Double Doors - Demonstrates the tent's versatility and removable components.

Operating Instructions

Usage Recommendations

This tent is ideal for temporary outdoor gatherings and provides ample space for guests and activities. Its design allows for flexibility in setup, adapting to various event needs.

- Perfect for wedding receptions, birthday parties, graduation celebrations, and barbecues.
- Can also serve as a carport or for backyard storage to protect vehicles, furniture, and tools.



Figure 7: The tent configured for an outdoor event with seating.

Ventilation and Light

The tent's design allows for customizable ventilation and natural light:

- Utilize the two zippered doors for quick access and to create cross-ventilation.
- Remove sidewalls to transform the tent into an open, breezy gazebo, ideal for warmer weather.
- The stylish windows allow for bright interiors while minimizing direct sun glare.

Maintenance and Care

Cleaning

To prolong the life of your tent, regular cleaning is recommended:

- Clean the canopy and sidewalls with mild soap and water. Avoid harsh chemicals or abrasive cleaners.
- Rinse thoroughly and allow all fabric components to dry completely before storage to prevent mildew.
- Wipe down the galvanized steel frame with a damp cloth to remove dirt and debris.

Storage

When not in use, proper storage will protect your tent:

- Disassemble the tent by reversing the setup steps.
- Ensure all components are clean and completely dry before packing.
- Store poles, connectors, canopy, and sidewalls in their original packaging or suitable protective bags in a cool, dry place.

Troubleshooting

Stability Issues

If the tent feels unstable, review the following:

- Verify all frame connections are fully engaged and secure.
- Ensure ground stakes are fully inserted and guy ropes are taut.
- Add additional weight to the tent legs, especially in windy conditions.

Water Accumulation

If water pools on the canopy:

- Check that the canopy is stretched tightly and evenly over the frame to prevent sagging.
- Ensure proper tensioning of all ropes and straps.

Damaged Components

For any damaged or missing parts:

- Contact Outsunny customer support for assistance with replacement parts.

Specifications

Attribute	Detail
Brand	Outsunny

Model Number	84C-020
Overall Dimensions	472.5" L x 236.25" W x 126" H (20' x 40' x 10.5')
Eaves Height	78.75" H
Material	Alloy Steel, Polyethylene (PE)
Frame Material	Alloy Steel (Galvanized, 38mm diameter, 0.7mm thick)
Water Resistance Level	Water Resistant
Ultraviolet Light Protection	Yes
Item Weight	363 Pounds
Coverage	776 sq.ft
UPC	842525104456

Warranty and Support

Warranty Information

For specific warranty details, please refer to the documentation included with your purchase or contact Outsunny customer support directly. Standard return policies typically apply.

Customer Support

Should you require assistance with assembly, parts, or general inquiries, please contact Aosom Direct, the seller, or visit the official Outsunny store for support.

- **Seller:** Aosom Direct
- **Outsunny Store:** Visit the Outsunny Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N4PVZR2

More documents and user manuals: **https://manuals.plus/**