



Manuals.plus /

› Kinetic Sand /

› Kinetic Sand Single Container (4.5 oz, Green) Instruction Manual

## Kinetic Sand B01N4V1JWS

# Kinetic Sand Single Container (4.5 oz, Green) Instruction Manual

### INTRODUCTION

---

Kinetic Sand is a unique moldable play sand designed for creative expression. This 4.5 oz container of green Kinetic Sand provides a tactile and engaging experience, stimulating creativity without the mess of traditional sand. It is made from 100% natural sand, never dries out, and is wheat, gluten, and casein free.

### SETUP

---

- Unpack the Kinetic Sand from its container.
- Ensure a clean, dry play surface for optimal use.
- Kinetic Sand is ready to use directly from the container; no preparation is required.

### OPERATING INSTRUCTIONS

---

Kinetic Sand can be molded, sculpted, and stretched. Its unique properties allow it to stick to itself, making it easy to shape and clean.

- **Molding:** Press the sand firmly into molds or shape it with your hands to create various forms.
- **Sculpting:** Use tools or your fingers to sculpt and create detailed designs.
- **Sensory Play:** Enjoy the unique texture as it flows and oozes through your fingers, providing a calming and engaging sensory experience.



Image: A pile of green Kinetic Sand, demonstrating its loose yet cohesive texture.



Image: Green Kinetic Sand molded into a castle shape, showcasing its moldability.

- **Storage:** Store Kinetic Sand in its original container or an airtight container to keep it clean and free from dust. While it never dries out, proper storage helps maintain its quality.
- **Cleaning:** If sand falls onto a surface, press a larger piece of Kinetic Sand onto the scattered bits to pick them up. It sticks to itself, making cleanup simple.
- **Avoid Water:** Do not mix Kinetic Sand with water, as this can alter its unique properties.

## TROUBLESHOOTING

---

- **Sand feels dry or less cohesive:** Kinetic Sand is designed not to dry out. If it feels less cohesive, ensure it has not been exposed to excessive humidity or water. Kneading it for a few minutes can often restore its original texture.
- **Sand got wet:** If Kinetic Sand accidentally gets wet, spread it out on a dry surface and allow it to air dry completely. Its properties should return once dry.

## SPECIFICATIONS

---

- **Brand:** Kinetic Sand
- **Model:** B01N4V1JWS
- **Color:** Green
- **Weight:** 4.5 oz (127g)
- **Age Range:** 3+ years
- **Material:** 100% Natural Sand (with binding agents), Plastic (container)
- **Special Features:** Squeezable, moldable, sticks to itself, never dries out, wheat/gluten/casein free.

## SAFETY INFORMATION

---

- **Choking Hazard:** Contains small parts. Not for children under 3 years.
- **Not for Consumption:** Kinetic Sand is a play material and is not intended for eating.

## WARRANTY AND SUPPORT

---

This product is covered by the Spin Master Care Commitment. For details regarding warranty, returns, or customer support, please refer to the manufacturer's official website or contact their customer service department directly.