Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HUDORA 205

HUDORA 205 Adult Kick Scooter Instruction Manual

Model: 205

Introduction and Safety Information

This manual provides essential instructions for the safe assembly, operation, and maintenance of your HUDORA 205 Adult Kick Scooter. Please read this manual thoroughly before first use and retain it for future reference.
The HUDORA 205 Kick Scooter is designed for individuals weighing up to 220 lbs (100 kg) and is suitable for various age groups, including children (ages 6-12), teens, and adults. Its robust aluminum frame ensures durability and stability.

General Safety Guidelines:

- Always wear a helmet and appropriate protective gear (knee pads, elbow pads, wrist guards) when riding.
- Ensure all clamps, fasteners, and the folding mechanism are securely locked before each ride.
- Do not ride in traffic, on wet or uneven surfaces, or at night without proper lighting.
- Adhere to all local traffic laws and regulations regarding scooter use.
- Maintain a safe distance from pedestrians and other vehicles.
- Regularly inspect the scooter for wear and tear, especially the wheels, brakes, and steering components.





Image: Main view of the HUDORA 205 Adult Kick Scooter, showcasing its sleek design and large wheels.




Image: Illustration highlighting the scooter's durability for children and teens up to 100 kg, and safe braking with good grip tires.

Setup and Assembly

The HUDORA 205 scooter comes largely pre-assembled. Minor assembly and adjustments are required before first use. Necessary tools are typically included.

1. Unfolding the Scooter:

1. Place the scooter on a flat, stable surface.
2. Locate the folding mechanism near the base of the handlebar stem.
3. Push up the folding machine (lever/button) to release the lock.
4. Carefully unfold the handlebar stem until it clicks into the upright position.
5. Ensure the folding mechanism is fully engaged and locked. You may need to push down on the handlebar slightly to secure the lock.



Image: Step-by-step diagram illustrating how to unfold the scooter: 1. Push up folding mechanism, 2. Push down handlebar, 3. Take it anywhere.

2. Adjusting Handlebar Height:

1. Locate the quick-release clamp on the handlebar stem.
2. Open the quick-release clamp.
3. Adjust the handlebar to one of the four available height settings (approximately 33", 36", 38", 41" or 79 cm to 104 cm) to suit the rider's height. The handlebar should be at waist level for comfortable riding.
4. Close the quick-release clamp securely. Ensure there is no play in the handlebar.

Partner

We cooperated with SHENZHEN LIYU SPORTING GOODS CO., LTD., established on August 25, 2003, with a factory area of more than 10,000 square meters and more than 300 employees, specializing in electric scooters, high-end scooters, strollers and sports equipment and other products design, development, production and sales.

Image: Illustration showing the adjustable handlebar height range from 79 cm to 104 cm.

Operating Instructions

Riding the Scooter:

- Place one foot firmly on the non-slip deck.
- Use your other foot to push off the ground, gaining momentum.
- Once moving, place both feet on the deck, one behind the other, or side-by-side if comfortable and stable.
- Steer by gently leaning and turning the handlebars in the desired direction.

Braking:

The HUDORA 205 scooter is equipped with a rear foot brake for effective stopping.

- To brake, gently press your heel down on the rear fender brake.
- Apply pressure gradually to avoid sudden stops, which can lead to loss of balance.
- Practice braking at low speeds in a safe area before riding in more challenging environments.



Image: A person riding the HUDORA scooter, demonstrating proper foot placement and riding posture.

Folding for Transport:

The patented folding system allows for easy storage and transport.

- Ensure the scooter is stationary and on a flat surface.
- Follow the reverse steps of unfolding: release the folding mechanism and fold the handlebar stem down towards the deck.
- Secure the folded scooter with any integrated locking mechanisms or the included carrying strap.




Image: Illustration showing the heavy-duty folding mechanism and the powerful rear brakes for safety.

Maintenance

Regular maintenance ensures the longevity and safe operation of your HUDORA scooter.

Cleaning:

- Wipe down the scooter with a damp cloth after use, especially if ridden in wet or dirty conditions.
- Avoid using harsh chemicals or abrasive cleaners.
- Do not use high-pressure water jets, as this can damage bearings.

Inspections:

- **Before each ride:** Check that all bolts, nuts, and quick-release clamps are tight and secure. Ensure the folding mechanism is fully locked.
- **Wheels:** Inspect wheels for wear, cracks, or damage. Ensure they spin freely and that the axles are tight.
- **Bearings:** Listen for unusual noises from the wheels. If bearings feel rough or noisy, they may need cleaning or replacement.
- **Brake:** Verify that the rear foot brake functions effectively and that the fender is not excessively worn.
- **Handlebars and Grips:** Ensure grips are secure and not torn. Check the handlebar for any bending or damage.
- **Frame:** Periodically inspect the aluminum frame for any signs of cracks, dents, or structural fatigue.

Lubrication:

- Apply a small amount of lubricant to moving parts of the folding mechanism if it becomes stiff.
- Avoid over-lubrication, which can attract dirt.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Scooter does not lock in unfolded position.	Folding mechanism not fully engaged.	Ensure the handlebar stem is fully upright and push down firmly on the handlebar to engage the lock. The mechanism may require a specific angle to click into place.
Rattling sound during ride.	Loose components (e.g., wheel spacers, fasteners, folding mechanism).	Inspect all bolts, nuts, and the folding mechanism for tightness. Tighten any loose fasteners. Check wheel bearings and spacers.
Handlebar feels loose after adjustment.	Quick-release clamp not tightened sufficiently.	Open the quick-release clamp, ensure the handlebar is at the desired height, and close the clamp firmly. Adjust the tension of the clamp if necessary.
Brake not effective.	Worn brake fender or debris.	Inspect the rear fender brake for wear. Clean any debris from the brake area and wheel. If worn, consider replacing the fender.

Specifications

Feature	Detail
Model Number	Hudora 205 adult scooter
Product Dimensions (L x W x H)	88.9 x 11.43 x 104.14 cm (approx. 35 x 4.5 x 41 inches)
Item Weight	4.2 kg (approx. 9.26 lbs)
Maximum Weight Capacity	220 Pounds (100 kg)
Age Range	Kid (suitable for ages 6+, teens, and adults)
Brake Type	Rear Braking (Foot Brake)
Wheel Size	8 Inches (205 mm)
Frame Material	Aluminum
Handlebar Height Adjustment	Adjustable to 4 heights (approx. 33", 36", 38", 41" or 79 cm to 104 cm)
Special Features	Adjustable Handlebar Height, Foldable, Non-Slip Deck, Wide Platform, Dual Suspension
Number of Wheels	2
Wheel Material	Polyurethane



Image: Visual summary of key features including 8-inch wheels, rear braking, non-slip deck, foldable T-bars, and included carry strap.

Warranty and Support

HUDORA products are manufactured to high quality and safety standards. For any suggestions or assistance, please contact customer support. Responses are typically provided within 12 hours.
Your satisfaction and safety are a top priority. Regular quality assurance is integral to the product development and manufacturing process.
For further assistance, please refer to the contact information provided with your purchase or visit the official HUDORA website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N563SG0

More documents and user manuals: **https://manuals.plus/**