

[Manuals.plus](#) /

› [Cosco](#) /

› Cosco Topside Backless Booster Car Seat Instruction Manual

## Cosco BC030EFP

# Cosco Topside Backless Booster Car Seat Instruction Manual

Model: BC030EFP

## 1. PRODUCT OVERVIEW

---

The Cosco Topside Backless Booster Car Seat is designed to provide a comfortable and safe lift for children weighing 40-100 lbs and measuring 43-57 inches. This lightweight and compact booster seat helps ensure that vehicle seatbelts are properly positioned across your child's body. Its seat-friendly design aims to prevent scuffing or indentations on your vehicle's upholstery.



Figure 1: Cosco Topside Backless Booster Car Seat (Grape)

## 2. SAFETY INFORMATION

---

Always read and follow all instructions and warnings provided with your booster seat and your vehicle owner's manual. Failure to do so could result in serious injury or death.

- This booster seat is for children weighing 40-100 lbs and between 43-57 inches tall.
- Always use the vehicle's lap and shoulder belt system with this booster seat.
- Ensure the shoulder belt lies snugly across your child's shoulder and chest, not on the neck or face.
- Ensure the lap belt lies low across your child's hips, touching the thighs, not across the abdomen.
- Never use this booster seat with only a lap belt.
- Do not use this booster seat if it has been involved in a crash.

## 3. SETUP AND INSTALLATION

---

The Cosco Topside Backless Booster Car Seat is designed for simple placement and use with your vehicle's

existing seatbelt system.

### 3.1 Unpacking

- Remove the booster seat from its packaging.
- Inspect the booster seat for any damage or missing parts. Do not use if damaged.

### 3.2 Placement in Vehicle

1. Place the booster seat firmly on the vehicle's back seat. Ensure it is positioned flat against the vehicle seat back.
2. The booster seat should be placed in a seating position equipped with a lap and shoulder belt.



Figure 2: Booster seat placed in a vehicle, demonstrating its lightweight design.

### 3.3 Securing the Child

1. Have your child sit on the booster seat.
2. Guide the vehicle's lap belt across your child's upper thighs, ensuring it is low on the hips and snug.
3. Guide the vehicle's shoulder belt across your child's shoulder and chest. It should not rest on the neck or fall off the shoulder.
4. Buckle the seatbelt and pull the shoulder belt to remove any slack. The booster seat does not use a LATCH system; it is secured by the child and the vehicle's seatbelt.



Figure 3: Child correctly positioned and secured in the booster seat.

## 4. OPERATING INSTRUCTIONS

---

Using the Cosco Topside Backless Booster Car Seat is straightforward once installed correctly.

- Ensure your child is always properly buckled in the vehicle's lap and shoulder belt system when using the booster seat.
- Regularly check that the seatbelt is correctly positioned and snug before each trip.
- Instruct your child on the importance of staying properly seated and not playing with the seatbelt.

## 5. MAINTENANCE

---

Proper maintenance ensures the longevity and hygiene of your booster seat.

### 5.1 Cleaning the Fabric Cover

- The fabric cover is hand-washable.
- Use mild soap and cold water.
- Air dry the cover completely before reattaching it to the booster seat.
- Do not machine wash, bleach, iron, or dry clean the fabric cover.

### 5.2 Cleaning the Booster Shell

- Wipe the plastic shell with a damp cloth and mild soap.
- Do not use abrasive cleaners or solvents.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your booster seat, refer to the following common solutions.

- **Seatbelt does not fit correctly:** Ensure the booster seat is placed flat on the vehicle seat. Adjust the vehicle seatbelt to ensure it lies snugly across the child's shoulder/chest and low across the hips. If the vehicle's seatbelt system cannot be properly routed, the booster seat may not be suitable for that seating position or vehicle.
- **Booster seat slides on vehicle seat:** The booster seat is designed to be secured by the child and the vehicle's seatbelt. Ensure the child is seated properly and the seatbelt is snug. The seat-friendly design helps prevent movement and protects upholstery.
- **Child complains of discomfort:** Check the seatbelt routing for proper fit. Ensure the child meets the minimum

height and weight requirements for the booster seat. The booster features extra-plush padding for comfort.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Cosco
Model Number	BC030EFP
Minimum Weight Recommendation	40 Pounds
Maximum Weight Recommendation	100 Pounds
Minimum Height Recommendation	43 Inches
Maximum Height Recommended	57 Inches
Installation Type	Seat Belt
Orientation	Forward Facing
Harness Type	3-Point (Vehicle's)
Material Type	Plush
Item Weight	2 Pounds
Item Dimensions (D x W x H)	14"D x 15.5"W x 6.5"H
UPC	884392610463



Figure 4: Product dimensions for the booster seat.

## 8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Cosco Kids website. Keep your proof of purchase for any warranty claims.