Britax E1A328F

BRITAX Boulevard ClickTight US Car Seat Instruction Manual

Model: E1A328F

1. IMPORTANT SAFETY INFORMATION

Please read this entire instruction manual carefully before installing or using your BRITAX Boulevard ClickTight US Car Seat. Failure to follow these instructions can result in serious injury or death to your child. Keep this manual in the designated storage area on the car seat for future reference.

- · Always secure your child in the car seat according to the instructions.
- Never leave your child unattended in the car seat.
- Ensure the car seat is correctly installed in your vehicle before each use.
- Do not use accessories or parts not approved by Britax.

2. PRODUCT OVERVIEW

The BRITAX Boulevard ClickTight US Car Seat is designed to provide safety and comfort for your child from infancy through toddlerhood. It features the ClickTight installation system for secure and easy installation, a 14-position quick-adjust harness, and multiple recline positions.



Image 2.1: The BRITAX Boulevard ClickTight US Car Seat in Trek color, showcasing its design and harness system.

Key Features:

- ClickTight Installation: Simplifies car seat installation using the vehicle's seat belt.
- Quick-Adjust Harness: 14-position harness with Click & Safe Snug Indicator for proper tightness.
- SafeCell Impact Protection: Features a steel frame and impact-absorbing base for enhanced safety.
- Side Impact Protection: Two layers of side impact protection.
- 7-Position Recline: Adjustable recline for child comfort and proper installation angle.
- Removable Cover: For easy cleaning.

3. SPECIFICATIONS

Specification	Value		
Model Number	E1A328F		
Minimum Weight (Rear-Facing)	5 lbs (2.27 kg)		
Maximum Weight (Rear-Facing)	40 lbs (18.14 kg)		
Minimum Weight (Forward-Facing)	20 lbs (9.07 kg)		
Maximum Weight (Forward-Facing)	65 lbs (29.48 kg)		
Maximum Height	49 inches (124.46 cm)		
Product Dimensions (L x W x H)	23 x 18.5 x 23.5 inches (58.42 x 46.99 x 59.69 cm)		
Item Weight	27 lbs (12.25 kg)		
Material Type	Alloy Steel		
Installation Type	Vehicle Seat Belt (ClickTight)		



Image 3.1: Illustration of the car seat's weight and height limits for rear-facing (5-40 lbs) and forward-facing (20-65 lbs)

4. SETUP AND INSTALLATION

4.1 Unpacking

Carefully remove the car seat from its packaging. Inspect all components for any damage. Do not use the car seat if any part is damaged or missing. Retain all packaging materials until you are satisfied with the product.

4.2 ClickTight Installation (Vehicle Seat Belt)

The ClickTight system makes installation straightforward. Follow these steps for a secure installation:

- 1. **Open the ClickTight Panel:** Locate the ClickTight dial on the front of the car seat. Push the dial and turn it to lift the seat portion, revealing the belt path.
- 2. **Route the Seat Belt:** Thread the vehicle's lap and shoulder belt through the designated belt path. Ensure the belt is not twisted.
- 3. **Buckle the Seat Belt:** Buckle the vehicle's seat belt. Pull the shoulder belt to remove any slack from the lap portion.
- 4. Close the ClickTight Panel: Push the seat portion down firmly until it clicks into place. This action automatically tensions the seat belt for a secure installation.



Image 4.1: Visual guide to the three steps of ClickTight installation: Push Dial, Turn & Lift; Thread & Buckle; Click It Closed.



Image 4.2: A close-up view of the ClickTight mechanism opening, showing the red lever used to release the seat base for belt routing.

4.3 Recline Position Adjustment

The car seat offers 7 recline positions to ensure proper angle for your child and vehicle fit. Adjust the recline before installation. Refer to the easy-read level indicators on the side of the car seat to confirm the correct recline angle for rear-facing or forward-facing use.



Image 4.3: Side view of the car seat highlighting the 7-position recline mechanism and the easy-read level indicators for correct angle.



Image 4.4: A close-up of the easy-read recline indicators, showing distinct color-coded zones for rear-facing and forward-facing installation.

4.4 Harness Height Adjustment

The 14-position quick-adjust harness allows you to change the harness height without rethreading. Simply squeeze the handle at the top of the headrest and slide it up or down to position the shoulder straps at the correct height for your child.

- Rear-Facing: Shoulder straps must be at or below your child's shoulders.
- Forward-Facing: Shoulder straps must be at or above your child's shoulders.



Image 4.5: The car seat's headrest and harness system, illustrating the 14 adjustable positions for optimal fit as the child grows.

5. OPERATING INSTRUCTIONS

5.1 Securing Your Child

- 1. Place your child in the car seat with their back flat against the seat back.
- 2. Bring the harness straps over your child's shoulders and between their legs.
- 3. Insert the two buckle tongues into the buckle until they click.
- 4. Slide the chest clip up to armpit level.
- 5. Pull the harness adjustment strap until the harness is snug. The Click & Safe Snug Indicator will make an audible click when the harness is within the range of proper tightness.



Image 5.1: A close-up view of the car seat's 5-point harness buckle and chest clip, demonstrating how to secure the child.

5.2 Releasing Your Child

- 1. Press the red button on the harness buckle to release the buckle tongues.
- 2. Unclip the chest clip.
- 3. Loosen the harness straps by pressing the harness release button (usually located near the harness adjustment strap) and pulling the shoulder straps forward.
- 4. Remove your child from the car seat.

6. MAINTENANCE

6.1 Cleaning Instructions

- Fabric Cover: The car seat features a removable cover. Refer to the care label on the fabric for specific washing instructions. Typically, machine wash with cold water on a delicate cycle and air dry. Do not bleach or iron.
- Harness Straps: Wipe harness straps with a damp cloth. Do not machine wash, bleach, or immerse harness straps in water, as this may weaken them.

- Buckle: Clean the buckle by rinsing it with warm water. Do not use soaps or detergents.
- Shell and Base: Wipe the car seat shell and base with a damp cloth and mild soap.

6.2 Storage

When not in use, store the car seat in a cool, dry place away from direct sunlight. Ensure all components are clean and dry before storage.

7. TROUBLESHOOTING

- **Difficulty with ClickTight Installation:** Ensure the vehicle seat belt is fully extended and not twisted. Apply firm downward pressure on the car seat before closing the ClickTight panel. If the panel does not close easily, re-open it, re-route the belt, and try again.
- Harness Not Tightening: Check that the harness straps are not twisted or caught under the child. Ensure the harness release button is not pressed while attempting to tighten. Pull the harness adjustment strap straight out, not upwards or downwards.
- Harness Too Tight/Loose: Adjust the harness height to ensure the shoulder straps are at the correct level for your child's shoulders (at or below for rear-facing, at or above for forward-facing). Use the Click & Safe Snug Indicator to achieve proper tightness.
- Car Seat Wiggles After Installation: After closing the ClickTight panel, test for movement at the belt path. The car seat should not move more than one inch side-to-side or front-to-back. If it does, re-install the car seat following the ClickTight instructions carefully.

8. WARRANTY AND SUPPORT

Britax car seats are manufactured with high-quality materials and undergo rigorous testing. For specific warranty details, please refer to the warranty card included with your product or visit the official Britax website. If you encounter any issues or have questions regarding your BRITAX Boulevard ClickTight US Car Seat, please contact Britax customer support for assistance.

For further information or to register your product, visit the Britax Store.

Documents - Britax - E1A328F



[pdf] Specifications Dimension Guide Guide

BOULEVARD® CLICKTIGHT ® ARB BLVD SellSheet 2020 CAN britax ca s |||

BOULEVARD CLICKTIGHT ARB INFANT/CHILD CAR SEAT REAR-FACING 2.3 - 18 KG FORWARD-FACING 10 - 29.4 ... ontinue or change fabrics, parts, models or products or to make substitutions. Circa E1A325Q Trek **E1A328F** Spark E1A709L Vector E1A328H CoolFlow E1A329T Circa E1A325Q Cool N Dry E1A289V StayCle... lang:en score:26 filesize: 281.9 K page_count: 2 document date: 2020-12-02