

SpaRoom 0857681006834

SpaRoom PureMist Medium Ultrasonic Essential Oil Diffuser Instruction Manual

Model: PureMist (0857681006834)

IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using your SpaRoom PureMist Diffuser. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the diffuser on a firm, flat, and waterproof surface.
- Keep out of reach of children and pets. This diffuser is designed to be safe around children and pets, but direct supervision is recommended.
- Do not immerse the diffuser base in water or any other liquid.
- Use only clean tap water or distilled water. Do not use hot water.
- Do not add water beyond the maximum fill line indicated inside the water tank.
- Use only 100% pure essential oils. Avoid synthetic fragrances or corrosive substances.
- Unplug the diffuser from the power outlet before cleaning or when not in use.
- Do not block the mist outlet during operation.
- If the diffuser emits an unusual smell or sound, or if smoke appears, unplug it immediately.
- Do not attempt to repair the diffuser yourself. Contact customer support for assistance.



Image: The SpaRoom PureMist diffuser is designed with safety in mind for households with children and pets. Always ensure proper placement and supervision.

PRODUCT OVERVIEW

The SpaRoom PureMist Ultrasonic Essential Oil Diffuser uses ultrasonic technology to disperse a fine mist of water and essential oils into the air, creating an aromatic and humidifying effect. It features gradient lighting with 7 rotating colors and an automatic shut-off function for safety.

Components

- Diffuser Base with Power Button
- Water Tank (100 mL capacity)
- Cover
- AC Adapter



Image: The SpaRoom PureMist Diffuser, shown with its retail packaging, highlighting its compact design and simple controls.



Image: This illustration shows the process of adding essential oil to the diffuser, alongside key features such as ultrasonic misting, noise-free operation, BPA-free construction, and adjustable light options.



Image: This graphic explains the dual benefits of the diffuser: providing an aromatherapy effect by dispersing essential oil fragrance and offering humidification by adding moisture to the air.

SETUP

Follow these steps to set up your SpaRoom PureMist Diffuser for first use:

1. **Remove the Cover:** Gently lift the top cover from the diffuser base.
2. **Add Water:** Fill the water tank with clean tap water or distilled water up to the maximum fill line (100 mL). Do not overfill.
3. **Add Essential Oil:** Add 5-10 drops of your preferred 100% pure essential oil directly into the water tank. Adjust the number of drops based on desired aroma intensity.
4. **Replace the Cover:** Carefully place the cover back onto the diffuser base, ensuring it is securely seated.
5. **Connect Power:** Plug the AC adapter into the power port on the back of the diffuser, then plug the adapter into a standard electrical outlet.



Image: A visual guide demonstrating the simple 3-step setup process: removing the cover, adding water and essential oil, and then replacing the cover to begin diffusing.



Image: Close-up view of a hand carefully adding essential oil into the diffuser's water reservoir, illustrating the oil addition step.

OPERATING INSTRUCTIONS

Once set up, operating your PureMist Diffuser is straightforward.

Powering On/Off and Mist Function

- **To Turn On:** Press the power button located on the front of the diffuser once. The diffuser will begin to mist, and the gradient lighting will activate, cycling through colors.
- **Automatic Shut-Off:** The diffuser is designed to operate for up to 3 hours continuously and will automatically shut off when the water level is low or after approximately 3 hours of operation.
- **To Turn Off:** Press the power button again to turn off both the mist and the light functions.



Image: The PureMist diffuser operating on a desk, demonstrating its mist output and highlighting its capability for 3 hours of continuous operation before automatic shut-off.

Light Modes

The PureMist Diffuser offers multiple lighting options:

- When the diffuser is turned on, the light will automatically cycle through 7 gradient colors.
- To **freeze the light on a specific color**, press the power button a second time while the diffuser is on.
- To **turn off the light** while the mist is still operating, press the power button a third time.
- Pressing the power button a fourth time will turn off both the mist and the light.



Image: An illustration showcasing the SpaRoom PureMist diffuser's 7 rotating light colors, demonstrating the gradient lighting effect.

MAINTENANCE

Regular cleaning and proper storage will ensure the longevity and optimal performance of your diffuser.

Cleaning

Clean the diffuser after every 5-6 uses or every 3-5 days, especially when changing essential oils, to prevent mineral buildup and ensure proper mist output.

1. **Unplug:** Ensure the diffuser is unplugged from the power outlet.
2. **Empty Water:** Remove the cover and carefully empty any remaining water from the tank, pouring away from the air outlet.
3. **Wipe Tank:** Use a soft cloth or cotton swab with a small amount of rubbing alcohol or white vinegar to gently wipe the inside of the water tank and the ultrasonic plate.
4. **Rinse:** Rinse the tank with clean water, being careful not to get water into the air outlet.
5. **Dry:** Wipe all parts dry with a clean, soft cloth.

Important: Do not use harsh detergents, abrasive cleaners, or scrub brushes, as these can damage the diffuser.

Storage

When not in use for an extended period, ensure the diffuser is clean and completely dry. Store it in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

If you encounter issues with your SpaRoom PureMist Diffuser, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No mist or weak mist.	<ul style="list-style-type: none">◦ Insufficient water in the tank.◦ Water level exceeds MAX line.◦ Mineral buildup on the ultrasonic plate.◦ Mist outlet blocked.	<ul style="list-style-type: none">◦ Add water to the tank, ensuring it is between MIN and MAX lines.◦ Empty excess water.◦ Clean the ultrasonic plate as per maintenance instructions.◦ Ensure the mist outlet is clear.
Diffuser does not turn on.	<ul style="list-style-type: none">◦ Power adapter not properly connected.◦ No power from the outlet.◦ Diffuser is damaged.	<ul style="list-style-type: none">◦ Check if the power adapter is securely plugged into both the diffuser and the wall outlet.◦ Test the outlet with another appliance.◦ Contact customer support.
Light function not working correctly.	<ul style="list-style-type: none">◦ Incorrect button presses.◦ Internal malfunction.	<ul style="list-style-type: none">◦ Refer to the "Light Modes" section in Operating Instructions.◦ Contact customer support.
Unusual noise during operation.	<ul style="list-style-type: none">◦ Insufficient water.◦ Diffuser not on a flat surface.	<ul style="list-style-type: none">◦ Add water.◦ Place the diffuser on a stable, flat surface.

SPECIFICATIONS

Model Name	PureMist Medium Ultrasonic Essential Oil Diffuser
Model Number	0857681006834
Product Dimensions	4.1 x 4.1 x 7 inches
Item Weight	7.2 ounces
Water Capacity	100 Milliliters

Run Time	Up to 3 hours continuous mist
Lighting Features	7 rotating gradient colors, freeze color, light off mode
Safety Features	Automatic shut-off when water is low or after 3 hours
Manufacturer	SpaRoom

WARRANTY AND SUPPORT

For warranty information or technical support, please contact SpaRoom customer service. Details regarding specific warranty periods and coverage may vary and are typically provided with your product purchase documentation.

For further assistance, please visit the official SpaRoom website or contact their customer support directly. Contact information can usually be found on the product packaging or the manufacturer's website.

Online Support: [Visit the SpaRoom Store on Amazon](#)