Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zienstar HY001

Zienstar 2.4G Wireless Keyboard HY001 User Manual

Model: HY001 | Brand: Zienstar

Introduction

Thank you for choosing the Zienstar 2.4G Wireless Keyboard, Model HY001. This keyboard features a Spanish layout and is designed for convenience and efficiency. It connects wirelessly via a USB receiver, offering a maximum range of up to 10 meters. Its slim, ergonomic design and scissor-structure keys provide a comfortable typing experience. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.

Package Contents

- 1 x Zienstar 2.4G Wireless Keyboard (Spanish Layout)
- 1 x USB Receiver
- 1 x USB Cable
- User Manual (this document)

Note: 2 AAA batteries are required and are not included in the package.

Setup

1. Install Batteries

1. Locate the battery compartment on the back of the keyboard.
2. Open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Image: Rear view of the keyboard with the battery compartment open, indicating where to insert two AAA batteries. The text on the image states "Only need 2*AAA batteries, can maintain adequate power up to 12 month.(battery not included)."

2. Connect USB Receiver

1. Locate the USB receiver, typically stored within the battery compartment or a dedicated slot on the keyboard.
2. Plug the USB receiver into an available USB port on your computer, laptop, TV Box, or Smart TV.
3. The system should automatically detect and install the necessary drivers. No manual driver installation is usually required.

The keyboard is compatible with various devices including laptops, desktop PCs, TV Boxes, and Smart TVs.

Operating Instructions

Basic Usage

- Ensure the keyboard is powered on (if it has an on/off switch, usually located near the battery compartment).
- Begin typing. The keyboard should respond immediately.
- The keyboard features a standard Spanish QWERTY layout.

Special Functions (Fn Keys)

The keyboard includes function keys (F1-F12) that can perform multimedia and system shortcuts when pressed in

combination with the **Fn** key.

- **Fn + F1**: Media Player
- **Fn + F2**: Volume Down
- **Fn + F3**: Volume Up
- **Fn + F4**: Mute
- **Fn + F5**: Previous Track
- **Fn + F6**: Next Track
- **Fn + F7**: Play/Pause
- **Fn + F8**: Stop
- **Fn + F9**: Home Page
- **Fn + F10**: Email
- **Fn + F11**: My Computer
- **Fn + F12**: Favorites
- **Fn + P**: Screen Print (as indicated in product image)



Image: Top view of the Zienstar wireless keyboard, showing the Spanish key layout and the Fn key. An overlay indicates "Fn+P: ScreenPrint".

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the keyboard surface. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the keyboard.
- **Battery Replacement:** Replace AAA batteries when the keyboard's performance degrades or the indicator light (if present) signals low power.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the keyboard to water or other liquids.
- **Avoid Drops:** Handle the keyboard with care to prevent damage from drops or impacts.

Troubleshooting

Problem	Possible Cause	Solution
Keyboard not responding	◦ Low or dead batteries ◦ USB receiver not properly connected ◦ Out of wireless range ◦ Interference	◦ Replace batteries with new AAA batteries. ◦ Ensure the USB receiver is firmly plugged into a working USB port. Try a different port. ◦ Move the keyboard closer to the USB receiver (within 10 meters). ◦ Move away from other wireless devices or large metal objects.
Keys not working correctly	◦ Dirt or debris under keys ◦ Software issue	◦ Clean the keyboard, especially around the affected keys. ◦ Restart your computer or device.
Lag or delayed input	◦ Weak wireless signal ◦ Interference	◦ Move the keyboard closer to the USB receiver. ◦ Ensure no large obstacles are between the keyboard and receiver. ◦ Minimize other 2.4GHz wireless activity in the vicinity.

Specifications

- **Model Number:** HY001
- **Connectivity Technology:** 2.4G Wireless (USB Receiver)
- **Wireless Range:** Up to 10 meters
- **Keyboard Layout:** Spanish
- **Key Structure:** Scissor-switch
- **Power Source:** 2 x AAA Batteries (not included)
- **Compatible Devices:** Laptop, Desktop PC, TV Box, Smart TV
- **Color:** Silver-White
- **Dimensions:** Approximately 285.3mm (Length) x 133mm (Width) x 15.3mm (Height at thickest point), 9mm (Height at thinnest point)
- **Number of Buttons:** 78
- **UPC:** 712022424183



Image: Top and side views of the Zienstar wireless keyboard with measurements indicating its length (285.3mm), width (133mm), and varying thickness (9mm to 15.3mm).




Image: Close-up of the keyboard keys with a diagram showing the internal "SCISSOR STRUCTURE" mechanism, emphasizing "High-speed rebound silent operation."

Warranty and Support

For warranty information and technical support, please refer to the documentation provided at the time of purchase or contact Zienstar customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N6MB5MQ

More documents and user manuals: **https://manuals.plus/**