

Jamara 410030

JAMARA Robicar 410030-1:14 RC Transformable Robot Car User Manual

Model: 410030

1. INTRODUCTION

Thank you for choosing the JAMARA Robicar 410030-1:14 RC Transformable Robot Car. This manual provides essential information for the safe operation, setup, and maintenance of your new remote-controlled toy. Please read this manual thoroughly before first use and keep it for future reference.

The Robicar is a unique 2-in-1 remote-controlled vehicle that transforms between a sleek sports car and an impressive robot with a single button press. It features detailed design, LED lights, and a speaker for an engaging play experience.



Image 1.1: The JAMARA Robicar 410030 in its red sports car configuration, viewed from the side.

2. SAFETY INFORMATION

- **Age Recommendation:** This product is suitable for users aged 6 years and older. Adult supervision is recommended for younger children.

- **Battery Safety:**

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Insert batteries with correct polarity (+ and -).
- Remove exhausted batteries promptly.
- Do not recharge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging.
- Keep batteries out of reach of small children.

- **Operating Environment:** Operate the Robicar in open, clear areas away from obstacles, people, and pets. Avoid operating near water or in wet conditions.
- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years.
- **Modifications:** Do not attempt to modify or disassemble the product. This may cause damage and void the warranty.

3. PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- 1x JAMARA Robicar 410030 Model (Red)
- 1x 2.4 GHz Remote Control
- 1x Instruction Manual

Note: Batteries are not included and must be purchased separately.

4. SETUP

4.1 Battery Installation for the Model

1. Locate the battery compartment on the underside of the Robicar model.
2. Using a screwdriver (not included), open the battery compartment cover.
3. Insert **4 x AA 1.5V batteries** (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.



Image 4.1: Rear view of the Robicar in car mode. The battery compartment is located on the underside.

4.2 Battery Installation for the Remote Control

1. Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover.
3. Insert **3 x AAA 1.5V batteries** (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover.

4.3 Pairing the Remote Control

The 2.4 GHz remote control should automatically pair with the Robicar when both are powered on. If pairing issues occur, ensure both devices have fresh batteries and are within close proximity.

5. OPERATING INSTRUCTIONS

5.1 Basic Driving Functions

Use the joysticks on the remote control to operate the Robicar:

- **Forward:** Push the left joystick forward.
- **Backward:** Pull the left joystick backward.
- **Turn Left:** Push the right joystick left.
- **Turn Right:** Push the right joystick right.
- **Stop:** Release both joysticks to their neutral position.

5.2 One-Button Transformation

The Robicar can transform between car and robot mode with a single button press on the remote control. Locate the dedicated transformation button on your remote. Pressing this button will initiate the transformation sequence.



Image 5.1: The Robicar initiating its transformation from car to robot mode.



Image 5.2: The Robicar fully transformed into its robot configuration, viewed from the front.

5.3 LED Lights and Speaker

The Robicar features integrated LED lights that illuminate during operation and transformation, enhancing the visual experience. A built-in speaker provides sound effects during transformation and operation.



Image 5.3: The Robicar in robot mode with its LED lights activated.

6. MAINTENANCE

- **Cleaning:** Wipe the Robicar and remote control with a soft, dry cloth. Do not use chemical cleaners or water, as this can damage electronic components.
- **Storage:** When not in use, store the Robicar and remote control in a cool, dry place, away from direct sunlight and moisture. Remove batteries from both the model and the remote control if storing for extended periods to prevent leakage.
- **Battery Disposal:** Dispose of used batteries responsibly according to local regulations.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Robicar does not respond to remote control.	Batteries are low or incorrectly installed. Robicar or remote control is not powered on. Out of range.	Check and replace batteries in both the Robicar and remote control. Ensure correct polarity. Turn on both the Robicar and the remote control. Move closer to the Robicar.
Transformation is not smooth or incomplete.	Low batteries. Obstruction in the transformation mechanism.	Replace batteries in the Robicar. Check for any debris or foreign objects obstructing the moving parts.
Short operating time.	Batteries are old or low quality.	Use fresh, high-quality alkaline batteries.

8. SPECIFICATIONS

Model Number:	410030
Brand:	Jamara
Scale:	1:14
Dimensions (L x W x H):	17.5 x 27 x 31.6 cm (Car mode)
Weight:	833.6 g
Material:	Plastic
Operating Frequency:	2.4 GHz
Model Battery Requirement:	4 x AA 1.5V (not included)
Remote Control Battery Requirement:	3 x AAA 1.5V (not included)
Approximate Run Time:	Up to 1 hour
Recommended Age:	6 years and older

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact your retailer or the manufacturer directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Jamara

For further assistance, please visit the official Jamara website or contact their customer service department.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question