

Manuals.plus /

› **Bosch** /

› Bosch Smart Home Controller Instruction Manual

## Bosch Controller

# Bosch Smart Home Controller Instruction Manual

## INTRODUCTION

---

The Bosch Smart Home Controller serves as the central hub for your Bosch Smart Home system. It facilitates communication between all connected Bosch Smart Home devices and consolidates all system information. This manual provides essential information for setting up, operating, and maintaining your controller, ensuring optimal performance and security for your smart home environment.

## WHAT'S INCLUDED

---

Please verify that all components are present in the package:

- 1x Bosch Smart Home Controller
- 1x Power Supply Unit
- 1x Network Cable (RJ45)
- 1x Wall Mount with Fastening Material
- 1x Installation Manual (this document)



Image: Bosch Smart Home Controller and its retail packaging.



Image: The Bosch Smart Home Controller shown with its power supply, network cable, and wall mount.

Your browser does not support the video tag.

Video: This short video demonstrates the Bosch Smart Home Controller and its included components, highlighting its compact design and essential accessories for setup.

## SETUP

---

### 1. Initial Connection

Connect the Bosch Smart Home Controller to your internet router using the provided network cable (RJ45). Plug the power supply unit into the controller and then into a standard power outlet. The controller will power on automatically.



Image: Hands demonstrating the installation of the Bosch Smart Home Controller on a wall, showing its compact form factor.

## 2. App Installation and Pairing

Download the Bosch Smart Home app from your device's app store (available for iOS and Android). Follow the in-app instructions to pair your controller and integrate your smart home devices. The app provides a user-friendly interface for managing your system, creating routines, and monitoring device status.



Image: The Bosch Smart Home Controller positioned on a wooden surface, with a smartphone nearby showing the Bosch Smart Home app interface.

## OPERATING INSTRUCTIONS

---

### System Overview

The controller organizes communication between all linked Bosch Smart Home devices. It ensures guaranteed system operation even during sudden internet outages at home, thanks to standard local data storage. This means your essential smart home functions can continue to operate without an active internet connection.

### App Control

Control your Smart Home system easily with a tap of your finger in the Bosch Smart Home app. The app allows you to manage individual devices, create customized scenarios, set schedules, and monitor your home's status from anywhere.



Image: A screenshot of the Bosch Smart Home app displaying various smart home device controls and status indicators.

## KEY FEATURES

---


- **Central Hub:** Acts as the heart of the Bosch Smart Home system, coordinating all connected devices.
- **Automatic Communication:** Organizes communication between all paired Bosch Smart Home devices and bundles all information.
- **Offline Functionality:** Ensures system functionality even with temporary internet outages at home.
- **Data Security:** Features standard local data storage for enhanced data security and privacy.
- **Intuitive Control:** Offers simple operation via the user-friendly Bosch Smart Home app.



Central Hub



Data Protection



Real-time Status



Customization

## TROUBLESHOOTING

---

### Common Issues and Solutions

#### Device Not Connecting

Ensure the controller is powered on and securely connected to your internet router. Check your Wi-Fi network status and ensure it is operational. Restart the controller by unplugging it for 10 seconds and then plugging it back in. Attempt the pairing process again through the Bosch Smart Home app. For specific device pairing instructions, refer to the app's help section.

#### Internet Outage Impact

The Bosch Smart Home system is designed to function locally for basic operations during internet outages. This means devices can still communicate within your home network. However, remote access via the app and certain cloud-dependent features will be unavailable until internet connectivity is restored. Ensure your local network is functioning correctly.

#### App Issues

If the Bosch Smart Home app is unresponsive or experiencing glitches, try restarting the app or your smartphone. Ensure the app is updated to the latest version from your device's app store. For persistent issues, visit the Bosch Smart Home support website or contact their customer service for further assistance.

## SPECIFICATIONS

---

Property	Value
Color	White
Brand	Bosch
Voltage	230 Volt
Product Dimensions (L x W x H)	35L x 135B x 120H millimeters
Material	Acrylic
UPC	783320405174
Item Type Name	Smart Home Controller
Included Components	Controller, Power Supply, Network Cable (RJ45), Wall Mount with Fastening Material, Installation Manual
Number of Units	1




Image: The Bosch Smart Home Controller with its key dimensions (length, width, height) indicated.

## WARRANTY AND SUPPORT

---

For detailed warranty information, technical support, or service requests, please visit the official Bosch Smart Home website or contact their customer service directly. It is recommended to keep your purchase receipt and the product serial number handy for faster assistance.

Official Bosch Smart Home Website: [www.bosch-smarthome.com](http://www.bosch-smarthome.com)