

[Manuals.plus](#) /

› [Progress Lighting](#) /

› Progress Lighting Debut Collection 2-Light Farmhouse Bath Vanity Light User Manual

Progress Lighting P300009-009

Progress Lighting Debut Collection 2-Light Farmhouse Bath Vanity Light

INSTRUCTION MANUAL - MODEL P300009-009

Product Overview

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Progress Lighting Debut Collection 2-Light Farmhouse Bath Vanity Light. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: The Debut Collection 2-Light Farmhouse Bath Vanity Light in Brushed Nickel, featuring two exposed bulbs and a rectangular backplate.

Safety Information

WARNING: Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installing or servicing. Consult a qualified electrician if you are unsure about the installation process.

- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
- Use UL/cUL listed wire connectors suitable for the size, type, and number of conductors.
- Fixture is designed for indoor use only.
- Do not exceed the maximum wattage specified for the bulbs.

Proposition 65 Warning: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Package Contents

Verify that all components are present before beginning installation:

- Light Fixture Assembly
- Mounting Hardware (screws, wire connectors, mounting plate)
- Installation Sheet

Specifications

Brand	Progress Lighting
Model Name	Debut
Part Number	P300009-009
Color	Brushed Nickel
Material	Alloy Steel
Style	Farmhouse
Product Dimensions	14.25"L x 5.75"W x 7.88"H
Number of Light Sources	2
Bulb Base	E26
Max Wattage	60 watts per bulb
Voltage	120 Volts
Indoor/Outdoor Usage	Indoor




Image: Dimensional drawing showing the light fixture's length (14-1/4"), height (7-7/8"), and depth (5-3/4").

Setup and Installation

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before proceeding.

1. **Prepare the Mounting Surface:** Ensure the electrical box is securely mounted and capable of supporting the fixture's weight.
2. **Attach Mounting Plate:** Secure the mounting plate to the electrical box using the provided screws.
3. **Make Electrical Connections:** Connect the fixture's wires to the corresponding household wires (black to black, white to white, ground to ground) using UL/cUL listed wire connectors. Ensure all connections are secure.
4. **Mount the Fixture:** Carefully align the fixture's backplate with the mounting plate and secure it with the decorative nuts or screws.
5. **Install Bulbs:** Insert two E26 base bulbs (not included) into the sockets. Do not exceed 60 watts per bulb.
6. **Install Glass Shades (Optional):** If using glass accessory shades (available separately), carefully attach them according to their specific instructions.



Image: The vanity light shown with optional frosted seeded glass shades installed, providing diffused light.



Image: The vanity light shown with optional clear seeded glass shades installed, allowing for brighter, more direct light.

Operating Instructions

Once installed, restore power to the fixture at the circuit breaker. The light fixture operates via a standard wall switch (not included). This fixture is compatible with incandescent, CFL, or LED bulbs with an E26 base, up to 60 watts each. For dimming functionality, ensure you use dimmable bulbs and a compatible dimmer switch.

Maintenance

- **Cleaning:** To clean the fixture, disconnect power and wipe with a soft, dry cloth. Do not use abrasive cleaners or solvents as they may damage the finish.
- **Bulb Replacement:** Disconnect power before replacing bulbs. Allow bulbs to cool completely before touching. Replace with E26 base bulbs, not exceeding 60 watts.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on	1. Power is off. 2. Faulty bulb. 3. Incorrect wiring.	1. Check circuit breaker and wall switch. 2. Replace bulb. 3. Verify wiring connections (consult electrician if needed).
Flickering light	1. Loose bulb. 2. Incompatible dimmer switch/bulb.	1. Tighten bulb. 2. Ensure dimmer and bulbs are compatible.

Warranty

This product is covered by a **1-year limited warranty**. For specific details regarding warranty coverage and claims, please refer to the official warranty documentation provided with your purchase or contact Progress Lighting customer support.

Support

For technical assistance, missing parts, or any questions regarding your Progress Lighting product, please contact Progress Lighting customer support. Visit the official Progress Lighting website for contact information and additional resources.

You can also visit the [Progress Lighting Store on Amazon](#) for more products and information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question